Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- LAUNCH /
- > LAUNCH X-431 Pad II HD III Diagnostic Tool User Manual

LAUNCH X-431 Pad II HD III

LAUNCH X-431 Pad II HD III Diagnostic Tool User Manual

Model: X-431 Pad II HD III

1. Introduction

This manual provides detailed instructions for the proper use and maintenance of the LAUNCH X-431 Pad II HD III diagnostic addon module. It is designed to assist users in understanding the device's functions, setup procedures, operational guidelines, and troubleshooting steps to ensure optimal performance and longevity.

Please read this manual thoroughly before operating the device. Keep it for future reference.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your package. If any items are missing or damaged, please contact customer support.

- LAUNCH X-431 Pad II HD III Module
- Main Diagnostic Cable
- · Various OBD-II and proprietary diagnostic adapters
- Power Adapter
- Battery Clamp Cable
- Cigarette Lighter Cable
- USB Cable
- User Manual (this document)
- Storage Case



Figure 2.1: The complete LAUNCH X-431 Pad II HD III diagnostic kit, including the main module, various cables, adapters, and power accessories, all neatly organized within its durable black storage case.

3. SETUP

3.1 Initial Power-Up

- 1. Connect the power adapter to the X-431 Pad II HD III module.
- 2. Plug the power adapter into a suitable electrical outlet.
- 3. Press and hold the power button on the module until the screen illuminates.
- 4. Follow the on-screen prompts for initial language and region settings.

3.2 Connecting to a Vehicle

- 1. Locate the diagnostic port (OBD-II or proprietary) on the vehicle. Refer to the vehicle's service manual for exact location.
- 2. Select the appropriate diagnostic adapter from the kit.
- 3. Connect the main diagnostic cable to the X-431 Pad II HD III module.
- 4. Connect the other end of the main diagnostic cable to the selected adapter.

- 5. Plug the adapter into the vehicle's diagnostic port.
- 6. Ensure the vehicle's ignition is in the "ON" position (engine off).



Figure 3.1: The LAUNCH X-431 Pad II HD III module display, indicating connection status. Icons for vehicle, power, Bluetooth, and USB connectivity are visible, confirming the device's readiness for operation.

4. OPERATING INSTRUCTIONS

4.1 Vehicle Diagnosis

- 1. After connecting the module to the vehicle, select the "Diagnosis" option from the main menu.
- 2. Choose the vehicle manufacturer, model, and year as prompted.
- 3. The system will automatically identify the vehicle's VIN (Vehicle Identification Number) or prompt for manual entry.
- 4. Select the desired diagnostic function (e.g., Read Fault Codes, Clear Fault Codes, Live Data Stream, Actuation Test, Special Functions).
- 5. Follow the on-screen instructions to perform the selected diagnostic procedure.
- 6. Save or print diagnostic reports as needed.

4.2 Software Updates

Regular software updates are crucial for maintaining compatibility with new vehicle models and accessing the latest diagnostic features.

- Ensure the module is connected to a stable internet connection (Wi-Fi).
- Navigate to the "Update" section in the main menu.
- Select the available updates and follow the on-screen instructions to download and install them.
- Do not power off the device during an update process.

5. MAINTENANCE

- Cleaning: Use a soft, damp cloth to clean the module's screen and exterior. Avoid abrasive cleaners or solvents.
- **Storage:** Store the device and its accessories in the provided storage case in a cool, dry place, away from direct sunlight and extreme temperatures.
- Battery Care: For optimal battery life, avoid fully discharging the device frequently. Charge the device regularly, even if not in use for extended periods.
- Cable Inspection: Periodically inspect all cables and adapters for signs of wear, damage, or fraying. Replace damaged components immediately to prevent electrical hazards or diagnostic errors.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery; Power adapter not connected; Faulty power button.	Charge the device; Ensure power adapter is securely connected; Contact support if power button is unresponsive.
Cannot connect to vehicle.	Incorrect adapter; Loose cable connection; Vehicle ignition off; Damaged diagnostic port.	Verify adapter compatibility; Check all cable connections; Turn vehicle ignition to "ON"; Inspect vehicle's diagnostic port.
Software update fails.	Unstable internet connection; Insufficient storage space; Server issues.	Ensure stable Wi-Fi; Clear unnecessary files; Try updating again later.

7. Specifications

• Model: X-431 Pad II HD III

• Manufacturer Part Number: 301190246

• Dimensions: Approximately 25 x 16 x 8 inches (Storage Case)

• Item Weight: Approximately 12 pounds (Complete Kit)

• Connectivity: Wired (via diagnostic cables), Bluetooth, USB

• Operating System: (Not specified, but implied by "Pad II")

• Power Input: 12V/24V DC (Vehicle), AC/DC Adapter (Charging)

8. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the official LAUNCH website or contact your authorized dealer.

Online Resources: www.launchtech.com

Customer Support: Refer to the contact information provided with your purchase documentation.



Related Documents - X-431 Pad II HD III



Launch GIII X-Prog 3 Advanced Immobilizer & Key Programmer Guide

Comprehensive guide to the Launch GIII X-Prog 3, an advanced immobilizer and key programmer for automotive diagnostics and key programming. Covers features, supported brands, systems, chip brands, connection methods, update procedures, specifications, and package contents.



LAUNCH X-431 PAD V Automotive Diagnostic Tool User Manual

This document is the user manual for the LAUNCH X-431 PAD V, an advanced automotive diagnostic and maintenance tool. It details the product's features, technical specifications, setup procedures, diagnostic functions, maintenance resets, optional toolboxes, and troubleshooting guidance for professional automotive technicians.



LAUNCH X-431 V+ User's Manual: Vehicle Diagnostic Tool Guide

Comprehensive user manual for the LAUNCH X-431 V+ vehicle diagnostic tool. Covers features, operations, safety precautions, and troubleshooting for professional and consumer use. Visit www.x431.com for more.



LAUNCH X-431 Throttle III Quick Start Guide

Comprehensive quick start guide for the LAUNCH X-431 Throttle III automotive diagnostic tool. Covers safety precautions, accessory checklist, device setup, network configuration, user registration, VCI activation, vehicle connection methods for OBD II and non-OBD II systems, and initiating diagnostic procedures.

CADITION

Occupied Information

Copyright Information

Occupied In

LAUNCH X-431 PRO MINI User Manual: Comprehensive Automotive Diagnostic Guide

This user manual provides detailed information on the LAUNCH X-431 PRO MINI, an advanced Android-based vehicle diagnostic tool. Learn about its features, setup, safety precautions, diagnostic functions, special resets, and software updates for efficient automotive troubleshooting.



LAUNCH UK Product Catalogue: Professional Automotive Diagnostic Tools

Explore the comprehensive LAUNCH UK product catalogue featuring advanced X-431 series diagnostic tools, TPMS solutions, maintenance equipment, and testing tools for professional workshops. Discover innovative automotive diagnostic technology.