



[Manuals.plus](#) /

› [THE G-LAB](#) /

› THE G-LAB KORP-OXYGEN Performance Gaming Headset User Manual

THE G-LAB KORP-OXYGEN

THE G-LAB KORP-OXYGEN Performance Gaming Headset

Model: KORP-OXYGEN

1. INTRODUCTION

The G-Lab KORP-OXYGEN is a high-performance gaming headset designed for an immersive audio experience across multiple platforms. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your headset to ensure optimal performance and longevity.



Figure 1: The G-Lab KORP-OXYGEN Performance Gaming Headset.

Key Features:

- **High-Quality Audio:** Equipped with 40mm alloy speakers for remarkable audio clarity and powerful sound.
- **Detachable Microphone:** Offers flexibility for gaming communication or general audio listening. The microphone arm is flexible for precise positioning.
- **X-TRA BASS Stereo Technology:** Delivers powerful bass for an enhanced gaming, music, and movie experience.
- **Lightweight Design:** Weighing only 220 grams with a comfortable foam-covered headband for extended use.
- **Multi-Platform Compatibility:** Compatible with PS4, PC, Nintendo Switch, Xbox One, Xbox One X, smartphones, and tablets via a 3.5mm jack.

2. SETUP

Follow these steps to set up your KORP-OXYGEN headset with your device.



Figure 2: Headset with detachable microphone and inline control.

1. **Connect the Microphone (Optional):** If you intend to use voice chat, gently insert the detachable microphone into the dedicated port on the left earcup until it clicks into place. Ensure it is firmly seated.
2. **Connect to Device:** Plug the 3.5mm jack cable from the headset into the corresponding audio port on your gaming console (PS4, Xbox One, Nintendo Switch), PC, smartphone, or tablet.
3. **Adjust Volume:** Locate the inline volume control on the headset cable. Rotate the wheel to adjust the audio volume to your desired level.
4. **Microphone Mute/Unmute:** Use the switch on the inline control to mute or unmute the microphone. Ensure it is in the "ON" position for voice communication.
5. **Position Microphone:** If using the microphone, gently bend the flexible arm to position the microphone near your mouth for clear voice pickup.

Note: For some PC setups, you may require a Y-splitter cable (not included) if your PC has separate audio input (microphone) and output (headphone) jacks.

3. OPERATION

Operating your KORP-OXYGEN headset is straightforward. Here are the primary functions:



Figure 3: Inline volume control and microphone switch.

- **Audio Playback:** Once connected, audio from your device will be routed through the headset. Adjust the volume using the inline control or your device's volume settings.
- **Microphone Usage:**
 - Ensure the microphone is securely attached.
 - Slide the switch on the inline control to the "ON" position to activate the microphone.

- Slide the switch to the "OFF" position to mute the microphone.
- Adjust the flexible microphone arm for optimal voice clarity.
- **Comfort Adjustment:** The headband is adjustable. Gently slide the earcups up or down to find a comfortable fit that fully covers your ears. The foam padding on the earcups and headband provides comfort for long gaming sessions.

4. MAINTENANCE

Proper care and maintenance will extend the life of your Korp-Oxygen headset.

- **Cleaning:**
 - Use a soft, dry cloth to wipe down the earcups and headband.
 - For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
 - Do not immerse the headset in water or any liquids.
- **Storage:**
 - Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
 - Avoid tangling the cable. Consider wrapping it loosely or using a cable tie.
 - If the microphone is detachable, you may remove it for storage to prevent damage.
- **Handling:**
 - Avoid pulling the cable forcefully when disconnecting the headset. Always grasp the plug.
 - Do not twist or bend the microphone arm excessively.

5. TROUBLESHOOTING

If you encounter issues with your Korp-Oxygen headset, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from headset.	Cable not fully plugged in. Volume too low. Incorrect audio output selected on device.	Ensure the 3.5mm jack is fully inserted into the device's audio port. Increase volume using the inline control and your device's volume settings. Check your device's audio settings and select the headset as the output device.
Microphone not working.	Microphone not attached or loose. Microphone muted. Incorrect audio input selected on device.	Ensure the detachable microphone is securely attached. Slide the microphone switch on the inline control to the "ON" position. Check your device's audio settings and select the headset microphone as the input device.
Sound distortion or static.	Loose connection. Interference. Volume too high.	Reconnect the 3.5mm jack. Move away from other electronic devices that may cause interference. Lower the volume.

If the problem persists after trying these solutions, please contact G-LAB customer support or refer to their official website for further assistance.

6. SPECIFICATIONS

Feature	Detail
Brand	THE G-LAB
Model Name	KORP-OXYGEN
Connectivity Technology	Wired (3.5mm Jack)
Driver Size	40mm
Frequency Range	20 Hz - 20,000 Hz
Impedance	32 ohms
Microphone	Detachable, Flexible
Weight	220 grams
Material	Leather (earcups/headband padding)
Color	Black
Ear Placement	Over-ear (Supra-auriculaire)
Control Type	Inline Tactile Control (Volume, Mic On/Off)
Compatibility	PS4, PC, Nintendo Switch, Xbox One, Xbox One X, smartphones, tablets

7. WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the warranty card included with your purchase or visit the official THE G-LAB website. Warranty terms and conditions may vary by region and retailer.

If you require technical support or have questions not covered in this manual, please contact THE G-LAB customer service through their official website or the contact information provided with your product packaging.

Official Website: www.the-g-lab.com