

[Manuals.plus](#) /

> [Famidoc](#) /

> Famidoc FDTH-V0-22 Baby Bath and Room Thermometer Instruction Manual

Famidoc AL-US-SWJ-01B

Famidoc Baby Bath and Room Thermometer

Model: FDTH-V0-22 (AL-US-SWJ-01B)

Instruction Manual

INTRODUCTION

The Famidoc Baby Bath and Room Thermometer is designed to provide accurate and reliable temperature readings for your baby's bath water and room environment. Crafted with safe materials and an intuitive design, it aims to enhance safety and comfort for your little one.

Key features include:

- Easy to use: Activates automatically by shaking, no on-off button.
- Waterproof design for safe use in bath water.
- Quick and accurate temperature updates every 5 seconds on an easy-to-read LCD screen.
- High and low temperature alarms: Displays "COLD" for low temperature and "HOT" with a red LED light flashing for high temperature.
- Safe and harmless built-in battery with at least a 1-year lifespan.



Figure 1: Famidoc Baby Bath and Room Thermometer (Blue)

This thermometer is not just a safety tool but also a fun floating toy for your baby, making bath time enjoyable and worry-free.

SETUP

The Famidoc Baby Bath and Room Thermometer comes with a built-in battery. No initial setup is required beyond ensuring the battery is functional.

Battery Information:

- The device includes 1 CR2 battery.
- The battery is designed for a lifespan of at least 1 year.
- To activate the thermometer, simply shake it gently. There is no manual on/off button.



Figure 2: Compact size for easy handling

OPERATING INSTRUCTIONS

Using your Famidoc thermometer is straightforward:

1. **Activation:** Gently shake the thermometer to activate its display. The LCD screen will light up and begin showing the temperature.
2. **Temperature Measurement:**
 - For bath water, place the thermometer directly into the water. It will float and continuously update the temperature every 5 seconds.
 - For room temperature, simply place the thermometer in the desired room.
3. **Temperature Alarms:** The thermometer provides visual alerts for extreme temperatures:
 - If the temperature is too low, the LCD will display "COLD" and a blue LED light will flash.
 - If the temperature is too high, the LCD will display "HOT" and a red LED light will flash.
4. **Optimal Temperature:** For baby baths, a temperature between 98.6°F (37°C) and 100.4°F (38°C) is generally recommended. Always test the water with your elbow or wrist before placing your baby in the

bath.



Figure 3: Thermometer in use during bath time



Figure 4: Temperature indicators (Cold, Optimal, Hot)

MAINTENANCE

Proper care ensures the longevity and accuracy of your Famidoc thermometer:

- **Cleaning:** Hand wash only. Use a soft cloth and mild soap if necessary. Do not use abrasive cleaners or immerse the entire unit in water for extended periods beyond normal bath use.
- **Battery Replacement:** When the number display appears incomplete or the screen is dark, it indicates that the battery needs to be replaced. Refer to the battery compartment on the back of the device for instructions on how to open and replace the CR2 battery.
- **Storage:** If you do not plan to use the thermometer for a long period, it is recommended to remove the battery to prevent leakage and preserve battery life. Store in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

If you encounter any issues with your Famidoc thermometer, please refer to the following common solutions:

Problem	Possible Cause	Solution
Display is incomplete or dark.	Low battery.	Replace the CR2 battery.
Thermometer does not activate.	Insufficient shaking or low battery.	Shake more vigorously. If issue persists, replace battery.
Inaccurate temperature readings.	Sensor obstruction or extreme environmental conditions.	Ensure sensor area is clean. Allow device to acclimate to room temperature before use.

SPECIFICATIONS

Feature	Detail
Brand	Famidoc
Model Name	AL-US-SWJ-01B
Color	Blue
Age Range (Description)	Baby
Outer Material	Plastic
Display Type	LCD
Power Source	Battery Powered (1 CR2 battery included)
Response Time	5 seconds
Resolution	0.1°F or 0.1°C
Upper Temperature Rating	50 Degrees Celsius
Lower Temperature Rating	89.6 Degrees Fahrenheit
Item Weight	1.44 ounces
Item Length	3.28 Inches
Special Feature	Alarm
Reusability	Reusable
Product Care Instructions	Hand Wash Only

WARRANTY AND SUPPORT

Famidoc is committed to providing high-quality products. For any warranty claims, technical support, or inquiries regarding your Baby Bath and Room Thermometer, please contact Famidoc customer service directly through their official channels or the retailer where the product was purchased. Please retain your proof of purchase for warranty validation.

