



Manuals.plus /

› Pyle /

› Pyle Compact Battery-Operated Megaphone User Manual

Pyle PMP31BL

Pyle Compact Battery-Operated Megaphone User Manual

Model: PMP31BL

1. INTRODUCTION

Thank you for purchasing the Pyle Compact Battery-Operated Megaphone. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Voice Mode:** Amplifies voice or sound spoken into the microphone.
- **Siren Alert Mode:** Activates an emergency alarm tone with a push of a button.
- **30 Watt Power Output:** Provides high-powered PA sound.
- **Audio Projection Range:** Up to 800+ yards.
- **Adjustable Volume:** For noise control in various situations.
- **Compact & Portable Design:** Features a foldable handle for easy transport and storage.
- **Battery Operated:** Requires (4) x D batteries.
- **Ergonomic Pistol Grip:** For comfortable handling.

2.2 Components

Familiarize yourself with the main components of your megaphone:

- Microphone (integrated)
- Power ON/OFF Switch
- Volume Control Slider
- Alarm Button
- Music/Speak Button (for melody playback)
- Battery Compartment
- Foldable Handle
- Wrist Strap



Figure 1: Pyle Compact Battery-Operated Megaphone (Blue model shown).

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment at the rear of the megaphone, typically under the red cap.
2. Twist or unlatch the cap to open the compartment.
3. Insert four (4) D-size batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Securely close the battery compartment cap.

COMPACT MEGAPHONE SPEAKER



Requires (4) x 'D' Batteries,
(Not Included)



Quick Folding
Handle



Ergonomic Grip



Figure 2: Battery installation in the megaphone.

3.2 Attaching the Wrist Strap

Attach the provided wrist strap to the designated loop on the megaphone's handle for added security during use.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

To power on the megaphone, slide the ON/OFF switch to the "ON" position. A red indicator light will illuminate, confirming the unit is active. To power off, slide the switch to the "OFF" position.

POWERFUL SOUND & PORTABLE SOLUTION



Figure 3: Megaphone control panel with power switch and other functions.

4.2 Voice Mode

1. Ensure the megaphone is powered on.
2. Adjust the volume slider to your desired level.
3. Speak clearly into the microphone located at the rear of the horn.
4. The megaphone will amplify your voice.

4.3 Siren Alert Mode

To activate the siren, press and hold the "ALARM" button. Release the button to stop the siren sound.

4.4 Music/Melody Playback

To play a pre-programmed melody, press the "MUSIC/SPEAK" button. Press it again to stop the playback.

5. MAINTENANCE

- **Cleaning:** Wipe the megaphone with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage and store the megaphone in a cool, dry place. The foldable handle allows for compact storage.
- **Battery Care:** Replace all batteries simultaneously. Do not mix old and new batteries or different types of batteries.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound or low volume	Batteries are dead or incorrectly installed. Volume control is too low. Power switch is off.	Replace batteries or check polarity. Increase volume using the slider. Ensure power switch is in the "ON" position.
Distorted sound	Volume set too high. Low batteries.	Decrease volume. Replace batteries.

7. SPECIFICATIONS

Feature	Detail
Model Number	PMP31BL
Power Output	30 Watts (Max)
Audio Projection Range	Up to 800+ yards
Power Source	4 x D Batteries (not included)
Dimensions (L x W x H)	6.15" x 6.15" x 10.04"
Item Weight	1.07 lbs
Color	Blue
UPC	842893111520

8. WARRANTY AND SUPPORT

For warranty information or technical support, please visit the official Pyle website or contact their customer service. Keep your purchase receipt as proof of purchase.

Pyle Official Website: www.pyleusa.com

