

[Manuals.plus](#) /

> [Geepas](#) /

> Geepas Mechanical Health Scale GBS4162 User Manual

Geepas GBS4162

Geepas Mechanical Health Scale GBS4162 User Manual

Model: GBS4162

INTRODUCTION

Thank you for choosing the Geepas Mechanical Health Scale GBS4162. This manual provides essential information for the safe and effective use of your new weighing scale. Please read these instructions thoroughly before use and retain them for future reference.

SAFETY INFORMATION

- Place the scale on a hard, flat surface for accurate readings. Avoid carpets or uneven floors.
- Do not use the scale on wet or slippery surfaces to prevent falls.
- Do not jump on the scale. Step on and off gently.
- Keep the scale away from extreme temperatures and direct sunlight.
- This scale is designed for personal body weight monitoring. Do not use it for commercial or medical diagnostic purposes.
- Maximum weight capacity is 125 kg. Do not exceed this limit.

PRODUCT OVERVIEW

The Geepas Mechanical Health Scale GBS4162 features a robust design with an easy-to-read analog display. It is designed for reliable and consistent weight measurement.



Figure 1: Top view of the Geepas Mechanical Health Scale GBS4162. This image displays the scale's blue weighing platform and the prominent analog dial located at the top center, which indicates weight measurements.



Figure 2: Side view of the Geepas Mechanical Health Scale GBS4162. This image provides a profile view of the scale, highlighting its compact form factor and the side angle of the analog display.

Components:

- **Weighing Platform:** The surface where you stand.
- **Analog Display:** Shows your weight in kilograms.

- **Zero Adjustment Knob:** Located near the display, used to set the scale to zero before use.

SETUP

1. **Unpack:** Carefully remove the scale from its packaging.
2. **Placement:** Place the scale on a firm, flat, and level surface. Ensure it is not on carpet, rugs, or uneven tiles, as this can affect accuracy.
3. **Zero Adjustment:** Before first use, and periodically thereafter, ensure the analog dial points exactly to zero. If it does not, gently turn the zero adjustment knob (usually a small wheel or lever near the dial) until the needle aligns with the '0' mark.

OPERATING INSTRUCTIONS

1. **Step On:** Gently step onto the center of the weighing platform with bare feet. Stand still and distribute your weight evenly.
2. **Read Measurement:** Wait for the needle on the analog display to stabilize. Read the weight indicated by the needle.
3. **Step Off:** Gently step off the scale. The needle should return to zero. If it does not, re-adjust using the zero adjustment knob.
4. For consistent results, weigh yourself at the same time each day, preferably in the morning before meals and after using the restroom.

MAINTENANCE

- **Cleaning:** Wipe the scale surface with a soft, damp cloth. Do not use abrasive cleaners or immerse the scale in water.
- **Storage:** Store the scale in a cool, dry place. Avoid storing it vertically or in areas with high humidity.
- **Inspection:** Periodically check for any loose parts or damage. Do not attempt to repair the scale yourself.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Inaccurate readings	Scale is on an uneven or soft surface (e.g., carpet). Zero adjustment is incorrect.	Place the scale on a hard, flat, level surface. Adjust the zero knob to ensure the needle points to '0' before use.
Needle does not return to zero	Zero adjustment is off.	Turn the zero adjustment knob until the needle aligns with '0'.
Scale appears damaged	Physical impact or misuse.	Discontinue use. Contact customer support for assistance. Do not attempt to repair.

SPECIFICATIONS

- **Model:** GBS4162
- **Type:** Mechanical Health Scale
- **Display:** Analog
- **Maximum Capacity:** 125 Kilograms
- **Measurement Type:** Kilograms
- **Material:** Aluminum

- **Color:** Blue
- **Form Factor:** Mini

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact Geepas customer service. Keep your purchase receipt as proof of purchase.

For further assistance, visit the official Geepas website or contact their authorized service centers.

