

ACTIVESHOP H6001L

ACTIVESHOP AZZURRO H6001L LED Magnifying Lamp

User Manual

1. INTRODUCTION

Thank you for choosing the ACTIVESHOP AZZURRO H6001L LED Magnifying Lamp. This lamp is designed to provide magnified viewing with bright, shadowless LED illumination, making it ideal for detailed tasks such as beauty treatments, electronics repair, crafting, and reading. The bifocal lens offers both 5 and 8 diopter magnification for versatile use. Please read this manual thoroughly before installation and operation to ensure safe and efficient use of the product.



Figure 1: Overview of the AZZURRO H6001L LED Magnifying Lamp.

2. SAFETY INSTRUCTIONS

To prevent injury or damage to the product, always follow these basic safety precautions:

- Ensure the power supply voltage matches the lamp's requirements (230V, 50/60Hz).
- Do not operate the lamp with a damaged cord or plug. Contact qualified service personnel for repairs.
- Keep the lamp away from water or other liquids. Do not use in wet environments.
- Avoid direct exposure of eyes to the LED light for extended periods.
- Do not place the lamp in direct sunlight or near heat sources.
- Always unplug the lamp from the power outlet before cleaning or when not in use.
- Keep the protective lens cover closed when the lamp is not in use to prevent dust accumulation and accidental damage.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- AZZURRO H6001L LED Magnifying Lamp with articulated arm
- Table Clamp
- Power Cable (integrated)
- User Manual (this document)

4. SETUP AND INSTALLATION

Follow these steps to set up your magnifying lamp:

1. **Attach the Table Clamp:** Securely fasten the provided table clamp to a sturdy desk or workbench surface. Ensure the surface thickness is compatible with the clamp's opening. Tighten the screw until the clamp is firmly in place.



Figure 2: Table Clamp for secure mounting.

2. **Insert the Lamp Arm:** Insert the base pin of the lamp's articulated arm into the hole on the table clamp. Ensure it is fully seated and stable.
3. **Connect to Power:** Plug the lamp's power cable into a standard 230V, 50/60Hz electrical outlet.

5. OPERATING INSTRUCTIONS

Operating your AZZURRO H6001L lamp is straightforward:

1. **Power On/Off:** Locate the power switch on the lamp head. Flip the switch to the 'ON' position to illuminate the LEDs. Flip it to 'OFF' to turn off the light.



Figure 3: Lamp head with LEDs illuminated.

2. **Adjusting the Arm:** The lamp features an articulated arm that allows for flexible positioning. Carefully adjust the arm to bring the magnifying lens and light over your work area. Hold the arm firmly when adjusting to prevent sudden movements.
3. **Using the Magnifying Lens:** The lamp is equipped with a bifocal lens offering 5 and 8 diopter magnification.

Position your object under the lens to achieve the desired magnification. The larger area provides 5 diopters, while a smaller, inner section offers 8 diopters for finer detail.



Figure 4: Detail of the bifocal magnifying lens.

4. **Protective Cover:** When the lamp is not in use, close the protective cover over the lens to shield it from dust and scratches.

6. MAINTENANCE

Proper maintenance ensures the longevity and performance of your lamp:

- **Cleaning the Lens:** Gently wipe the magnifying lens with a soft, lint-free cloth. For stubborn smudges, use a small amount of lens cleaning solution. Avoid abrasive cleaners or harsh chemicals.
- **Cleaning the Lamp Body:** Wipe the lamp's arm and head with a soft, damp cloth. Do not use excessive moisture or allow water to enter the electrical components.
- **Storage:** When not in use for extended periods, unplug the lamp and store it in a clean, dry place with the protective lens cover closed.

7. TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply. Power switch is off.	Check if the power cable is securely plugged into a working outlet. Ensure the power switch on the lamp head is in the 'ON' position.
Light is dim or flickering.	Unstable power supply. LEDs reaching end of life.	Try plugging the lamp into a different outlet. If the issue persists, contact customer support.

Problem	Possible Cause	Solution
Magnification is blurry.	Lens is dirty. Object is not at optimal focal distance.	Clean the lens according to maintenance instructions. Adjust the lamp arm and object distance until the image is clear.

8. SPECIFICATIONS

Feature	Specification
Model	H6001L
Power	5 W
Voltage	230 V
Frequency	50/60 Hz
Light Source	54 LED Diodes
Light Intensity	243 lm
Lens Type	Bifocal
Magnification	5 Diopters and 8 Diopters
Arm Length	105 cm
Lamp Head Dimensions	29 x 21 cm
Product Weight	6.6 kg (14.55 lbs)
Power Source	Electric Cable
Manufacturer	ACTIVESHOP

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question