

[Manuals.plus](#) /

> [Luxton Home](#) /

> Luxton Home Automatic Hand Sanitizer Dispenser with Stand (Model HDS-1406) - Instruction Manual

## Luxton Home HDS-1406

# Luxton Home Automatic Hand Sanitizer Dispenser with Stand

**MODEL: HDS-1406**

Instruction Manual

## 1. PRODUCT OVERVIEW

The Luxton Home Automatic Hand Sanitizer Dispenser with Stand (Model HDS-1406) provides a touchless solution for hand hygiene. This unit is designed for various environments, offering convenience and promoting cleanliness.

- **Touchless Operation:** Infrared sensor for automatic dispensing.
- **Refillable Bottle:** 1200ml capacity, compatible with gel or liquid sanitizers.
- **Sturdy Stand:** Heavy-duty steel construction for stability.
- **Drip Catcher:** Integrated tray to prevent spills and maintain cleanliness.
- **Power Source:** Requires 4 C-sized batteries (not included).



Figure 1: Luxton Home Automatic Hand Sanitizer Dispenser with Stand.

## 2. SETUP AND ASSEMBLY

### 2.1 Unpacking and Component Identification

Carefully remove all components from the packaging. Verify that all parts are present:

- Automatic Dispenser Unit
- Steel Floor Stand (multiple pole sections)
- Heavy-duty Base

- Drip Catcher
- Refillable Inner Bottle (1200ml)
- Assembly Hardware (screws, wrench, screwdriver)
- Dispenser Key



Figure 2: Exploded view of the dispenser and stand components.

## 2.2 Stand Assembly

1. Screw the pole sections of the stand together firmly.
2. Insert the provided screw through the hole in the heavy-duty base.
3. Attach the assembled pole to the base by screwing it onto the inserted screw. Tighten securely using the provided wrench.
4. Attach the dispenser holder to the top pole section using the provided screw and wrench.

## 2.3 Dispenser Unit Preparation

1. Use the provided key to open the dispenser unit. Insert the key into the two small holes on the top of the dispenser and push down to release the front cover.
2. Locate the battery compartment inside the dispenser. Insert 4 C-sized batteries, ensuring correct polarity (+/-). Batteries are not included.
3. Remove the rubber cap from the refillable inner bottle.
4. Pour your preferred gel or liquid hand sanitizer into the bottle. Do not overfill.
5. Replace the rubber cap firmly onto the bottle.

6. Place the filled bottle back into the dispenser unit.
7. Close the dispenser unit cover until it clicks securely.

## 2.4 Final Assembly

1. Slide the dispenser unit onto the dispenser holder attached to the stand. Ensure it is seated firmly.
2. Attach the drip catcher to the stand directly below the dispenser unit.

Video 1: Assembly instructions for the Luxton Home Automatic Hand Sanitizer Dispenser Stand Kit.

## 3. OPERATING INSTRUCTIONS

1. Locate the power switch, typically inside the dispenser unit or on its side. Slide the switch to the 'ON' position.
2. Place your hand flat under the dispenser's sensor. The sensor will detect your hand and automatically dispense a measured amount of sanitizer.
3. Rub your hands together thoroughly until dry.

The integrated drip catcher is designed to collect any excess sanitizer, keeping the area clean and preventing floor damage.



Figure 3: Touchless operation of the dispenser with hand under sensor.

Video 2: Demonstration of the automatic, touch-free hand sanitizer dispenser in operation.

## **4. MAINTENANCE**

### **4.1 Refilling Sanitizer**

When the sanitizer level is low, refill the inner bottle by following steps 1-6 of Section 2.3. Ensure the dispenser is turned off before refilling to prevent accidental dispensing.



## Eco-friendly

Eliminate plastic waste with our refillable  
1200 ml capacity bottle

Figure 4: Process of refilling the internal sanitizer bottle.

### 4.2 Battery Replacement

When the dispenser stops working or the indicator light signals low battery, replace the 4 C-sized batteries by following steps 1-2 of Section 2.3. Always ensure correct polarity.

### 4.3 Cleaning

- Wipe the exterior of the dispenser and stand with a soft, damp cloth.
- Regularly empty and clean the drip catcher to prevent residue buildup.
- Avoid using abrasive cleaners or solvents that may damage the finish.

## 5. TROUBLESHOOTING

| Problem               | Possible Cause   | Solution  |
|-----------------------|--|---|
| Dispenser not working | Low or dead batteries; Power switch off; Sanitizer bottle empty or improperly installed. | Replace batteries; Turn power switch ON; Refill sanitizer bottle and ensure it is correctly seated. |

| Problem                                      | Possible Cause                      | Solution  |
|--|-------------------------------------|---|
| Sanitizer dispenses inconsistently or sprays | Nozzle clogged; Sensor obstruction. | Clean the dispenser nozzle; Ensure nothing is blocking the sensor.  |
| Stand is unstable                            | Loose connections.                  | Ensure all pole sections and the base screw are tightened securely. |

## 6. SPECIFICATIONS

- **Model:** HDS-1406
- **Brand:** Luxton Home
- **Material:** Steel (Stand), Plastic (Dispenser)
- **Color:** White (Dispenser), Black (Stand)
- **Product Dimensions (Dispenser):** 5.9"L x 11"W x 7.1"H
- **Liquid Volume:** 1200 Milliliters
- **Item Weight:** 11.47 pounds (approx. for entire unit)
- **Power:** 4 C-sized batteries (not included)
- **UPC:** 732326290635



Figure 5: Key dimensions of the Luxton Home Automatic Hand Sanitizer Dispenser with Stand.

## 7. WARRANTY AND SUPPORT

For information regarding product warranty or technical support, please contact Luxton Home customer service directly. Contact details can typically be found on the product packaging or the official Luxton Home website.

