#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Conceptronic /
- > Conceptronic AMDIS04 1080P Full HD Webcam User Manual

# Conceptronic AMDIS04\_3

# Conceptronic AMDIS04 1080P Full HD Webcam User Manual

Model: AMDIS04\_3

#### INTRODUCTION

The Conceptronic AMDIS04 1080P Full HD Webcam with Microphone is designed to provide high-quality video and audio for various communication needs. It offers 1080P Full HD resolution at 30 frames per second, ensuring clear and smooth video playback. Equipped with a built-in microphone featuring noise reduction, this webcam is suitable for video conferencing, online courses, gaming, and live streaming. Its plug-and-play USB 2.0 interface ensures easy setup with most mainstream operating systems.

# PACKAGE CONTENTS



Image: The AMDIS04 webcam shown alongside its retail box, highlighting key features like 1080P resolution, USB plug & play, and noise-reduction microphone.

Please check the package contents upon unboxing to ensure all items are present:

- Conceptronic AMDIS04 1080P Full HD Webcam with integrated USB cable
- Privacy Cover

## **SETUP**

Follow these steps to set up your Conceptronic AMDIS04 webcam:

#### 1. Mounting the Webcam:

The webcam features a versatile stand that can be placed on a flat surface or clipped onto the top edge of a monitor or laptop screen. Adjust the stand to achieve the desired angle and stability.



Image: The adjustable base of the AMDIS04 webcam, designed for stable placement on a desk or attachment to a monitor.

## 2. Connecting to Your Computer:

Locate an available USB 2.0 port on your computer. Plug the USB cable from the webcam into the USB port. The webcam is plug-and-play, meaning no additional drivers are typically required for Windows, macOS, or Android operating systems.



Image: The AMDIS04 webcam with its integrated USB cable, ready for connection to a computer.

## 3. Privacy Cover Installation:

The included privacy cover can be attached over the webcam lens when not in use to ensure privacy. Align the cover with the webcam lens and gently press it into place.



Image: The AMDIS04 webcam with the privacy cover slid over the lens, providing physical privacy when the camera is not in use.

# 4. Software Recognition:

Once connected, your operating system should automatically detect the webcam. You can then open any video conferencing application (e.g., Zoom, Skype, Microsoft Teams) or camera application to select the "Conceptronic AMDIS04" as your video and audio input device.

# **OPERATING THE WEBCAM**



Image: Front view of the AMDIS04 webcam, showing the lens and "FHD 1080P" indicators.

The Conceptronic AMDIS04 webcam is designed for ease of use with minimal manual controls. Most functions are managed through your computer's operating system or the specific application you are using.

#### · Video Capture:

Open your preferred video application (e.g., camera app, video conferencing software). Select the Conceptronic AMDIS04 as your primary camera. The webcam will automatically adjust focus and exposure for optimal image quality.

#### • Audio Capture:

The built-in microphone with noise reduction will automatically be detected. Ensure it is selected as your audio input device in your application settings for clear voice transmission.

#### · Privacy:

Utilize the included privacy cover to physically block the camera lens when it is not in use, providing an additional layer of security and peace of mind.

# **M**AINTENANCE

Proper maintenance ensures the longevity and optimal performance of your webcam:

#### • Cleaning the Lens:

Gently wipe the webcam lens with a soft, lint-free cloth. For stubborn smudges, use a small amount of lens cleaning solution applied to the cloth, not directly to the lens.

#### • General Cleaning:

Clean the body of the webcam with a dry or slightly damp cloth. Avoid using harsh chemicals or abrasive cleaners.

#### • Storage:

When not in use, especially during travel, store the webcam in a protective pouch or its original packaging to prevent scratches and damage. Always use the privacy cover.

## **TROUBLESHOOTING**

If you encounter issues with your Conceptronic AMDIS04 webcam, refer to the following common solutions:

Problem	Possible Cause / Solution
Webcam not detected by computer.	Ensure the USB cable is securely plugged into a working USB port.  Try a different USB port on your computer.  Restart your computer.  Check Device Manager (Windows) or System Information (macOS) to see if the webcam is listed.
No video output.	Make sure the privacy cover is not blocking the lens.  Verify that the correct webcam is selected in your application's video settings.  Check if other applications are using the webcam simultaneously. Close them if necessary.
No audio from microphone.	Ensure the Conceptronic AMDIS04 microphone is selected as the audio input device in your application and system sound settings.  Check microphone privacy settings in your operating system.  Adjust microphone volume levels.
Poor video quality (blurry, dark, grainy).	Ensure adequate lighting in your environment.  Clean the webcam lens.  Check your internet connection speed if streaming.  Ensure your application is set to use 1080P resolution if available.

## **SPECIFICATIONS**

Feature	Detail
Model Number	AMDIS04_3
Video Resolution	1920 x 1080 pixels (Full HD)

Feature	Detail
Frame Rate	30 fps (frames per second)
Viewing Angle (Horizontal)	65°
Interface	USB 2.0
Microphone	Built-in with Noise Reduction
Color	Black
Mounting Type	Stand (Clip/Desk)
Cable Length	1.5 m
Dimensions (W x D x H)	75 mm x 33 mm x 110 mm (approx. 2.95 x 1.30 x 4.33 inches)
Weight	86 g (approx. 3.03 oz)
Supported OS	Windows 7/8/8.1/10, macOS (10.6 to 10.15), Android

# WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Conceptronic website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims.

Note: Specific warranty terms may vary by region and retailer.

© 2024 Conceptronic. All rights reserved.

## Related Documents - AMDIS04\_3

AMDISO9B  Ouick Installation Guide  Schnellinstallation Guide  Schnellinstallation Rapide Guide Installation Rapide Gyers Telephore (Installation Sayoka Norticipe Proteins) Guid de Installaçõe Rapide	Conceptronic AMDIS09B Webcam: Quick Installation Guide  This quick installation guide provides setup instructions for the Conceptronic AMDIS09B webcam.  Learn about system requirements, mounting, connecting, Windows Hello setup, and safety precautions.
ABBY22G  Oulck Installation Guide  Schnellinstallation Repode Guarde Invalidation Repode Guarde Invali	Conceptronic ABBY22G USB to HDMI Adapter Quick Installation Guide  Quick installation guide for the Conceptronic ABBY22G USB to HDMI adapter, detailing system requirements, driver installation, connection, display configuration, and safety information.

Conceptronic Digital Video Recorder User Manual
User manual for the Conceptronic Digital Video Recorder (DVR). Provides comprehensive guidance on setup, operation, features, safety, and troubleshooting for surveillance systems.