

Manuals.plus /

› Sennheiser /

› Sennheiser IE 100 PRO Dynamic In-Ear Monitoring Headphones User Manual

## Sennheiser IE 100 PRO

# Sennheiser IE 100 PRO Dynamic In-Ear Monitoring Headphones User Manual

Model: IE 100 PRO

## INTRODUCTION

The Sennheiser IE 100 PRO in-ear monitoring headphones are designed for demanding live performances, offering a precise acoustic overview. Featuring a newly developed dynamic driver, these headphones deliver a warm, powerful, and detailed sound. They ensure distortion-free audio even in loud environments. Ideal for musicians and DJs, the IE 100 PRO provides exceptional sound quality and high wearing comfort for live sessions, production, or daily use.

## WHAT'S IN THE BOX

Your Sennheiser IE 100 PRO package includes the following items:

- IE 100 Pro CLEAR In-Ear Monitors
- Detachable Cable
- Protective Case
- Cleaning Tool
- Foam and Silicone Ear Adapters (various sizes)




Figure 1: Contents of the Sennheiser IE 100 PRO package.

The IE 100 PRO features an innovative, dynamic 10-mm broadband transducer for powerful, precise monitoring. Its dynamic driver system minimizes acoustic stress factors, ensuring homogeneous, distortion-free audio reproduction. The slim and ergonomic single-driver design provides a secure and comfortable fit, complemented by excellent sound shielding from optimized earpieces and flexible silicone/foam tips. The stage-proof cable includes an internal cable duct for enhanced durability.

## Reinventing the single dynamic driver principle

### English

- This natural, warm and precise in-ear monitor sound allows you to focus on your performance
- Detachable, stage-proof cable with break-proof connection (patent pending) and reinforced ear hook
- Comfortable fit due to compact profile and lightweight yet rugged ear mold design
- Extra value with soft pouch and range of ear tips, individually adaptable to your ear canal depth

### Deutsch

- Durch den natürlichen, warmen und präzisen Klang dieser In-Ear-Hörer können Sie sich ganz auf Ihre Performance konzentrieren
- Abnehmbares, Bühnentaugliches Kabel mit verstärktem Ohrbügel und sicherer Steckverbindung (Patent angemeldet)
- Hoher Tragekomfort durch kompaktes Profil und leichte und zugleich robuste Gehäuseform
- Praktisches Zubehör: Transport-Etui und verschiedene Ohradapter für die individuelle Anpassung an Ihre Ohrkanaltiefe

### Français

- Ce retour de scène intra-auriculaire a un son naturel, chaud et précis vous permet de vous concentrer sur votre performance.
- Câble amovible parfait sur scène avec connecteur incassable (brevet déposé) et contour d'oreille renforcé
- Port confortable grâce au profil compact et au design d'embout auriculaire léger et robuste
- Atouts supplémentaires tels que l'étui souple et la gamme d'embouts d'écouteurs ajustables à votre canal auditif

### Español

- El sonido natural, cálido y preciso del auricular de vigilancia intraaural le permite concentrarse en su rendimiento
- Cable desmontable para escenarios con conexión antirrotura (pendiente de patente) y gancho para las orejas reforzado.
- Se acopla cómodamente gracias a su contorno compacto y ligero, aunque posee un molde robusto
- Complementos adicionales como el estuche blando y la gama de almohadillas que se adaptan a cada canal auditivo

### 中文

- 自然、温暖而精准的入耳监听级音质,可让您专注于自己的表演
- 拥有可拆卸、防破损演出专用线缆(正在申请专利)和加固耳扣
- 采用外观小巧、轻盈耐用的耳膜设计,佩戴舒适无比
- 附赠柔软的收纳袋和各式耳垫,使用者可根据自己的耳道结构进行调整,尊享完美佩戴体验

### Русский

- Естественный, «теплый» и четкий звук вставных наушников для мониторинга позволяет вам сосредоточиться на выступлении
- Отсоединяемый кабель устойчив к условиям сцены, оснащен соединителем с защитой от обрыва (подана патентная заявка) и упрочненным заушиком
- Комфортное прилегание благодаря компактной, легкой и в то же время прочной конструкции ушного вкладыша
- Дополнительная эффективность с мягкой сумкой и набором ушных насадок с возможностью индивидуальной подгонки с учетом глубины ушного канала пользователя



## IE PRO SERIES

### IE 400 PRO

Delivers clarity with presence and power for the big stage.

### IE 500 PRO

Unmatched sound experience - Developed for perfection. The monitor engineer's choice.

**SENNHEISER**

www.sennheiser.com

Sennheiser is a trademark of Sennheiser electronic GmbH & Co. KG, Am Lüder 1, 30900 Wedemark, Germany

Designed and engineered in Germany  
Made in China

Figure 2: Sennheiser IE 100 PRO in-ear monitors.

Your browser does not support the video tag.

Video 1: Official product overview highlighting key features and design of the Sennheiser IE 100 PRO in-ear monitors.

## SETUP

### 1. Selecting the Right Ear Tips

Proper ear tip selection is crucial for optimal sound quality and comfort. The package includes various sizes of silicone and foam ear adapters. Experiment with different sizes to find the pair that fits most snugly and comfortably in your ear canals. A good seal ensures excellent sound isolation and proper audio reproduction.

### 2. Attaching the Cable

The IE 100 PRO features a detachable cable for convenience and durability. To attach, align the connector on the cable with the port on the earbud and push gently until it clicks into place. Ensure a secure connection for both earbuds.



Figure 3: Detachable cable connection point on the earbud.

### 3. Wearing the In-Ear Monitors

Place the earbuds into your ear canals, ensuring the cable loops over the top of your ears for a secure and comfortable fit. Adjust the cable behind your head or under your chin as preferred. The ergonomic design is intended to provide stability during movement.



Figure 4: Correct wearing of the IE 100 PRO in-ear monitors.

## OPERATING INSTRUCTIONS

The Sennheiser IE 100 PRO are passive in-ear monitors designed for direct connection to an audio source. They do not feature active noise cancellation or built-in media controls on the cable itself, relying on the connected device for volume and playback management.

### 1. Connecting to an Audio Source

Connect the 3.5 mm jack of the IE 100 PRO cable to the headphone output of your audio device (e.g., monitoring system, audio interface, smartphone, laptop). Ensure the connection is firm.

### 2. Volume Adjustment

Adjust the listening volume directly on your connected audio source. Start with a low volume and gradually increase it to a comfortable level to prevent hearing damage.

## MAINTENANCE

Regular maintenance helps prolong the life and maintain the performance of your IE 100 PRO in-ear monitors.

- **Cleaning Ear Tips:** Remove the silicone or foam ear tips from the earbuds. Clean them gently with a soft,

damp cloth. For foam tips, follow the manufacturer's specific cleaning instructions. Ensure they are completely dry before reattaching.

- **Cleaning Earbuds:** Use the provided cleaning tool to carefully remove any earwax or debris from the earbud nozzles. Pay attention to the internal foam filters within the nozzle and ear tips; ensure they are correctly oriented after cleaning.
- **Cable Care:** The stage-proof cable is designed for durability. Avoid sharp bends or excessive pulling. If the cable becomes dirty, wipe it with a dry, soft cloth.
- **Storage:** When not in use, store your IE 100 PRO in the provided protective case to prevent damage from dust, dirt, and physical impact.

## TROUBLESHOOTING

If you encounter issues with your Sennheiser IE 100 PRO, try the following troubleshooting steps:

Problem	Possible Cause	Solution
Poor sound quality or lack of bass	Incorrect ear tip size or improper fit in the ear canal.	Experiment with different ear tip sizes to achieve a snug fit and good seal. Ensure the earbuds are worn correctly.
No sound from one or both earbuds	Loose cable connection or faulty audio source.	Check that the detachable cable is securely connected to both earbuds and the audio source. Test with a different audio source or cable if possible.
Distorted sound	Audio source volume too high or earbud nozzles are blocked.	Reduce the volume on your audio source. Clean the earbud nozzles and ear tips using the provided cleaning tool.

## SPECIFICATIONS

Feature	Specification
Brand	Sennheiser
Model Name	IE 100 Pro
Color	Clear
Ear Placement	In Ear
Form Factor	Universal In Ear
Impedance	20 Ohms
Frequency Range	20Hz - 18,000Hz
Sensitivity	115 dB
Noise Control	Sound Isolation
Audio Driver Type	Dynamic Driver
Cable Features	Detachable
Headphone Jack	3.5 mm Jack
Item Weight	160 Grams
Water Resistance Level	Water Resistant

## WARRANTY AND SUPPORT

### Warranty Information

The Sennheiser IE 100 PRO comes with a 2-year manufacturer's warranty. Please retain your proof of purchase for warranty claims.

### Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official Sennheiser website or contact their customer service department. You can find detailed contact information and FAQs on their support pages.