

CooSpo PC-0310-62

CooSpo Replacement USB Charger Cable Instruction Manual

Model: PC-0310-62

1. PRODUCT OVERVIEW

This document provides detailed instructions for the CooSpo Replacement USB Charger Cable (Model: PC-0310-62). This cable is specifically designed to charge compatible CooSpo heart rate monitor armbands and other specified devices. Please read this manual thoroughly before use to ensure proper and safe operation.

2. PRODUCT FEATURES

- **Dedicated Design:** Specifically engineered as a replacement charger cable for CooSpo HW706, HW702A, and HW807 heart rate monitor armbands.
- **Convenient Charging:** Facilitates easy and convenient charging for your compatible devices, suitable for both home and travel use.
- **Safety Protections:** Incorporates built-in short circuit protection, over-voltage protection, and over-current protection to safeguard your device during charging.
- **Tangle-Free Design:** The cable is designed to resist tangling, enhancing user convenience.
- **Compact Size:** Features a compact length of approximately 8.46 inches (21.5 cm).
- **Secure Packaging:** Supplied in a sealed anti-static bag to protect the cable during transit and storage.

3. COMPATIBILITY

The CooSpo Replacement USB Charger Cable is compatible with the following devices:

- CooSpo HW706 Heart Rate Monitor Armband
- CooSpo HW702A Heart Rate Monitor Armband
- CooSpo HW807 Heart Rate Monitor Armband
- Schwinn IC4 Heart Rate Monitor
- DDP Yoga Heart Rate Monitor Armband
- Echelon HR Armband Monitor

Important Note: This cable is **NOT** suitable for the CooSpo newest armband HW9.

4. SETUP AND USAGE

Follow these steps to charge your compatible heart rate monitor armband:

1. **Connect to Device:** Align the magnetic charging pins of the cable with the charging contacts on your heart rate monitor armband. The magnetic connection will secure the cable in place.
2. **Connect to Power Source:** Insert the USB-A end of the charging cable into a compatible 5V DC power adapter or a USB port on a computer.
3. **Charging Indicator:** Refer to your heart rate monitor armband's specific instructions for its charging indicator light behavior. Typically, a light will illuminate to indicate charging is in progress.
4. **Charging Completion:** Once charging is complete, disconnect the cable from both the power source and your device.

Plug and Play



Image: CooSpo heart rate monitor armband connected to the charging cable, showing a green indicator light for charging.



Image: Coospo heart rate monitor armband being charged by connecting the USB cable to a laptop's USB port.

5. SAFETY INFORMATION

To ensure safe operation and prolong the life of your charging cable and device, please observe the following:

- Always use a DC 5V power adapter or a computer USB port for charging. Using power sources with higher voltage may damage the cable or your device.
- The cable features built-in short circuit, over-voltage, and over-current protection. However, avoid exposing the cable to extreme conditions or physical damage.
- Do not attempt to disassemble or modify the charging cable.
- Keep the charging cable away from water, moisture, and high temperatures.
- Ensure the charging contacts on both the cable and your device are clean and dry before connecting.



Protect Your
Device



Over-voltage
Protection



Over-current
Protection



Image: Visual representation of the charging cable's magnetic connector and USB-A plug, highlighting its safety features including device protection, over-voltage, and over-current protection.

6. SPECIFICATIONS

Brand	CooSpo
Model Number	PC-0310-62
Connector Type	USB (Male-to-Male)
Cable Type	USB
Compatible Devices	Heart Rate Monitor Armbands (CooSpo HW706/HW702A/HW807, Schwinn IC4, DDP Yoga, Echelon)
Special Feature	Tangle Free
Color	Black
Number of Pins	4
Item Weight	0.01 Kilograms (0.317 ounces)

Indoor/Outdoor Usage	Indoor
Customer Package Type	Sealed anti-static bag
Maximum Voltage	5 Volts (DC)
Package Dimensions	8.46 x 2.2 x 0.47 inches

7. MAINTENANCE

To maintain the performance and longevity of your charging cable:

- Store the cable in a cool, dry place when not in use.
- Avoid bending or kinking the cable sharply, especially near the connectors.
- Clean the magnetic charging pins and USB connector periodically with a dry, soft cloth to remove any dust or debris.
- Do not use harsh chemicals or abrasive materials for cleaning.

8. TROUBLESHOOTING

If you encounter issues while charging, consider the following:

- **Device Not Charging:** Ensure the magnetic pins are correctly aligned and securely connected to your heart rate monitor. Verify that the USB-A end is fully inserted into a working 5V DC power adapter or computer USB port.
- **Slow Charging:** Ensure you are using a reliable power source. Charging from a computer USB port might be slower than a dedicated wall adapter.
- **Intermittent Connection:** Check for any visible damage to the cable or connectors. Ensure the charging contacts on both the cable and the device are clean.
- **Compatibility Issue:** Double-check that your heart rate monitor model is listed as compatible with this charging cable (refer to Section 3).

9. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video demonstrating the features and usage of the CooSpo USB Charging Cable.

10. ADDITIONAL PRODUCT IMAGES



Image: Close-up view of the magnetic charging connector end of the CooSpo USB cable.



Image: Close-up view of the standard USB-A connector end of the CooSpo USB cable.

11. WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your CooSpo Replacement USB Charger Cable, please refer to the official CooSpo website or contact their customer service directly. Details are typically provided with your product packaging or on the manufacturer's website.

You can visit the [CooSpo Store on Amazon](#) for more product information.