



[Manuals.plus](#) /

› [TZS First Austria](#) /

› TZS First Austria Foot Spa with Vibration, Bubble Massage, Infrared, and Heating Function, Model FA-8115-3

TZS First Austria FA-8115-3

TZS First Austria Foot Spa with Vibration, Bubble Massage, Infrared, and Heating Function, Model FA-8115-3

User Instruction Manual

[Safety Instructions](#)

[Product Components](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance &](#)

[Cleaning](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your TZS First Austria Foot Spa, Model FA-8115-3. Please read these instructions carefully before first use and retain them for future reference.



Image 1.1: TZS First Austria Foot Spa, Model FA-8115-3.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of electric shock, burns, fire, or injury, always follow basic safety precautions when using electrical appliances.

- Read all instructions before use.
- Do not use while sleeping or drowsy.
- Do not use on infants, invalids, or by persons insensitive to heat.
- Do not operate under a blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- Never use pins or other metallic fasteners with this appliance.
- Close supervision is necessary when this appliance is used by, on, or near children or invalids.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended

by the manufacturer.

- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not use outdoors.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- To disconnect, turn all controls to the OFF position, then remove plug from outlet.
- Do not stand on or in the foot spa. Use only while seated.
- Never use the foot spa on open wounds, inflamed areas, or skin eruptions.
- Consult your doctor before using this foot spa if you have any medical conditions, including diabetes, pregnancy, heart disease, or circulatory problems.

3. PRODUCT COMPONENTS

The TZS First Austria Foot Spa includes the following parts:

- Foot Spa Unit with Massage Function
- Instruction Manual
- Pedicure Attachment (Brush)
- Pedicure Attachment (Massage)
- Pedicure Attachment (Pumice Stone)
- Aromabox (integrated)
- LED Display Control Panel
- Foldable Handle



Image 3.1: Overview of the foot spa with control panel and pedicure attachments.

The unit features massage nubs on the surface for enhanced foot stimulation.

4. SETUP

1. **Unpack:** Carefully remove the foot spa from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the foot spa on a flat, stable, and dry surface. Ensure the power cord can reach an electrical outlet without being stretched or obstructed.
3. **Fill with Water:** Fill the foot spa with warm or cold water. Do not exceed the maximum fill line indicated inside the basin. The water level should cover your feet comfortably.
Caution: Do not operate the unit without water. Ensure the water temperature is not excessively hot before placing your feet in the spa.
4. **Add Essential Oils (Optional):** If desired, add a few drops of essential oil to the integrated aromabox. Do not add oils directly to the water.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet.

Your browser does not support the video tag.

Video 4.1: Demonstration of the TZS First Austria foldable foot spa setup and features. This video shows the product's design, folding mechanism, and basic operation, including filling with water and using the handle.

5. OPERATING INSTRUCTIONS

The foot spa features an LED display and control buttons for easy operation.



Image 5.1: Close-up of the LED control panel.

5.1 Control Panel Functions

- **Power Button:** Turns the unit ON/OFF.
- **Temperature Control (+/-):** Adjusts the water temperature within the range of 35°C to 45°C. The LED display shows the current temperature.

- **Bubble Massage Button:** Activates/deactivates the bubble massage function.
- **Vibration Massage Button:** Activates/deactivates the vibration massage function.
- **Infrared Light Button:** Activates/deactivates the infrared heating function.
- **Program Selection:** The unit offers 2 massage programs. Press the program button to cycle through the available options.

5.2 Using the Foot Spa

1. After filling the foot spa and plugging it in, press the **Power Button** to turn on the unit.
2. Place your feet gently into the water.
3. Use the **Temperature Control (+/-)** buttons to set your desired water temperature. The unit will maintain this temperature.
4. Activate the **Bubble Massage**, **Vibration Massage**, and/or **Infrared Light** functions as desired using their respective buttons.
5. Select one of the 2 available massage programs if you wish to use a pre-set combination of functions.
6. Utilize the integrated massage nubs and the included pedicure attachments for additional foot care.



Image 5.2: Pedicure attachments (brush, massage, pumice stone) for comprehensive foot care.

7. Enjoy your foot spa session. Recommended session duration is 15-30 minutes.
8. After use, press the **Power Button** to turn off the unit and unplug it from the electrical outlet.

Your browser does not support the video tag.

Video 5.3: This video demonstrates the various massage functions, infrared light, and temperature control of the TZS First Austria Foot Spa, highlighting its ease of use.

6. MAINTENANCE & CLEANING

Regular cleaning and maintenance will ensure the longevity and hygienic operation of your foot spa.

1. **Drain Water:** After each use, unplug the unit and carefully pour out the water. The foldable handle can assist with transport.
2. **Clean Basin:** Wipe the basin with a soft, damp cloth and a mild, non-abrasive cleaner. Rinse thoroughly with clean water.
3. **Clean Attachments:** Remove the pedicure attachments and clean them with soap and water. Allow them to air dry completely before reattaching or storing.
4. **Exterior Cleaning:** Wipe the exterior of the unit with a soft, dry cloth. Do not immerse the unit in water or allow water to enter the control panel.
5. **Storage:** Ensure the foot spa is completely dry before folding it for storage. Store in a cool, dry place away from direct sunlight. The foldable design allows for space-saving storage.

7. TROUBLESHOOTING

If you encounter any issues with your foot spa, please refer to the following table before contacting customer support.

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outlet malfunction; unit malfunction.	Ensure the power cord is securely plugged into a working outlet. Test the outlet with another appliance. If the problem persists, contact customer support.
No bubbles/vibration.	Function not activated; insufficient water level.	Press the respective bubble/vibration button. Ensure water level is above the minimum fill line.
Water not heating up.	Heating function not activated; temperature setting too low.	Activate the infrared/heating function. Increase the temperature setting using the '+' button. Allow time for water to heat.
Unit makes unusual noise.	Foreign object in the basin; unit malfunction.	Turn off and unplug the unit. Inspect the basin for any foreign objects and remove them. If the noise continues, discontinue use and contact customer support.

8. TECHNICAL SPECIFICATIONS

- **Model:** FA-8115-3
- **Brand:** TZS First Austria

- **Power:** 450W
- **Functions:** Vibration massage, Bubble massage, Infrared heat, Heating function
- **Programs:** 2
- **Attachments:** 3 (Brush, Massage, Pumice Stone)
- **Temperature Range:** 35°C - 45°C (Adjustable)
- **Max. Shoe Size:** EU 43
- **Product Dimensions (L x W x H):** 41 x 34 x 21.5 cm
- **Net Weight:** 2.1 kg
- **Manufacturer:** Timetron Warenhandelsgesellschaft m.b.H.
- **Country of Origin:** China



Image 8.1: Product dimensions for the TZS First Austria Foot Spa.

9. WARRANTY & SUPPORT

Your TZS First Austria Foot Spa is covered by a manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions.

For technical support, spare parts, or warranty claims, please contact your retailer or the manufacturer directly. Contact information can typically be found on the product packaging or the manufacturer's official website.

Manufacturer: Timetron Warenhandelsgesellschaft m.b.H.

© 2024 TZS First Austria. All rights reserved.
This manual is subject to change without prior notice.