

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Easysleep](#) /

› [Easysleep White Noise Machine \(Model i-1\) Instruction Manual](#)

Easysleep i-1

Easysleep White Noise Machine (Model i-1) Instruction Manual

Brand: Easysleep | Model: i-1

PRODUCT OVERVIEW

The Easysleep White Noise Machine (Model i-1) is designed to provide a calming environment with 25 non-looping soothing sounds and adjustable night lights. It features 32 levels of volume control, a 5-setting sleep timer, and a memory function.



Image: Easysleep White Noise Machine displaying its 25 soothing sound options.

This compact device is powered by either AC or USB, making it suitable for home, office, or travel use.

EasySleep Noise Machine

--Better for your sleep



Relaxing Sound



Soft Night Light



Anxiety Relieving



Image: Easysleep White Noise Machine on a nightstand, highlighting its sleep benefits.

SAFETY INFORMATION

Please adhere to standard safety precautions. Avoid exposing the device to extreme temperatures, humidity, or direct sunlight. Do not disassemble or attempt to repair the device yourself. Keep out of reach of children and pets. Ensure proper ventilation during use. If applicable, be mindful of noise exposure limits to prevent hearing damage.

SETUP

1. Power Connection

Connect the device using the provided AC adapter or a USB cable. The device can be powered via AC or USB. Ensure the power source is stable and matches the device's requirements.



Image: Powering the device via USB or AC adapter.

2. Placement

Place the device on a stable, flat surface away from water, excessive heat, or direct sunlight. Its compact design makes it easy to fit in various locations.

Compact Design---
Just put it in your bag for a dream trip

Size : 3.9*3.9*2.3 inch



Image: The compact design of the white noise machine for easy portability.

OPERATING INSTRUCTIONS



Image: Control panel of the Easysleep White Noise Machine.

Power On/Off

Press the power button (marked with a circle and vertical line) to turn the device on or off.

Sound Selection

The machine offers 25 non-looping sounds including white noise, fans, brook, sea waves, birds, bonfire, train, piano, lullabies, and meditation. Use the forward (▶▶) and backward (◀◀) track buttons to cycle through the available sounds.

25 Soothing Sounds



Image: Visual representation of the 25 soothing sounds.

Volume Adjustment

Adjust the volume using the '+' and '-' buttons. There are 32 levels of volume to suit your preference.

Sleep Timer

The device features a sleep timer with options for 60, 120, 180, or 240 minutes (1, 2, 3, or 4 hours). It can also be set for continuous play (indicated by an infinity symbol). Press the timer button to select your desired duration. The device will automatically turn off after the set time.



Image: Sleep timer function with multiple duration options.

Night Light

The integrated night light has four levels of warm light. Press the light button (marked with a lightbulb icon) to cycle through the brightness levels or turn the light off.



Image: Night light feature providing a soft glow.

Memory Function

The memory function automatically restores your previous volume, sound, and timer settings when the device is turned on again.

MAINTENANCE

To clean the device, wipe it with a soft, dry cloth. Do not use liquid cleaners, aerosols, or abrasive materials, as these may damage the surface or internal components. Ensure the device is unplugged from the power source before cleaning.

TROUBLESHOOTING

No Sound/Power

- Check if the device is properly connected to a power source (AC adapter or USB).
- Ensure the power button is pressed to turn the device on.
- Verify the volume is not set to the lowest level.

Light Not Working

- Press the light button to cycle through brightness levels.
- Ensure the device is powered on.

SPECIFICATIONS

Feature	Detail
Product Dimensions	4.14 x 4.14 x 2.38 inches; 6.72 ounces
Model Number	i-1
Manufacturer	Easysleep
Power Source	Corded Electric (AC or USB)
Sounds	25 Non-Looping
Volume Levels	32
Timer Options	Continuous, 60, 120, 180, 240 minutes
Night Light	Four levels of warm light
Material	Acrylonitrile Butadiene Styrene (ABS), Metal, Polycarbonate, Polypropylene, Silicone

WARRANTY AND SUPPORT

The Easysleep White Noise Machine comes with an 18-month warranty from the date of purchase.

For any questions, technical assistance, or warranty claims, please contact Easysleep customer service.

Refer to the product packaging or the official Easysleep website for contact details.

This machine is approved by ETL, FCC, CE, and RoHS standards, ensuring compliance with safety and quality regulations.