

HOMCOM 800-136GN

HOMCOM Portable Skincare Fridge with LED Display

MODEL: 800-136GN

Introduction

Thank you for choosing the HOMCOM Portable Skincare Fridge. This 12-liter mini fridge is specifically designed to maintain the freshness and efficacy of your beauty, makeup, and cosmetic products. Its compact size and versatile storage make it ideal for various settings, including bedrooms, home offices, and desktops. The unit features an intuitive LED display for temperature and operating hours, along with three distinct operating modes to suit your needs.

For optimal performance and longevity of your appliance, please read this manual thoroughly before use and retain it for future reference.

Safety Information

- Ensure the power cord is not damaged and is properly connected to a suitable power outlet.
- Do not block the ventilation openings on the appliance. Adequate airflow is essential for proper function and to prevent overheating.
- Keep the appliance away from direct sunlight, heat sources, and moisture.
- Do not immerse the appliance in water or other liquids.
- Unplug the fridge before cleaning or if it will not be used for an extended period.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Package Contents

Please check that all components are present and in good condition:

- 1 x HOMCOM Portable Skincare Fridge (Model 800-136GN)
- 1 x Power Cord (Type B - 3 pin North American)
- Handles (pre-installed or to be attached)

- Removable shelves and door racks

Setup

1. **Unpacking:** Carefully remove the fridge from its packaging. Inspect for any damage during transit.
2. **Placement:** Place the fridge on a flat, stable surface. Ensure there is at least 10 cm (4 inches) of space around all sides for proper ventilation. Avoid placing it near heat sources or in direct sunlight.
3. **Interior Organization:** Install the removable shelves and door racks as desired to customize your storage space.
4. **Power Connection:** Connect the power cord to the fridge and then plug it into a standard 240V AC power outlet.
5. **Initial Cooling:** Allow the fridge to sit for at least 30 minutes before plugging it in to allow refrigerants to settle. Once plugged in, allow it to cool for approximately 1-2 hours before placing items inside.



Image: The HOMCOM Portable Skincare Fridge in green, positioned on a desk with various cosmetic bottles nearby. This illustrates a typical setup environment.

Operating Instructions

The HOMCOM Skincare Fridge features an LED display and multiple operating modes for precise control.

Power On/Off

- Press the power button on the control panel to turn the fridge on or off.

LED Display and Temperature Control

- The LED screen displays the current operating hours and temperature.
- Use the dedicated buttons on the control panel to switch between Fahrenheit (°F) and Celsius (°C) for temperature readings.
- The fridge maintains an intelligent constant temperature, typically around 50°F (10°C), which is ideal for skincare products.



Image: The skincare fridge with its door open, highlighting the digital display, LED interior lighting, and convenient handle. This shows the user interface and internal features.

Operating Modes

The fridge offers three modes for optimized performance:

- **Intelligent Constant Temperature Mode:** Maintains a stable temperature suitable for cosmetics.
- **Night Mute Mode:** Reduces operational noise for undisturbed sleep.
- **Energy Saving Mode:** Optimizes power consumption for efficiency.

Refer to the control panel icons for mode selection. The thermoelectric cooling method ensures efficient and quiet operation.



Image: A close-up of the fridge's exterior, detailing the control panel with icons for Intelligent Constant Temperature, Night Mute Mode, and Energy Saving Mode, along with indicators for low noise and cooling/warming functions.

Storage and Capacity

The 12L capacity provides ample space for various beauty products. The interior is designed with:

- 3 Shelves for organized storage.
- 5 Door Racks for smaller items.
- 1 Drawer for additional storage.
- 15 Silicone Holders on the door for securing items like lipsticks or brushes.

VERSATILE STORAGE



Image: The interior of the skincare fridge, showcasing its versatile storage options including three shelves, five door racks, and a bottom drawer, designed to accommodate various beauty products.



Image: A detailed view of the silicone holders located on the inside of the fridge door, designed to securely hold small items like lipsticks or serums.



Image: A close-up of the pull-out drawer inside the fridge, featuring the HOMCOM logo, providing additional enclosed storage space.

Maintenance

Cleaning

- Always unplug the fridge before cleaning.
- Wipe the exterior with a soft, damp cloth. For stubborn stains, use a mild detergent.
- Clean the interior with a soft cloth dampened with a mild soap solution. Rinse with a clean, damp cloth and dry thoroughly.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the surfaces.

Defrosting

- This appliance features a manual defrost system.
- If ice buildup occurs, unplug the unit and allow the ice to melt naturally.
- Wipe away melted water with a clean cloth. Do not use sharp objects to remove ice.

Troubleshooting

Problem	Possible Cause	Solution
Fridge not cooling	Power cord unplugged; Power outage; Ventilation blocked.	Check power connection; Verify power supply; Ensure adequate space around the unit.
Excessive noise	Unit not level; Fan obstruction; Normal operating sounds.	Ensure fridge is on a flat, stable surface; Check for obstructions near the fan; Some noise is normal for thermoelectric units. Consider Night Mute Mode.
LED display not working	Power issue; Display malfunction.	Check power connection; If power is on but display is off, contact customer support.
Temperature inconsistent	Door not closed properly; Too many items; Ambient temperature too high.	Ensure door is sealed; Do not overfill; Place in a cooler environment.

Specifications

Feature	Detail
Model Number	800-136GN
Product Dimensions (D x W x H)	10.75" x 10.75" x 17.5" (27.3 cm x 27.3 cm x 44.5 cm)
Capacity	12 Liters
Color	Green
Cooling Method	Thermoelectric
Number of Shelves	3
Number of Door Racks	5
Adjustable Temperature Control	Yes (via modes and display)
Item Weight	11 Pounds (5 kg)
Power Source	Corded Electric
Voltage	240 Volts (AC)
Defrost System	Manual
Material	Plastic



Image: A diagram showing the external dimensions of the HOMCOM Skincare Fridge: 10.75 inches deep, 10.75 inches wide, and 17.5 inches high.

Warranty

This HOMCOM Portable Skincare Fridge (Model 800-136GN) comes with a **1 Year Warranty Against Manufacturer Defects** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

Support

For further assistance, technical support, or warranty inquiries, please contact HOMCOM customer service. Refer to the contact information provided with your purchase or visit the official HOMCOM website

for support details.

Manufacturer: Aosom LLC