

OTOFIX OTOWATCHBV

OTOFIX Smart Watch with VCI (Black) User Manual

INTRODUCTION

The OTOFIX Smart Watch with VCI integrates the functionalities of a vehicle smart key with those of a modern smartwatch. This device allows for convenient vehicle control and personal health monitoring. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal use of your OTOFIX Smart Watch.

Key features include:

- Wearable smart key functionality for vehicle access and remote start.
- Compatibility with most vehicles equipped with smart keys or FOBs (requires VCI programming).
- Call and text notifications when paired with an iOS or Android smartphone.
- Comprehensive health monitoring, including sleep, heart rate, and pulse oxygen.
- Multiple exercise and sports applications (running, walking, hiking, yoga, cycling).
- Voice control for vehicle functions.

WHAT'S IN THE BOX

Upon unboxing your OTOFIX Smart Watch, verify that all components are present:

- OTOFIX Smart Watch
- Bluetooth VCI (Vehicle Communication Interface)



Image: The OTOFIX Smart Watch (black, square face) displayed next to the OTOFIX VCI module (black with orange label).

SETUP

1. **Charge the Smart Watch:** Before initial use, fully charge your OTOFIX Smart Watch using the provided charging cable.
2. **Install Autel Link App:** Download and install the "Autel Link" application on your iOS or Android smartphone. This app is essential for pairing the watch, tracking health data, and managing smart key functions.
3. **Pair with Smartphone:** Follow the on-screen instructions on the watch and within the Autel Link app to pair your OTOFIX Smart Watch with your smartphone via Bluetooth. This enables call/text notifications and data synchronization.
4. **VCI Programming for Smart Key Functions:**
 - The VCI module is required to program the Smart Watch to your vehicle for smart key functionalities.
 - Connect the VCI to your vehicle's OBD-II port.
 - Follow the specific programming instructions provided within the Autel Link app or consult a qualified automotive locksmith for vehicle-specific programming. *Note: Vehicle compatibility varies. Ensure your vehicle is supported before attempting programming.*

OPERATING INSTRUCTIONS

Smart Key Functions

Once the Smart Watch is successfully programmed to your vehicle via the VCI, you can perform the following functions directly from your watch:

- **Lock Doors:** Tap the lock icon on the watch screen.
- **Unlock Doors:** Tap the unlock icon on the watch screen.
- **Remote Start:** Tap the remote start icon on the watch screen.

Important: The Smart Watch can only perform vehicle functions that are supported by your vehicle's original smart key or FOB. If your vehicle does not have a remote start feature, the watch cannot enable it.

Smart Watch Functions

The OTOFIX Smart Watch offers a range of personal monitoring and communication features:

- **Call and Text Notifications:** When paired with your smartphone, receive incoming call alerts and text message notifications directly on your watch.
- **Exercise and Sports Apps:** Access various pre-installed applications for tracking activities such as running, walking, hiking, yoga, and cycling. Data is synchronized with the Autel Link app.
- **Health Monitoring:** The watch continuously monitors key health metrics.



Image: The back of the OTOFIX Smart Watch, showing the optical heart rate sensors emitting green light.

- **Heart Rate:** Monitors your heart rate throughout the day.
- **Pulse Oxygen:** Measures blood oxygen saturation levels.
- **Sleep Tracking:** Analyzes your sleep patterns and quality.
- **Stand Reminders:** Prompts you to stand and move after periods of inactivity.

- **Breathe Exercises:** Guides you through breathing exercises for relaxation.

Voice Control

Utilize voice commands to control certain vehicle functions. For example, you can tell the watch to "Remotely Start Car," "Lock Doors," "Unlock Doors," or "Open Trunk." Ensure your watch is properly connected to your vehicle and smartphone for this feature to function.

MAINTENANCE

- **Cleaning:** Regularly clean your Smart Watch and VCI with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Charging:** Charge the Smart Watch regularly to maintain battery health. Avoid extreme temperatures during charging.
- **Software Updates:** Periodically check the Autel Link app for firmware updates for both the Smart Watch and VCI to ensure optimal performance and access to new features.
- **Storage:** When not in use for extended periods, store the Smart Watch and VCI in a cool, dry place.

TROUBLESHOOTING

Smart Key functions not working:

- Ensure the VCI is correctly plugged into the vehicle's OBD-II port and powered on.
- Verify that the Smart Watch has been successfully programmed to your specific vehicle model. Compatibility issues may arise if the vehicle is not supported or programming was incomplete.
- Check the connection between the Smart Watch and the VCI via the Autel Link app.
- Confirm that the desired vehicle function (e.g., remote start) is supported by your vehicle's original smart key system.

Watch not pairing with phone:

- Ensure Bluetooth is enabled on your smartphone and the watch.
- Restart both the watch and your smartphone.
- Try re-pairing through the Autel Link app.

Inaccurate health data:

- Ensure the watch is worn snugly on your wrist, with the sensors making good contact with your skin.
- Clean the sensors on the back of the watch regularly.
- Environmental factors or excessive movement can sometimes affect sensor accuracy.

SPECIFICATIONS

| Feature | Detail |
|-------------------|-----------------------------|
| Brand | OTOFIX |
| Model Name | OTOFIX Smart Watch with VCI |
| Item Model Number | OTOWATCHBV |

| | |
|-------------------------|----------------------------------|
| Screen Size | 45 Millimeters |
| Operating System | Android, iOS |
| Connectivity Technology | Bluetooth |
| Special Feature | Heart Rate Monitor |
| Item Weight | 2.39 ounces |
| Product Dimensions | 11.51 x 3.5 x 2 inches |
| Batteries | 1 Lithium Ion battery (included) |
| GPS | No GPS |

WARRANTY AND SUPPORT

The OTOFIX Smart Watch with VCI is covered by a one-year limited warranty. For technical assistance, troubleshooting, or warranty claims, please contact OTOFIX customer support. Free technical support is available.

Extended protection plans are also available for purchase:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly billing)

PRODUCT OVERVIEW VIDEO

For a visual introduction to the OTOFIX Smart Watch and its features, please watch the official product video below.

Your browser does not support the video tag.

Video: An official OTOFIX video introducing the Smart Watch, demonstrating its smart key and health monitoring capabilities.

Duration: 13 seconds.