

BILITOK TOK-989

BILITOK Zero Gravity Full Body Massage Chair Recliner (Model TOK-989) User Manual

Comprehensive instructions for setup, operation, maintenance, and troubleshooting.

1. INTRODUCTION

Thank you for choosing the BILITOK Zero Gravity Full Body Massage Chair Recliner, Model TOK-989. This manual provides essential information for the safe and effective use of your massage chair. Please read it thoroughly before operation and retain it for future reference.

2. SAFETY INFORMATION

To ensure safe operation, always follow these basic precautions:

- Read all instructions before using the massage chair.
- Do not use the chair if you have any medical conditions that may be aggravated by massage. Consult a physician if unsure.
- Keep children and pets away from the chair during operation.
- Ensure the power cord is not damaged and is properly connected to a grounded outlet.
- Do not operate the chair in a wet or damp environment.
- Unplug the chair from the power outlet when not in use or before cleaning.
- Recommended for users weighing less than 300 lbs and under 6.1 feet tall for optimal Zero Gravity function.

3. PACKAGE CONTENTS & SETUP

The massage chair is delivered in two boxes. Assembly is required. Follow the included assembly instructions carefully.

Minimum Doorway Size: Ensure your doorway is at least 35 inches wide for transport.



Figure 3.1: Minimum doorway size for chair delivery (35 inches).

The internal structure is designed for quick and simple assembly. Refer to the separate assembly instructions for detailed steps.

4. OPERATING INSTRUCTIONS

4.1 Smart Touchscreen Control

The intuitive smart touchscreen allows for effortless control of your massage experience. Easily switch between massage modes and adjust settings.

ZERO GRAVITY DESIGN

It will remain hovering after the massage



Figure 4.1: Smart Touchscreen for controlling massage functions.

The touchscreen provides access to various functions including auto modes, manual adjustments, heat, and airbag controls.

4.2 Zero Gravity Function

Experience a weightless sensation by pressing the "Zero Gravity" button. The chair reclines to elevate your feet above your heart, reducing spinal pressure and improving blood circulation.

EASY SMART CONTROL

- Suitable for different operating environments
- Easy-care and high-end leather



Figure 4.2: Zero Gravity Design with Initial, Comfort, and Deep Zero Gravity positions.

The chair offers multiple Zero Gravity positions for personalized comfort.

Your browser does not support the video tag.

Video 4.1: Demonstration of the Zero Gravity recline function on the massage chair.

4.3 Full Body Massage & Rollers

The chair features 8 fixed rollers targeting the neck, back, and waist. Choose from 5 preset automatic modes for a customized massage experience.

8 MASSAGE ROLLERS

Providing a massage customized just for you and release full body fatigue



Figure 4.3: Location of 8 massage rollers for full body coverage.

The rollers provide a deep and soothing massage along the spine and other key areas.

4.4 Air Compression Massage

Multiple airbags located in the shoulders, arms, and legs deliver a comprehensive air compression massage, promoting relaxation and circulation.



Figure 4.4: Full body airbags for effective fatigue relief and various massage needs.

4.5 Heat Therapy

Built-in heating functions in the waist and leg areas activate within 3 minutes, promoting blood circulation and relieving muscle soreness.

4.6 Foot Roller Massage & Extendable Leg Rest

The foot roller massage function provides deep, soothing relief for your feet. The retractable footrest accommodates users of different heights, extending up to 5 inches.



Figure 4.5: Foot roller massage and leg retraction feature.

4.7 Bluetooth Audio Player

Connect your device via Bluetooth to enjoy your favorite music while relaxing in the massage chair.

2-IN-1 PHONE HOLDER

- Release hands to enjoy massage
- Large screen touch control



360° rotation



Stable and durable



Wireless bluetooth

Figure 4.6: Integrated Bluetooth audio player for enhanced relaxation.

Your browser does not support the video tag.

Video 4.1: Overview of the massage chair's features, including Zero Gravity and Bluetooth.

Your browser does not support the video tag.

Video 4.2: Detailed demonstration of the Zero Gravity massage chair's functions and features.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your massage chair.

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically check the power cord and connections for any damage.

6. TROUBLESHOOTING

If you encounter any issues, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Chair does not power on.	Power cord unplugged or outlet issue.	Ensure power cord is securely plugged in. Check the power outlet with another device.
Massage rollers are not moving.	Mode not selected or temporary malfunction.	Select an auto mode or manual massage. Power cycle the chair (unplug, wait 30 seconds, plug back in).
No heat from heating function.	Heat function not activated.	Activate the heating function via the touchscreen. Allow a few minutes for the heat to build up.

For further assistance, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	BILITOK
Model Name	TOK-989
Color	White
Product Dimensions	39.41"D x 28.8"W x 53.21"H
Item Weight	125.4 pounds
Material	Faux Leather
Maximum Weight Recommendation	300 Pounds
Special Feature	Automatic, Zero Gravity, Heat Therapy, Air Compression, Foot Roller, Bluetooth Speaker, Touch Screen

8. WARRANTY AND SUPPORT

This product typically comes with a manufacturer's warranty. Please refer to your purchase documentation for specific warranty terms and conditions.

For customer support, technical assistance, or warranty claims, please contact the seller or manufacturer directly.

Return Policy: 30-day easy returns (refer to seller for details).

Protection Plans: Optional 3-Year Protection Plan or Complete Protect monthly plan may be available for purchase (check retailer for current offers).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question