

## RAVAK NOHYLAGUNA

# RAVAK Laguna Universal Bathtub Feet (NOHYLAGUNA) Installation Manual

Model: NOHYLAGUNA

[Introduction](#)   [Safety Information](#)   [Package Contents](#)   [Setup & Installation](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

Thank you for choosing RAVAK Laguna Universal Bathtub Feet (NOHYLAGUNA). This manual provides essential instructions for the safe and correct installation, adjustment, and maintenance of your bathtub support system. Please read this manual thoroughly before beginning installation and retain it for future reference.

## 2. SAFETY INFORMATION

Always observe the following safety precautions:

- Ensure all components are present and undamaged before installation.
- Installation should be performed by a qualified professional or a person with adequate technical knowledge.
- Wear appropriate personal protective equipment (e.g., gloves, safety glasses) during installation.
- Do not overtighten screws or fasteners, as this may damage the bathtub or the feet.
- Verify the stability of the bathtub after installation and before use.
- Keep children and pets away from the installation area.

## 3. PACKAGE CONTENTS

The RAVAK Laguna Universal Bathtub Feet package typically includes:

- Adjustable bathtub feet (quantity as per bathtub model requirement)
- Mounting hardware (screws, washers, etc.)
- Installation instructions (this manual)

*Note: Specific components may vary slightly depending on the bathtub model and region.*

## 4. SETUP & INSTALLATION

---

These feet are designed for RAVAK Laguna bathtubs. Ensure your bathtub is compatible before proceeding.

### 4.1 Attaching the Feet to the Bathtub

1. Carefully turn the bathtub upside down on a soft, protective surface to prevent scratches.
2. Locate the designated mounting points on the underside of the bathtub. These are typically reinforced areas.
3. Position each foot assembly onto its respective mounting point. Ensure the foot is oriented correctly.
4. Secure the feet using the provided screws and hardware. Tighten firmly but do not overtighten.



Figure 1: Illustration of how the adjustable feet attach to the underside of the RAVAK Laguna bathtub.

### 4.2 Adjusting the Height

The RAVAK Laguna Universal Bathtub Feet are adjustable from 80mm to 195mm, allowing for precise leveling and desired height.

1. Once all feet are attached, carefully turn the bathtub upright and place it in its intended position.
2. Use a spirit level to check the bathtub's levelness in all directions.
3. Adjust the height of each foot by rotating the threaded mechanism. Turn clockwise to lower and counter-clockwise to raise.
4. Continue adjusting until the bathtub is perfectly level and stable. Ensure all feet are making firm contact with the floor.



Figure 2: Demonstrating the height adjustment mechanism of the RAVAK Laguna bathtub feet.

### 4.3 Wall Mounting (Optional, if applicable)

For enhanced stability, some RAVAK Laguna bathtubs may utilize wall mounting hooks. Refer to your specific bathtub's manual for details on integrating these with the feet installation.

- If wall hooks are used, ensure they are securely fastened to a structurally sound wall.
- Align the bathtub with the wall hooks before final leveling adjustments.

## 5. MAINTENANCE

---

Regular maintenance ensures the longevity and stability of your bathtub feet.

- **Cleaning:** Clean the feet with a soft cloth and mild, non-abrasive cleaning agents. Avoid harsh chemicals that could damage the material.
- **Inspection:** Periodically check the feet for any signs of wear, corrosion, or damage. Ensure all mounting screws remain tight.
- **Stability Check:** Occasionally verify the bathtub's stability and levelness. Re-adjust the feet if necessary.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Bathtub is unstable or wobbly.	Feet are not evenly adjusted or not all feet are touching the floor.	Re-adjust the height of each foot until the bathtub is level and stable. Ensure all feet bear weight.
Bathtub is not level.	Incorrect height adjustment.	Use a spirit level to identify uneven areas and adjust individual feet accordingly.
Feet appear damaged or corroded.	Exposure to harsh chemicals or physical impact.	Replace damaged feet immediately to ensure structural integrity. Contact RAVAK support for replacement parts.

## 7. SPECIFICATIONS

- **Brand:** RAVAK
- **Model:** NOHYLAGUNA
- **Product Type:** Universal Bathtub Feet
- **Adjustable Height Range:** 80mm - 195mm
- **Compatibility:** Designed for RAVAK Laguna bathtubs
- **ASIN:** B0BPH1MFJR

## 8. WARRANTY & SUPPORT

For warranty information, technical support, or to order replacement parts, please contact RAVAK customer service or visit the official RAVAK website. Keep your proof of purchase for warranty claims.

*Note: Specific warranty terms and conditions may vary by region.*

