

Conair WW545Z

Conair WW545Z Digital Bathroom Scale User Manual

Model: WW545Z

[Overview](#) [Setup](#) [Operation](#) [Safety Information](#) [Product](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. SAFETY INFORMATION

Please read all instructions before using your scale. Keep this manual for future reference.

- The scale platform is made of tempered safety glass. Handle with care. Avoid dropping or striking the scale, as this may cause damage or injury.
- Always place the scale on a hard, flat surface for accurate readings. Using it on carpet or uneven floors may affect accuracy.
- Do not use the scale on wet or slippery surfaces. Ensure the scale and your feet are dry before stepping on to prevent slipping.
- This scale is designed for personal body weight measurement only. Do not use for commercial purposes.
- The maximum weight capacity for this scale is 400 lbs (182 kg). Do not exceed this limit.
- Keep the scale away from extreme temperatures and direct sunlight.
- Do not attempt to disassemble or repair the scale yourself. This will void the warranty.

2. PRODUCT OVERVIEW

The Conair WW545Z Digital Bathroom Scale is designed to provide accurate and consistent weight measurements. It features a stylish white marble tempered safety glass platform and an easy-to-read hidden LED display.

Key Features:

- **Durable Construction:** Sturdy, impact-resistant design with a tempered safety glass platform.

- **High Capacity:** Measures body weight up to 400 lb. (182 kg).
- **Clear Display:** Jumbo 2-inch (50mm) white LED readout for easy visibility.
- **Precision:** Displays weight in 0.1 lb. (0.05 kg) increments.
- **Instant-On:** Simply step on the platform to activate the scale and get a reading.
- **Power:** Operates on 3 AAA batteries (included).



This image shows the Conair WW545Z digital bathroom scale in use, with a person's feet positioned on the white marble platform and the digital display showing a weight measurement of 129.3 lbs.

HIDDEN DISPLAY GLASS SCALE

white marble finish
glass scale

easy to read
jumbo 2" white LED
hidden display

**White
LED**


high-visibility
white LED display



tempered
safety glass

400 LB

weighs up
to 400 lb.



This infographic illustrates the main features of the scale, such as its hidden 2-inch white LED display, the durable white marble tempered safety glass, and its maximum weight capacity of 400 pounds.

3. SETUP

Battery Installation:

1. Locate the battery compartment on the underside of the scale.
2. Open the battery compartment cover.
3. Insert the 3 AAA batteries (included) into the compartment, ensuring correct polarity (+ and -).
4. Close the battery compartment cover securely.

Placement:

For accurate readings, place your scale on a hard, flat, and stable surface. Avoid placing it on carpets, rugs, or uneven flooring, as this can affect measurement accuracy.



The image displays the Conair WW545Z digital bathroom scale positioned on a tiled floor in a contemporary bathroom, showcasing its aesthetic integration into a home environment.

4. OPERATING INSTRUCTIONS

Taking a Weight Measurement:

1. Ensure the scale is on a hard, flat surface.
2. Gently step onto the scale platform with bare feet. The scale will automatically turn on.
3. Stand still and centered on the scale. The display will show your weight measurement.
4. Step off the scale. The display will hold your weight for a few seconds and then turn off automatically.

For consistent results, weigh yourself at the same time each day, preferably in the morning before breakfast and after using the restroom.

5. MAINTENANCE

Cleaning:

- Clean the scale with a damp cloth and mild detergent. Do not use abrasive cleaners or immerse the

scale in water.

- Wipe dry immediately after cleaning.

Battery Replacement:


If the display becomes dim or shows an error message related to low battery, replace all 3 AAA batteries with new ones. Refer to the 'Battery Installation' section for instructions.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No display / Scale does not turn on	Batteries are dead or incorrectly installed.	Check battery polarity. Replace with new AAA batteries.
Inaccurate or inconsistent readings	Scale is on an uneven surface; scale needs recalibration; user movement.	Place scale on a hard, flat floor. Step off the scale, wait for it to turn off, then step back on to recalibrate. Stand still and centered during measurement.
"Lo" or low battery indicator	Batteries are low.	Replace all 3 AAA batteries.
"Err" or overload indicator	Weight exceeds maximum capacity.	The scale's maximum capacity is 400 lbs (182 kg). Do not exceed this limit.

7. SPECIFICATIONS

Feature	Detail
Model Number	WW545Z
Product Dimensions	11.8 x 11.8 x 0.9 inches (300 x 300 x 24 mm)
Item Weight	3.8 pounds
Weight Capacity	Up to 400 pounds (182 kg)
Readout Accuracy	0.1 lb (50 g)
Display Type	Jumbo 2-inch (50mm) White LED
Power Source	3 x AAA batteries (included)
Material	Tempered Safety Glass
Color	White Marble Finish



This diagram provides precise measurements of the scale, indicating its length and width of 11.8 inches each, and a height of 0.9 inches (24 mm).

8. WARRANTY & SUPPORT

Limited 10-Year Warranty:

This Conair WW545Z Digital Bathroom Scale is covered by a Limited 10-Year Warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accidents, unauthorized repairs, or normal wear and tear.

For warranty service or support, please contact Conair Customer Service. Keep your proof of purchase for warranty claims.

Customer Support:

For further assistance, product information, or to inquire about replacement parts, please visit the official Conair website or contact their customer service department. Contact information can typically be found on the manufacturer's website or on the product packaging.

