

[Manuals.plus](#) /

> [DAYTEE](#) /

> Daytech WiFi Tuya Intelligent Bracelet Emergency Alarm for Elderly, Model E-05W

DAYTEE E-05W

Daytech WiFi Tuya Intelligent Bracelet Emergency Alarm

Model: E-05W

Brand: DAYTEE

1. PRODUCT OVERVIEW

The Daytech WiFi Tuya Intelligent Bracelet Emergency Alarm (Model E-05W) is designed to provide a reliable emergency alert system for elderly individuals, sick persons, children, and pregnant women. This system ensures that help can be summoned quickly and efficiently when needed, offering peace of mind for both users and their caregivers.

Key features include an easy-to-use emergency call button, low battery alerts, the ability to connect to multiple receivers and pagers, and message sharing capabilities via the Tuya APP. Users can also adjust various settings such as ringtone and volume through the application.



Figure 1: The Daytech emergency alarm bracelet is suitable for various users, including elderly individuals, sick persons, children, and pregnant women, providing a versatile safety solution.

2. SETUP INSTRUCTIONS

2.1 Unboxing and Initial Check

- Carefully unbox all components: emergency bracelet, receiver unit, and user manual.
- Verify that all items are present and undamaged.

2.2 Battery Installation

- The system requires 2 AAA batteries (included).
- Open the battery compartment on the receiver unit.
- Insert the AAA batteries, ensuring correct polarity (+/-).
- Close the battery compartment securely.

2.3 Connecting to WiFi and Tuya App

1. Download the Tuya Smart or Smart Life app from your smartphone's app store (iOS or Android).
2. Register or log in to your Tuya account.
3. Power on the receiver unit.
4. In the Tuya app, follow the on-screen instructions to add a new device. Select the appropriate device type (e.g., 'Security Sensor' or 'Alarm').
5. Ensure your smartphone is connected to a 2.4GHz WiFi network during the pairing process.
6. Once connected, the receiver unit will indicate successful pairing (e.g., a steady blue LED light).



Figure 2: The system allows for signal transmission over 150 meters, ensuring the app receives alerts as long as the receiver is within WiFi range.

2.4 Sharing Device Access

The Tuya app allows you to share device access with multiple family members or friends. This ensures that several individuals receive emergency notifications simultaneously.

- In the Tuya app, navigate to the device settings for your emergency alarm.
- Look for a 'Share Device' or 'Add Member' option.
- Invite other users by entering their Tuya account details.
- Once accepted, they will receive notifications and can manage certain device settings.



Figure 3: The Smart Care Emergency Button application supports shared use of the device with family and friends, allowing multiple caregivers to receive alerts.

3. OPERATING INSTRUCTIONS

3.1 Triggering an Emergency Alert

- To send an emergency alert, simply press the SOS button on the bracelet.

- Upon activation, the receiver unit will emit an audible alarm and a visual LED indicator will flash.
- Simultaneously, a push notification will be sent to all linked smartphones via the Tuya app.



Figure 4: The emergency alert process involves pressing the SOS button, which triggers an audible alarm on the receiver and sends a notification to linked mobile phones.

3.2 Mobile App Notifications

The mobile application ensures that emergency notifications are received regardless of distance, as long as the receiver is connected to WiFi.



Figure 5: Mobile apps are not limited by distance, allowing users to receive alarm notifications anywhere in the world via a 2.4GHz WiFi connection.

3.3 Low Battery Alert

When the bracelet's battery is low, the LED indicator on the bracelet will illuminate, and a notification will be sent to the connected mobile phone via the Tuya app. This ensures you are aware of the need to replace batteries before the device loses power.

3.4 Multifunction Settings via Tuya App

Through the Tuya app, you can customize various functions of the emergency alarm, including:

- **Ringtone:** Select different alert sounds for the receiver.
- **Volume:** Adjust the alarm volume of the receiver.
- **New Device:** Add additional emergency buttons or receivers to your system.
- **Other Functions:** Explore additional settings and customizations available within the app.

4. MAINTENANCE

4.1 Battery Replacement

- When a low battery alert is received, replace the 2 AAA batteries in the receiver unit promptly.
- Ensure to use new, high-quality alkaline AAA batteries for optimal performance and battery life (approximately 12 months).
- Dispose of old batteries according to local regulations.

4.2 Cleaning

- Wipe the device surfaces with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays, as these may damage the device.
- Avoid exposing the device to excessive moisture.

4.3 General Care

- Keep the device away from extreme temperatures and direct sunlight.
- Avoid dropping or subjecting the device to strong impacts.
- Ensure the receiver unit is placed in a central location within WiFi range for optimal signal reception.

5. TROUBLESHOOTING

5.1 No Alarm or Notification

- **Check Battery:** Ensure the receiver unit has fresh batteries and the bracelet is not showing a low battery alert.
- **WiFi Connection:** Verify that the receiver unit is connected to a stable 2.4GHz WiFi network. Check your router and internet connection.
- **App Status:** Ensure the Tuya app is running in the background on your smartphone and notifications are enabled for the app.
- **Device Pairing:** Confirm that the bracelet is correctly paired with the receiver unit and the receiver unit is paired with the Tuya app. Re-pair if necessary.
- **Range:** Ensure the bracelet is within range of the receiver unit (up to 150m).

5.2 Phone Call/SMS Notifications Not Working

Refer to the feature comparison table below. Phone call and SMS notifications are typically premium features and may require a paid subscription or specific service availability.



Figure 6: Comparison of Standard vs. Premium Notification Functions. Note that phone call and SMS notifications are premium features and their availability may vary.

- **Premium Version:** Ensure you have the Premium version or a subscription that includes these features.
- **Service Availability:** The availability of phone and SMS services may vary by country and service provider. Contact your service provider for details.

5.3 App Connectivity Issues

- **Router Settings:** Ensure your WiFi router is configured for 2.4GHz. Some routers combine 2.4GHz and 5GHz bands; try separating them or connecting to the 2.4GHz band directly.
- **App Update:** Make sure your Tuya app is updated to the latest version.
- **Restart Devices:** Try restarting your smartphone, the receiver unit, and your WiFi router.

6. SPECIFICATIONS

Feature	Detail
Brand	DAYTEE
Model Number	E-05W
Product Dimensions (L x W x H)	9 x 3.7 x 9 cm; 140 grams
Color	White 1-1
Power Source	Battery Powered
Battery Type	2 AAA batteries (Alkaline)
Batteries Included	Yes
Battery Life	Approximately 12 months
Control Method	Tactile (Button)
Sound Level	110 Decibels
Mounting Type	Mounting without support
Sensor Technology	Ultrasonic Sensor
Compatible Devices	Smartphone, Tablet
ASIN	B0C27TP29H
Date First Available	September 7, 2023
Spare Parts Availability	Information unavailable

7. WARRANTY INFORMATION

Specific warranty details for the Daytech WiFi Tuya Intelligent Bracelet Emergency Alarm (Model E-05W) are not provided in the product information. Please retain your proof of purchase for any warranty claims. For detailed warranty terms and conditions, it is recommended to contact the manufacturer directly.

Information regarding the availability of spare parts for this product is currently unavailable.

8. CUSTOMER SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact Daytech customer support. Refer to the product packaging or the official Daytech website for the most up-to-date contact information.

For app-related queries, you may also refer to the help section within the Tuya Smart or Smart Life application.