

Adamson A28

Adamson A28 Mechanical Bathroom Scales User Manual

Model: A28

INTRODUCTION

Thank you for choosing the Adamson A28 Mechanical Bathroom Scales. This manual provides essential information for the safe and effective use of your new scales. Please read it thoroughly before use and retain it for future reference.

PRODUCT OVERVIEW

What's in the Box

- 1 x Adamson A28 Analog Scale

Key Features

- **High Capacity:** Measures body weight up to 550 lb.
- **Anti-Skid Surface:** Textured rubber platform for secure footing.
- **Large Display:** High-contrast dashboard with large numbers for easy reading.
- **Mechanical Operation:** No batteries or electronic components required.
- **Durable Construction:** Designed for long-term reliability.



Image: Top view of the Adamson A28 Mechanical Bathroom Scale, showing the large dial and textured black surface.

SETUP

1. **Unpacking:** Carefully remove the scales from their packaging.
2. **Placement:** Place the scales on a hard, flat, and stable surface. Avoid carpets or uneven flooring, as this can affect accuracy.
3. **Initial Calibration:** Before first use, ensure the pointer on the dial is aligned with the zero mark. If it is not, use the small adjustment wheel, usually located near the bottom of the dial, to manually set it to zero.



Image: Illustration showing the three steps for quick calibration: check pointer, adjust wheel, and step on the scale.

OPERATION

1. **Step On:** Gently step onto the center of the scale platform with bare feet. Stand still and distribute your weight evenly.
2. **Read Measurement:** Wait for the pointer to stabilize. Read your weight directly from the dial. The scales measure in pounds (lb) only.
3. **Step Off:** Step off the scales. The pointer will return to zero.

Important Notes for Accurate Readings:

- Always use the scales on a firm, flat surface.
- For consistent results, weigh yourself at the same time each day, preferably in the morning before breakfast and after using the restroom.
- Avoid weighing yourself immediately after exercise or bathing.

- Ensure the pointer is at zero before each use.



Image: A person's feet on the Adamson A28 Mechanical Bathroom Scale, demonstrating its use and large capacity.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the scales with a damp cloth and mild detergent. Do not use abrasive cleaners or immerse the scales in water.
- **Storage:** Store the scales in a dry place at room temperature. Avoid extreme temperatures or high humidity.
- **Avoid Impact:** Do not drop the scales or subject them to heavy impact, as this can damage the internal mechanism.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Inaccurate readings	Scales on uneven surface; pointer not at zero; scales moved between uses.	Place scales on a hard, flat surface. Calibrate to zero before each use. Avoid moving scales frequently.
Pointer does not return to zero	Internal mechanism issue; scales not level.	Ensure scales are on a level surface. If issue persists, contact customer support.
Difficulty reading numbers	Lighting conditions; user's position.	Ensure adequate lighting. Stand directly over the scales to view the dial clearly.

SPECIFICATIONS

- **Model:** A28
- **Brand:** Adamson
- **Maximum Weight Capacity:** 550 lb
- **Display Type:** Mechanical (needle)
- **Product Dimensions:** 14 x 13.2 x 3.3 inches
- **Item Weight:** 6.5 Pounds
- **Special Features:** Anti-slip surface, Accurate readings, Tare wheel

WARRANTY AND SUPPORT

Adamson provides a **20-Year Assurance** for the A28 Mechanical Bathroom Scales, covering manufacturing defects and ensuring long-term reliability.

For customer support, please use the "Contact seller" button on the Amazon product page. Our customer service team aims to respond within 24 hours to assist with any inquiries or issues.

For more information, visit the official [Adamson Store on Amazon](#).

