

[Manuals.plus](#) /

› [Naroote](#) /

› Naroote H8 Wireless Intercom System User Manual

Naroote H8

Naroote H8 Wireless Intercom System User Manual

Model: H8 | Brand: Naroote

INTRODUCTION

The Naroote H8 Wireless Intercom System provides convenient two-way voice communication for various environments such as homes, offices, and medical facilities. This system is designed for ease of use, featuring a built-in rechargeable battery and a long operating range. This manual provides detailed instructions for setting up, operating, and maintaining your intercom system.



Image: A collage illustrating diverse applications for the Naroote H8 intercom system, including home, homestay, villa, workshop, teahouse, and hospital settings, demonstrating its versatility.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- 2 x Naroote H8 2-Way Voice Intercom Units
- 2 x Charging Bases
- 2 x USB Cables
- 1 x User Manual (this document)

PRODUCT OVERVIEW

The Naroote H8 Wireless Intercom System is designed for reliable and clear communication. Key features

include:

- **Two-Way Voice Communication:** Enables clear, private conversations.
- **Long Battery Life:** Equipped with a 3.7V 2000mAh rechargeable lithium battery and intelligent power-saving features.
- **User-Friendly Indicators:** LED lights for intercom and power status.
- **Versatile Modes:** Easily switch between ringtone call and intercom modes.
- **Extended Range:** Up to 1000 meters in open areas, 20-50 meters through walls.



Image: Two Naroote H8 wireless intercom units, showing the speaker, call button, and talk button. These units are designed for portable, two-way communication.



***About 1000 meter far distance
No network required, no
wiring required, turn on to use***



Image: A single Naroote H8 intercom unit placed in its charging base, with text indicating a 1000-meter range and no network or wiring required, emphasizing its ease of use.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Charge Units:** Before first use, fully charge both intercom units.
 - Connect the USB cable to the charging base and a power source (e.g., USB wall adapter, computer USB port).
 - Place an intercom unit into the charging base. Ensure the charging contacts align.
 - The indicator light will show charging status. Charge until the light indicates a full charge.



Image: A close-up view of the Naroot H8 charging base, showing the charging pins where the intercom unit connects for power.

3. **Power On:** Press and hold the power button on each unit until the indicator light illuminates.
4. **Placement:** Position the intercom units in desired locations within their operational range. Consider areas where communication is most needed, such as different rooms, floors, or buildings within the range.

OPERATING INSTRUCTIONS

The Naroot H8 intercom system offers simple operation for effective communication.

1. **Initiating a Call (Intercom Mode):**
 - To speak, press and hold the "TALK" button.
 - Speak clearly into the microphone.
 - Release the "TALK" button to listen for a response.



Image: A close-up of the Naroote H8 intercom unit, highlighting the "TALK" button with "Press to speak" and "Release to stop" labels, indicating its push-to-talk functionality.

2. Receiving a Call:

- When another unit initiates a call, your unit will emit an audible alert.
- To respond, press and hold the "TALK" button on your unit.
- Release the "TALK" button to allow the other party to speak.

3. Doorbell Functionality:

The units can also function as a doorbell system. Specific instructions for switching between intercom and doorbell modes may be found in the quick start guide included with your package, or by referring to the call button functionality.



Image: A close-up of the Naroote H8 intercom unit, showing the speaker grille and the green call button, which can be used for initiating calls or as a doorbell function.

4. Indicator Lights:

Observe the indicator lights for status updates, such as power on/off, charging status, and active communication.

MAINTENANCE

- **Cleaning:** Wipe the units with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the units frequently. Recharge them when the low battery indicator appears.
- **Storage:** If storing the units for an extended period, charge them to approximately 50% and store in a cool, dry place. Recharge every few months to prevent deep discharge.
- **Environmental Conditions:** Avoid exposing the units to extreme temperatures, direct sunlight, or moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No power / Unit does not turn on	Battery is discharged.	Charge the unit using the provided USB cable and charging base. Ensure the charging contacts are clean and properly aligned.
Poor sound quality / Weak signal	Units are out of range or obstructed by too many walls/dense materials.	Move units closer together. Reduce the number of obstacles between units. Ensure no strong interference sources are nearby.
Intercom not responding	Unit is off, battery is low, or not in intercom mode.	Check if both units are powered on and charged. Ensure the "TALK" button is pressed correctly.
Short battery life	Frequent use, aging battery, or improper charging habits.	Ensure units are fully charged before use. Avoid leaving units fully discharged for long periods. Battery performance may degrade over time.

SPECIFICATIONS

Feature	Detail
Model	H8
Material	ABS
Battery	Rechargeable Lithium Battery 3.7V 2000mAh (Built-in)
Connectivity Technology	Wireless
Operating Range (Open Space)	Up to 1000 meters (approx. 3280 feet)
Operating Range (Through Walls)	20 to 50 meters (approx. 65 to 164 feet)
Control Method	Touch (buttons)
Item Weight	0.29 Kilograms (approx. 10.2 ounces) per unit
Dimensions (Package)	8.27 x 5.08 x 1.34 inches

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided by your retailer or the manufacturer, Naroote. Keep your purchase receipt for warranty claims.

For further assistance, you may visit the Naroote official website or contact their customer service department.

