

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [iHome](#) /

> [iHome Digital Step-On Bathroom Scale \(Model 272IHSGL1BL\) User Manual](#)

iHome 272IHSGL1BL

iHome Digital Step-On Bathroom Scale User Manual

Model: 272IHSGL1BL

INTRODUCTION

Thank you for choosing the iHome Digital Step-On Bathroom Scale. This manual provides essential information for the safe and effective use of your new scale. Please read these instructions thoroughly before operation and retain them for future reference.

IMPORTANT SAFETY INFORMATION

- Always place the scale on a hard, flat surface. Avoid carpets or soft surfaces, as this can affect accuracy.
- The scale surface is made of tempered glass. To prevent slipping, ensure the surface is dry before stepping on it.
- Do not jump on the scale or use it for purposes other than weighing.
- Keep the scale away from water and extreme temperatures.
- This scale is designed for personal use and is not intended for medical or commercial purposes.
- Keep batteries out of reach of children.

PACKAGE CONTENTS

- 1 x iHome Digital Step-On Bathroom Scale
- 2 x AAA Batteries (included)
- 1 x User Manual

SETUP

1. Battery Installation

1. Locate the battery compartment on the underside of the scale.
2. Open the battery compartment cover.
3. Insert the two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

Design with Function Digital Scale

iHome

It looks great and easily fits into your **BATHROOM, BEDROOM OR GYM.**



MINIMAL, SIMPLE AND SLIM DESIGN



SAVES SPACE



2.5 cm (1 inch)



SLEEK SURFACE
Easy to clean



ROUND-CORNER DESIGN



CLEAR LCD DISPLAY
Easy to read



Image: Underside of the iHome Digital Scale, highlighting the battery compartment and unit conversion button.

2. Initial Placement

Place the scale on a firm, flat surface. For optimal accuracy, avoid placing it on carpets, rugs, or uneven flooring.

Stable and Strong

STEP ON / STEP OFF
Auto-calibrated platform

iHome

With an industry leading 10"x10" tempered glass scale, this scale is comfortable, strong, and stable to stand on.

1. Place the iHome Scale on a flat & hard floor (not on a carpet)
2. Wait until display reads Zero before stepping on



STRONG



STABLE



Image: Illustration demonstrating correct scale placement on a hard, flat floor and incorrect placement on carpet.

3. Unit Conversion (Pounds/Kilograms)

To switch between pounds (lb) and kilograms (kg), locate the unit conversion button on the underside of the scale, near the battery compartment. Press this button to toggle between the measurement units.

OPERATING INSTRUCTIONS

1. Taking a Measurement

1. Ensure the scale is on a hard, flat surface.
2. Gently step onto the scale with bare feet. The scale will automatically turn on.
3. Stand still on the scale. The display will show your weight.
4. Wait for the reading to stabilize and blink, indicating the measurement is complete and locked.
5. Step off the scale. The display will show your weight for a few seconds before automatically turning off.

Stable and Strong

STEP ON / STEP OFF
Auto-calibrated platform

iHome

With an industry leading 10"x10" tempered glass scale, this scale is comfortable, strong, and stable to stand on.

1. Place the iHome Scale on a flat & hard floor (not on a carpet)
2. Wait until display reads Zero before stepping on



Image: Visual guide for stepping onto the scale and waiting for the '00.0' display before measurement.

2. Auto Shut-Off Feature

The iHome Digital Step-On Bathroom Scale is equipped with an auto shut-off feature to conserve battery life. If no activity is detected for a short period, the scale will automatically turn off.

MAINTENANCE

- **Cleaning:** Wipe the scale surface with a damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals.
- **Storage:** Store the scale in a cool, dry place. Do not place heavy objects on the scale when not in use.
- **Battery Replacement:** If the display shows a low battery indicator or becomes dim, replace both AAA batteries.

TROUBLESHOOTING

Problem	Solution
"Lo" or "Err" displayed	Low battery. Replace the AAA batteries.
Inaccurate readings	Ensure the scale is on a hard, flat, and level surface. Recalibrate by stepping on the scale briefly until "0.0" appears, then step off and wait for it to turn off before re-weighing. Ensure you are standing still and centered on the scale.
No display	Check if batteries are installed correctly. Replace batteries if they are depleted.

SPECIFICATIONS

- **Brand:** iHome
- **Model:** 272IHSGL1BL
- **Color:** Black
- **Material:** Tempered Glass
- **Display Type:** LCD
- **Weight Capacity:** 400 lbs / 180 kg
- **Accuracy:** ± 0.2 lbs
- **Dimensions:** 10.5 x 10.5 x 1 inches
- **Power Source:** 2 x AAA Batteries (included)
- **Special Features:** Auto Shut Off, Step-On Activation, Unit Conversion

High Precision Body Weight Scale

iHome



iHome,

is a leader in the industry with over 60 years of consumer electronics innovation presents the **iHome LCD Digital Step-On Bathroom Scale**



400 lbs / 180 kg Max
weight capacity



Auto Shut Off



Weight results
in pounds or kilogram

Image: iHome Digital Scale showcasing its minimal design, dimensions (10.5 x 10.5 x 1 inches), 5mm tempered glass, and features like durability, slim profile, and lightweight construction.



400 lbs / 180 kg Max
Weight capacity



STEP ON / STEP OFF
Auto-calibrated platform



4 HIGH PRECISION
SENSORS



DELIVERING RESULTS
with a **0.2 lb./0.1kg**
accuracy



Image: Features of the iHome Digital Scale, including 400 lbs / 180 kg maximum weight capacity, clear LCD display, rounded corners, and a sleek surface.

WARRANTY AND SUPPORT

The iHome Digital Step-On Bathroom Scale comes with a **5-Year Warranty**. For warranty claims, technical support, or any inquiries regarding your product, please contact iHome customer service through their official website or the contact information provided with your purchase documentation.

Please retain your proof of purchase for warranty validation.