

## Snailax SL-535

# Snailax SL-535 Heated Foot Rest Instruction Manual

Model: SL-535

Brand: Snailax

## INTRODUCTION

---

The Snailax SL-535 Heated Foot Rest is designed to enhance comfort and support during prolonged sitting. It combines ergonomic design with heating and vibration massage functions to alleviate muscle tension and improve circulation. This manual provides essential information for the proper setup, operation, and maintenance of your foot rest.

## PRODUCT FEATURES

---

- **Ergonomic Support Design:** Features a contoured shape to cradle feet and improve sitting posture, with a dual-layer height adjustment mechanism to reduce muscle tension. The non-slip base ensures stability.
- **Adaptive Heating Technology:** Equipped with three adjustable heat settings to provide gentle warmth. The removable cover allows for year-round use.
- **Massage Innovation:** High-density memory foam molds to foot shape, distributing pressure. A customizable vibration massage module stimulates foot muscles.
- **Effortless Maintenance:** The machine-washable cover simplifies cleaning routines.
- **Universal Compatibility:** Compact height range fits under most desks, suitable for home office chairs, gaming stools, sofas, and other seating.

## PACKAGE CONTENTS

---

## PACKAGE INCLUDED



Foot Rest



Packing Box



User Manual



UL Home Adapter

The package includes the Snailax footrest unit, a packing box for storage or transport, a user manual for instructions, and a UL-certified home power adapter.

- Snailax Heated Foot Rest Unit
- User Manual
- UL Home Power Adapter

## SETUP

1. Place the Snailax footrest under your desk or preferred seating area.
2. Adjust the height to your desired level by using the adjustment mechanism. The footrest features a dual-layer design, allowing you to use both layers for increased height or remove the top layer for a lower profile.
3. Connect the UL Home Power Adapter to the footrest and then to a power outlet.

## ADJUSTABLE DESIGN

2 HEIGHT OPTIONS



The Snailax footrest offers an adjustable design with two height options. This allows users to customize the footrest's elevation to suit their individual needs and desk height, promoting optimal leg positioning.

## OPERATING INSTRUCTIONS

### Control Panel Overview



The control panel features intuitive buttons for power/heat, heat timer, and vibration modes.

### Heating Function

1. Press the power/heat button to turn on the heating function.

2. Cycle through the available heat levels (Low, High) by pressing the button again. The indicator lights will show the selected level.
3. For heating functionality, press the heating button to choose between two levels of warmth (122°F ~ 140°F).

## HEAT UP IN 1 MIN

MAX. TEMPERATURE OF 140 °F  
(WARM ENOUGH)



2 LEVELS  
122°F ~ 140 °F



The footrest provides rapid heating, reaching optimal warmth within one minute. The image shows a user enjoying the warmth, with a visual representation of cold feet (blue) transforming to warm feet (red) at two adjustable heat levels (122°F ~ 140°F).

### Vibration Massage Function

1. Press the vibration mode button to activate the massage.
2. Cycle through the three available vibration modes (M1, M2, M3) by pressing the button again.
3. The vibration massage module is designed to stimulate foot muscles and provide relaxation.



The footrest includes a vibration massage function. This feature helps stimulate foot muscles and nerves, providing a soothing sensation and aiding in relaxation, particularly beneficial for individuals with sedentary lifestyles.

### **Using the Foot Pocket**

For enhanced warmth and comfort, you can tuck your feet inside the plush pocket located on the top of the footrest. The soft fleece lining provides additional insulation.

## COZY COVER KEEP YOUR FEET WARMER IN WINTER



The footrest features a cozy, removable, and machine-washable cover. This cover enhances comfort and allows for easy maintenance. The memory foam core conforms to the feet, providing soft support and warmth.

### MAINTENANCE

The plush cover of the Snailax foot rest is removable and machine-washable. To clean, detach the cover from the main unit and follow the washing instructions on the care label. Ensure the cover is completely dry before reattaching it to the foot rest.

### SPECIFICATIONS

<b>Model Name</b>	535
<b>Brand</b>	Snailax
<b>Product Dimensions</b>	17"L x 12"W x 4"H (43.18 x 30.48 x 10.16 cm)
<b>Color</b>	Dark Grey
<b>Material</b>	Metal, Plastic

Item Model Number	SL-535
-------------------	--------

## TROUBLESHOOTING

---

- **No Power:** Ensure the power adapter is securely connected to both the foot rest and a working electrical outlet. Check if the outlet is functional.
- **No Heat/Vibration:** Verify that the respective function buttons have been pressed and their indicator lights are on. If the issue persists, try unplugging and re-plugging the device.
- **Weak Vibration:** Ensure the foot rest is on a flat, stable surface. Excessive pressure on the foot rest may affect vibration intensity.

## OFFICIAL PRODUCT VIDEO

---

Your browser does not support the video tag.

This official product video from Snailax showcases the key functionalities of the heated foot rest, including its ergonomic design, heating capabilities, and vibration massage modes, as well as its adjustable height and versatile use in different settings.

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Snailax website. Keep your purchase receipt for warranty claims.