

ICARE GQ102

ICARE GQ102 Ozone Odor Eliminator and Air Purifier User Manual

Model: GQ102

1. INTRODUCTION

Thank you for choosing the ICARE GQ102 Ozone Odor Eliminator and Air Purifier. This device is designed to effectively remove strong odors, including those from pet litter, smoke, and formaldehyde, enhancing the air quality in your home. Please read this manual thoroughly before use to ensure safe and optimal operation.

2. IMPORTANT SAFETY INFORMATION

WARNING: This device generates ozone. Ozone is a strong oxidant and can be harmful if inhaled in high concentrations.

- **Do Not Operate in Occupied Spaces:** Ensure no people, pets, or plants are present in the room during ozone generation.
- **Ventilation is Crucial:** After the device completes its operation cycle, ventilate the treated area by opening windows and doors for at least 15-20 minutes before re-entering.
- **Ozone Scent:** The device emits a scent similar to *Houttuynia cordata* during operation. If you are sensitive to this smell, it is recommended to leave the area during ozone operation.
- **Unmanned Operation:** For sensitive individuals or if you dislike the ozone scent, consider operating the device during unmanned hours (e.g., when you are out or at night) and ensure proper ventilation before returning.
- **Keep Out of Reach:** Install the device in a location inaccessible to children and pets.

Ozone naturally decomposes into oxygen molecules within approximately 20 minutes after generation ceases. Following these safety guidelines will ensure a safe and odor-free environment.

3. PRODUCT FEATURES

- **Fast Deodorization:** Active oxygen output of 300mg/h for professional and rapid odor elimination.
- **High Deodorization Rate:** Achieves up to 99.99% deodorization, targeting pet litter, smoke, and

other unpleasant smells.

- **4 Work Modes:** Adjustable settings (P1, P2, P3, P4) to suit various room sizes and odor levels.
- **Filter-Free Operation:** No filter replacements needed, reducing ongoing costs and maintenance.
- **Versatile Application:** Ideal for small spaces such as bedrooms, kitchens, laundry rooms, baby rooms, pet rooms, bathrooms, hotels, and closets.
- **Compact and Lightweight:** Easy to install and move between locations.

4. PACKAGE CONTENTS

- ICARE GQ102 Ozone Odor Eliminator
- Power Adapter
- User Manual
- Installation Tools (screws and transparent sticker)

5. SETUP

1. **Unpacking:** Carefully remove the Ozone Odor Eliminator and all accessories from the packaging. Remove any protective films from the device, especially from the display.
2. **Power Connection:** Plug the power adapter into a standard electrical outlet. Connect the other end to the device.
3. **Placement Options:**
 - **Tabletop Use:** Place the device on a flat, stable surface in the desired area.
 - **Wall Mounting (Screws):** The back of the purifier has a hanging hole. Use the provided screws to securely mount the device on a wall.
 - **Wall Mounting (Adhesive Sticker):** A transparent adhesive sticker is included. Attach it to the back of the purifier and then firmly press the device onto a clean, dry wall surface.



KITCHEN Smoke & Odors

Remove smoke and odors in the kitchen

Image: The ICARE GQ102 Ozone Odor Eliminator plugged into a wall outlet, demonstrating its compact design and readiness for operation.



Image: A visual guide illustrating the various installation methods for the ICARE GQ102, including using the hanging hole or the transparent adhesive sticker for wall placement.

Video: A demonstration of unboxing and setting up the ICARE Ozone Odor Eliminator, including plugging it in and showing the initial display.

6. OPERATING INSTRUCTIONS

The ICARE GQ102 features a simple interface with an On/Off button and a Mode button to select between 4 working modes. The LED display shows the current mode.

1. **Power On/Off:** Press the "On/Off" button to turn the device on or off. The mode indicator will flash when working and stay on when in standby.
2. **Select Mode:** Press the "Mode" button to cycle through the four available operating modes (P1, P2, P3, P4). Each mode is designed for different durations and intervals, suitable for various room sizes and odor intensities.

Operating Modes:

Mode	Ozone Generation Duration	Cycle Interval	Recommended Use
P1	3 minutes	1 hour	Small spaces, light odors (e.g., small bathroom)
P2	5 minutes	2 hours	Medium spaces, moderate odors (e.g., pet area, kitchen)
P3	30 minutes	4 hours	Larger spaces, strong odors (e.g., basement, smoke)
P4	25 minutes	12 hours	Continuous maintenance for persistent odors

Choose the appropriate mode based on the size of your room (5-30 square meters recommended) and the intensity of the odor. Remember to always ensure the area is unoccupied during operation and properly ventilated afterward.

4 Working Modes Easy to Operate

You can choose the mode according to your needs and the size of the room



Image: The ICARE GQ102 device showcasing its LCD digital display and the four distinct working modes, P1 through P4, for user selection.

Video: A brief overview of the ICARE Ozone Odor Eliminator, demonstrating its compact size, power connection, and how to cycle through the different operating modes.

7. MAINTENANCE

- **No Filter Replacement:** The ICARE GQ102 does not require filter replacements, saving you time and money.
- **Cleaning:** To maintain optimal performance, periodically wipe the exterior of the device with a soft, dry cloth. Do not use liquid cleaners or immerse the device in water.
- **Storage:** When not in use for extended periods, unplug the device and store it in a cool, dry place.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device not turning on	No power supply or loose connection	Ensure the power adapter is securely plugged into both the device and a working electrical outlet.
Weak odor elimination	Incorrect mode selected for room size/odor intensity; insufficient operating time; poor ventilation after use.	Select a higher mode (e.g., P3 or P4) for larger rooms or stronger odors. Allow sufficient operating time. Ensure proper ventilation after use.
Strong ozone smell persists	Insufficient ventilation after operation.	Increase ventilation time by opening windows and doors for a longer period (e.g., 30-60 minutes) before re-entering the room.

9. SPECIFICATIONS

Feature	Detail
Model Number	GQ102
Product Dimensions	6.46"D x 4.53"W x 1.18"H (1.18 x 4.53 x 6.46 inches)
Item Weight	16 ounces (1 Pound)
Ozone Output	300mg/h
Power Source	Corded Electric
Color	White
Applicable Area	5-30 square meters

10. WARRANTY AND SUPPORT

ICARE is committed to providing high-quality products. For any questions, concerns, or technical support regarding your GQ102 Ozone Odor Eliminator, please refer to the contact information provided with your purchase or visit the official ICARE website. Please retain your proof of purchase for warranty claims.