#### Manuals+

## Q & A | Deep Search | Upload

#### manuals.plus /

- AULA /
- AULA Wired Gaming Keyboard and S12 Pro Gaming Mouse Combo User Manual

# **AULA AULA Typewriter Style Mechanical Keyboard and S12 Pro Gaming Mouse Combo**

# AULA Wired Gaming Keyboard and S12 Pro Gaming Mouse Combo User Manual

#### 1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your AULA Wired Gaming Keyboard and S12 Pro Gaming Mouse Combo. Please read this guide thoroughly to ensure optimal performance and longevity of your devices.

## 2. PRODUCT OVERVIEW

The AULA Wired Gaming Keyboard and S12 Pro Gaming Mouse Combo offers a unique blend of classic aesthetics and modern gaming functionality. The keyboard features a distinctive typewriter style, while the mouse provides precision and customization for an enhanced gaming experience.

## 2.1 Keyboard Features

- Retro Typewriter Style Round Keycaps: Equipped with mechanical blue switches for a quick, springy response
  and crisp click sound. Double-shot injection molded keycaps ensure clear backlighting and durability. The stepped
  floating keycap design promotes precise positioning and reduces typing fatigue. A keycap puller is included for easy
  cleaning.
- Multimedia and Backlight Control Knob: Dedicated media control keys allow for effortless adjustment of media
  volume, backlight effects, music playback, and switching. The knob supports 19 different lighting effects, adjustable
  brightness, and speed. Three customized backlight profiles can be created. Long press the knob for three seconds
  to switch between media and lighting modes.
- Metal Panel and Magnetic Wrist Rest: The keyboard panel is constructed from top-grade aluminum alloy with a
  matte-finish texture for durability and scratch resistance. An ergonomic ABS palm rest provides firm support to
  alleviate wrist pressure, enhancing comfort during extended use.
- Stylish, Durable, and Wide Compatibility: Modern design with a high-low key layout. Compatible with PC, Mac, Laptop, Tablet, and Desktop computers running Windows 7/8/10/XP/Vista, Linux, and Mac OS systems. Features a USB wired connection for plug-and-play functionality without requiring drivers or software.

## 2.2 Mouse Features

- S12 Pro Wired Gaming Mouse: Offers 6 adjustable DPI levels (1200/1600/2400/4800/7200/12800 DPI) with a 1000Hz return rate.
- RGB Light Effects: Features 13 distinct RGB lighting effects.
- **Programmable Buttons:** Equipped with 8 programmable buttons and supports software macro programming for DIY keybinds and rapid fire functions.

## 3. SETUP INSTRUCTIONS

Setting up your AULA Gaming Keyboard and Mouse Combo is a straightforward process.

- 1. Connect the Keyboard: Plug the USB connector of the keyboard into an available USB port on your computer.
- 2. Connect the Mouse: Plug the USB connector of the mouse into another available USB port on your computer.
- 3. **Automatic Installation:** The devices are plug-and-play. Your operating system should automatically detect and install the necessary drivers. No additional software installation is required for basic functionality.
- 4. Compatibility: The combo is compatible with Windows 7/8/10/XP/Vista, Linux, and Mac OS systems.



Figure 1: AULA Wired Gaming Keyboard and Mouse Combo connected to a computer.

#### 4. OPERATING INSTRUCTIONS

## 4.1 Keyboard Operation

- Basic Typing: Use the typewriter-style keys for standard input. The mechanical blue switches provide tactile feedback
- Multimedia Control: Use the dedicated media control keys (F1-F12, usually accessed with the 'Fn' key) for quick access to volume, play/pause, and track switching.
- Multimedia/Backlight Knob:
  - Short press the knob to control media functions (e.g., volume up/down, mute).
  - Long press the knob for approximately 3 seconds to switch between media control mode and backlight control mode.

#### 4.2 Mouse Operation

- **DPI Adjustment:** Press the DPI button (usually located near the scroll wheel) to cycle through the 6 available DPI settings (1200/1600/2400/4800/7200/12800 DPI).
- Programmable Buttons: Utilize the 8 programmable buttons for custom commands and macros. Refer to the
  optional software for advanced customization.



Figure 2: Overview of customizable mouse button functions.

#### 5. Customization

## 5.1 Keyboard Backlight Customization

- Changing Effects: In backlight control mode (activated by long-pressing the knob), turn the knob to cycle through 19 different lighting effects.
- Adjusting Brightness/Speed: Use the dedicated keys (often Fn + Up/Down arrow for brightness, Fn + Left/Right arrow for speed) to fine-tune the backlight intensity and animation speed.
- Custom Backlight Profiles: The keyboard supports creating 3 customized backlight profiles. Refer to the product's advanced settings or software (if available) for detailed instructions on setting these up.



Figure 3: The keyboard displaying its bright multicolor backlight effects.



Figure 4: The multimedia and backlight control knob, showing its dual functionality.

## 5.2 Mouse RGB Lighting

• The S12 Pro mouse features 13 RGB light effects that cycle automatically. Specific control over individual colors or patterns may require optional software.



Figure 5: The S12 Pro mouse showcasing its RGB backlight effect.

## 6. MAINTENANCE

- **Keycap Cleaning:** Use the included keycap puller to carefully remove keycaps for thorough cleaning. Clean with a soft, damp cloth. Ensure keycaps are completely dry before reattaching.
- **General Cleaning:** Regularly wipe down the keyboard and mouse surfaces with a soft, dry cloth to prevent dust buildup. Avoid using harsh chemicals or abrasive materials.
- Wrist Rest: The magnetic wrist rest can be detached for separate cleaning.



Figure 6: The detachable magnetic wrist rest for ergonomic comfort and easy cleaning.

## 7. TROUBLESHOOTING

- **Device Not Recognized:** Ensure both the keyboard and mouse USB connectors are securely plugged into your computer's USB ports. Try different USB ports.
- Backlight Not Working: Check if the keyboard is properly connected. Ensure the backlight is not turned off or set to the lowest brightness level. Try cycling through the lighting effects using the control knob.
- Mouse DPI Issues: Press the DPI button on the mouse to cycle through the available sensitivity settings.
- **Keys Not Responding:** If individual keys are not responding, try removing and reattaching the keycap to ensure proper seating. Clean any debris around the switch.

## 8. SPECIFICATIONS

Feature	Detail
Brand	AULA
Model	AULA Typewriter Style Mechanical Keyboard and S12 Pro Gaming Mouse Combo
Keyboard Type	Wired Mechanical Keyboard

Key Switches	Mechanical Blue Switch
Keycap Style	Retro Typewriter Style Round Keycaps
Keyboard Backlight	Rainbow Backlight (19 effects, adjustable brightness/speed, 3 custom profiles)
Mouse Model	S12 Pro Wired Gaming Mouse
Mouse DPI	6 adjustable levels (1200/1600/2400/4800/7200/12800 DPI)
Mouse Return Rate	1000Hz
Mouse Buttons	8 Programmable Buttons
Mouse Backlight	13 RGB Light Effects
Connectivity	USB Wired
Compatible Devices	PC, Mac, Laptop, Tablet, Desktop
Operating Systems	Windows 7/8/10/XP/Vista, Linux, Mac OS

#### 9. WARRANTY AND SUPPORT

For warranty information, technical support, or any product-related inquiries, please refer to the official AULA website or contact AULA customer service directly. Keep your purchase receipt for warranty claims.

## Related Documents - AULA Typewriter Style Mechanical Keyboard and S12 Pro Gaming Mouse Combo

AND A COMMENT OF A	User Manual SC100 Wreless Rechargeable Nouse With USB Receiver							
A CONTRACTOR CONTRACTO	North College	22-429						
mencione di sociale di 20  di considerati i supportante di 20  di								
The Control of the Co	OP1 3 Gear 866-	286-1580-Deh	m# 1630s					
The control of the co	PHOUSE PLAN. 200	D4A0-125						
The control of the co	58 x 140 X1 x79	991 (37 04 4 0	5nm					
Commission Special Control Con	Eulore E							
The ACT OF	Pair Method, Fre-	1 Grote						
The man and among the entity provided to entity the second provided to the man and among the control of the man and among the second of the seco	Meterial #85							
The ACT OF			-					
"Van hom pill problem i teine den eine in 'n 'n sommer beeln hindern fan 20 ist Dakel BERLEIN (1996) of "Neuroll 1996."  BERLEIN (1996) of "Neuroll 1996."  De eine den eine				N 1000				
The Committee of the Co					Section State 200	or many		
1 Worker beliefe.  The standard specified in the standard product for mount in consist standard product for mount in consist standard product for mount.  The standard product for standard consistent of standard consistent for mount.  I would be standard to the standard consistent for mount in the standard product for t								
1 Worker beliefe.  The standard specified in the standard product for mount in consist standard product for mount in consist standard product for mount.  The standard product for standard consistent of standard consistent for mount.  I would be standard to the standard consistent for mount in the standard product for t								
The man and among the entity provided to entity the second provided to the man and among the control of the man and among the second of the seco	Description of	Washing Mode						
2. Level 1 Sept sides.  1. Level 1 Sept sides where 1. Level 2 Sept sides 2. Level 1 Sept sides. 1. Level 2 Sept sides 3. Level 2 Sept sides. 1. Level 2 Sept sides 3. Level 2 Sept sides. 1. Level 2 Sept sides 3. Level 2 Sept sides. 1. Level 2 Sept sides 3. Level 2 Sept sides. 1. Level 2 Sept sides 3. Level 2 Sept sides. 1. Level 2 Sept sides 3. Level 2 Sept sides. 1. Level 2 Sept sides 3. Level 2 Sept sides. 1. Level 2 Sept sides 3. Lev								
The most design range for leveral 4 area most.  Low 2 files a state.  The most design range for leveral 4 area most.  Low 5 files a state.  The most design range for leveral 4 area most. It seems not a purpose  4.1 When her before the state or when he medical  4.1 When her range of mark as a low soulder, also 11 seeded that the state of each mark  4.1 When her range of mark as a low soulder, also 11 seeded that the state of each mark  4.1 When he range of mark  1.4 When her range of mark  1.4 When her state of each of ea			hey bis present, th	e mouse islove	arking mode.			
It was 1 does note.  The manuse despression of the result of animal trans 2 dies is store. The results sealer of plat has the control of the results of the								
The makes allow concept in treased, if contributed a less pools, the require select popularies of the less pools, the require select popularies of the less pools and the require of the less popularies of th			econd, if orders bev	# 2 deep made.				
4. Open Sizes Sizes (French Strams the bushes or whealth sending.)  1. 1 View has recovered misser or has to expect, the Ell Frenches of other sizes design of the product of the Confidence of								
4.1 Wen'the review of two or to be greaters, after 15 marks it orbits view prepared at 15 marks it orbits view view prepared at 15 marks it orbits view view prepared at 15 marks it orbits view view view prepared view view prepared view view view view view view view view						or signs swince.		
4.1 When soo class the computer or ungling the receiver, the moves cannot defect the soot after a security and the second and centers classy users made to the soot after a second and centers cannot be second and centers and associated to the second								
atter is according and it enteres clamp strong-model  Minimal Enteres Enteres controlled  (Interes of the State St. American Space (MSS procedurate Ct.)  Pronting Victor State (St. American Space (MSS procedurate Ct.)  Pronting Victor State (St. American Space (MSS procedurate Ct.)  Pronting Victor State (St. American Space (MSS procedurate Ct.)  Pronting Victor State (St. American Space (MSS procedurate Ct.)  Pronting Victor State (MSS procedurate Ct.)								
Washing Faster Communication (Net Surface A4 white paper, 5005 photoelectric IC) (Net Surface A4 white paper, 5005 photoelectric IC) (Nethory/whate) (Nethory/whate) (Nethory/whate) (Nethory/whate) (Nethory/whate)				e rockbot, the r	nouter cannot did	ted the receiv		
(Net Surtace: A4 with paper, 2005 photoelectric IC)  Welling-Veltage: Minding-connect: Level 1 sleep: Level 2 sleep: Deep Since  A4 Street: A4 With Connect Co	ate texons a	DEE OF BUILDING	step rode					
(Net Surtace: A4 with paper, 2005 photoelectric IC)  Welling-Veltage: Minding-connect: Level 1 sleep: Level 2 sleep: Deep Since  A4 Street: A4 With Connect Co	No. of Second							
Welling-Vellage Welling conset Land 1 sleep Land 2 sleep Deep Sleep			S storman to the					
				Land Salam	Level 7 Hours	Osen Stean		
		Africa	7.33n6-6.55n6	\$.15mt	E 1996	1545		
3.7V Core.Court   ElinaGilling   Elina   Elina   15aa		Cors.Lyon	\$ 63mt-6 30mt	6 Clerk	8.1508	154		

## SC100 Wireless Rechargeable Mouse User Manual

User manual for the SC100 Wireless Rechargeable Mouse with USB Receiver, detailing its features, working modes, power consumption, usage guide, troubleshooting, and cleaning instructions.



## AULA WIND SC800 Gaming Mouse: Features, Specifications, and User Guide

Comprehensive guide to the AULA WIND SC800 Gaming Mouse, covering its features, product specifications, connection methods (2.4G, Bluetooth, Wired), DPI settings, charging instructions, and sleep mode. Includes key layout and operational details.



## AULA SC580 Gaming Mouse User Manual and Specifications

Detailed user manual and specifications for the AULA SC580 Gaming Mouse, covering features, connectivity (BT, 2.4G, Wired), charging, and sleep mode. Includes multilingual support.



#### AULA F815 Wired Gaming Mouse User Manual and Specifications

Comprehensive user manual for the AULA F815 wired gaming mouse, detailing installation, DPI switching, illumination effects, button functions, software, and WEEE compliance.



# AULA F3050 Mechanical Keyboard User Guide

Comprehensive guide to the AULA F3050 Mechanical Keyboard, detailing its features, specifications, shortcut keys, and operational modes for gaming and office use.

