

Loop en-ex-blk-03

Loop Experience 2 Ear Plugs User Manual

Stylish Certified Hearing Protection for Concerts & Festivals, Live Events, Musicians, Sports, DJs and Nightlife

INTRODUCTION

Welcome to the user manual for your Loop Experience 2 Ear Plugs. These high-fidelity earplugs are designed to reduce noise levels while maintaining sound clarity, making them ideal for various loud environments. This manual provides essential information on how to set up, operate, maintain, and troubleshoot your earplugs to ensure optimal performance and hearing protection.

PRODUCT OVERVIEW

The Loop Experience 2 Ear Plugs offer a unique blend of style, comfort, and effective noise reduction. They are engineered to provide a crisp, clear listening experience by lowering volume without compromising sound quality.

Key Features:

- **Less Noise, Crisper Sound:** Enjoy moments at your preferred volume. Designed for live events, these earplugs lower volume without compromising sound quality, ensuring a crisp, clear listening experience.
- **Certified Hearing Protection:** Qualify as certified hearing protection, safeguarding your ears from damaging noise. Offers 17 dB (SNR) of filtered noise reduction.
- **Made for Dancing and Moving:** Designed to stay securely in place day and night. Customize your fit with 4 upgraded ear tip sizes for a secure fit, even in smaller ears.
- **Easy to Use:** Simple to insert and adjust for optimal noise reduction and comfort.

What's in the Box:

- 1 set of Loop Experience 2 earplugs
- 4 sets of silicone ear tips (sizes XS + S + M + L)
- 1 portable and convenient keychain Carry Case



Image: A pair of black Loop Experience 2 Ear Plugs, showcasing their distinctive circular design.

SETUP

Proper fit is crucial for optimal noise reduction and comfort. Follow these steps to set up your Loop Experience 2 Ear Plugs:

1. **Choose the Right Ear Tip Size:** Your earplugs come with four different sizes of silicone ear tips (XS, S, M, L). Experiment with each size to find the one that provides a snug yet comfortable fit in your ear canal. The correct size should create a good seal without causing discomfort.
2. **Insert the Earplugs:** Gently insert the earplug into your ear canal.
3. **Twist to Secure:** Once inserted, gently twist the earplug to secure it in place. When inserted

correctly, Loop Experience 2 earplugs should not stick out prominently from the front of your ear.

Find your perfect fit

1. Insert and twist

Loop earplugs should never stick out or be visible from the front.



2. Try all ear tip sizes

Sticking out or uncomfortable?
Try a smaller size.

Don't feel secure?
Go a size up.



Image: Visual guide demonstrating the insertion and twisting motion for a secure fit, and showing that the earplugs should not stick out from the front.

OPERATING YOUR EAR PLUGS

Your Loop Experience 2 Ear Plugs are designed for continuous wear in various loud environments, allowing you to enjoy the experience at a safer volume while maintaining sound quality.

Usage Scenarios:

- **Concerts & Festivals:** Reduce the overall volume of music and crowd noise while preserving the clarity of sound, allowing you to fully enjoy performances without ear fatigue or damage.
- **Live Events & Sports:** Filter out excessive background noise at sporting events, DJ sets, or other live gatherings, ensuring a more comfortable and enjoyable experience.
- **Daily Noise Reduction:** Can be used in any situation where you need to lower ambient noise, such as busy commutes, noisy offices, or crowded public spaces, to enhance focus and reduce

sensory overload.

No official product videos from the seller are available for embedding in this manual.

MAINTENANCE

To ensure the longevity and hygiene of your Loop Experience 2 Ear Plugs, regular cleaning is recommended:

- **Cleaning:** Gently wipe the silicone ear tips and the main body of the earplugs with a soft, damp cloth. For a more thorough clean, you can use mild soap and water. Ensure they are completely dry before storing them.
- **Storage:** Always store your earplugs in the provided keychain Carry Case when not in use. This protects them from dust, dirt, and damage, and prevents them from getting lost.

TROUBLESHOOTING

If you encounter any issues with your Loop Experience 2 Ear Plugs, try the following solutions:

- **Muffled Sound or Insufficient Noise Reduction:**
 - Ensure the earplugs are inserted correctly and twisted to create a proper seal.
 - Try a different size of ear tip. A tip that is too small may not create an adequate seal, while one that is too large may prevent proper insertion.
 - Check if the ear tips or acoustic channels are obstructed by debris. Clean them thoroughly if necessary.
- **Discomfort or Pain:**
 - Ensure you are using the correct ear tip size. If the earplug feels too tight or causes pressure, try a smaller size.
 - Re-insert the earplug gently, ensuring it is not pushed too deep or at an awkward angle.
- **Earplugs Falling Out:**
 - Try a larger ear tip size to achieve a more secure fit.
 - Ensure the earplug is twisted properly to lock into place within the ear's concha.

If problems persist, please refer to the Warranty & Support section for further assistance.

SPECIFICATIONS

Feature	Detail
---------	--------

Product Dimensions	3.07 x 3.07 x 0.75 inches
Item Weight	1.06 ounces
Model Number	en-ex-blk-03
Manufacturer	Loop
Color	Black
Material	Acrylonitrile Butadiene Styrene
Noise Reduction Rating (SNR)	17 dB
Recommended Uses	Hearing Protection (Concerts, Festivals, Live Events, Musicians, Sports, DJs, Nightlife)
Country of Origin	China

SAFETY INFORMATION

Choking Hazard Warning:

Please note, this product contains small parts and may present a choking hazard for children under 3 years of age. Keep out of reach of young children.

WARRANTY & SUPPORT

For detailed warranty information and support, please refer to the official Loop Earplugs website or the User Manual (PDF) provided with your product.

You can access the User Manual (PDF) [here](#).

For additional information or to explore other Loop products, visit the [Loop Store](#).

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.