

[Manuals.plus](#) /

> [Drsaec](#) /

> Drsaec Wireless Earbuds User Manual

Drsaec U-VID

Drsaec Wireless Earbuds User Manual

Model: U-VID

INTRODUCTION

This manual provides detailed instructions for the Drsaec Wireless Earbuds, Model U-VID. These earbuds are designed for high-quality audio experience with Bluetooth 5.3 connectivity, featuring 4 ENC microphones for effective noise cancellation during calls, deep bass for rich sound, and an IP7 waterproof rating. They are suitable for various activities, including exercising and running, and offer broad compatibility with both iOS and Android devices.

PRODUCT OVERVIEW





Figure 1: Drsaec Wireless Earbuds and Charging Case. The image displays the Drsaec Wireless Earbuds, white in color, resting inside their open charging case. The earbuds are positioned upright, revealing their design and the charging pins within the case. A blue light is visible on the front of the charging case, indicating its status.

SETUP

What's in the Box

- Drsaec Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual (this document)

Charging the Earbuds and Case

1. **Initial Charge:** Before first use, fully charge both the earbuds and the charging case.
2. **Charging the Case:** Connect the provided USB-C cable to the charging port on the case and the other end to a

USB power adapter (not included). The indicator light on the case will show charging status.

3. **Charging the Earbuds:** Place the earbuds into their respective slots in the charging case. Ensure they are correctly seated; magnetic contacts will hold them in place. The earbuds will begin charging automatically.
4. **Battery Indicator:** A blue light on the charging case indicates charging or battery status.

Pairing with Your Device

1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. **Activate Bluetooth:** On your mobile device (smartphone, tablet, etc.), go to the Bluetooth settings and turn on Bluetooth.
3. **Select Device:** Look for "Drsaec U-VID" or a similar name in the list of available Bluetooth devices. Select it to connect.
4. **Confirmation:** Once connected, you will hear an audio prompt from the earbuds, and the device's Bluetooth settings will show them as connected.
5. **Automatic Reconnection:** After the initial pairing, the earbuds will automatically connect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

Touch Controls

The Drsaec Wireless Earbuds feature intuitive touch controls on each earbud. The touch-sensitive area is typically located on the outer surface of the earbud stem.

Action	Control
Play/Pause Music	Single tap on either earbud
Next Track	Double tap on the Right earbud
Previous Track	Double tap on the Left earbud
Volume Up	Triple tap on the Right earbud
Volume Down	Triple tap on the Left earbud
Answer/End Call	Single tap on either earbud during an incoming call
Reject Call	Press and hold either earbud for 2 seconds during an incoming call
Activate Voice Assistant	Press and hold either earbud for 3 seconds

Wearing the Earbuds

For optimal sound quality and comfort, ensure the earbuds are properly seated in your ears. The ergonomic design with rounded tips is intended to fit snugly into the ear canal. Gently insert each earbud and twist slightly until you achieve a

secure and comfortable fit. This also helps in maximizing the passive noise isolation.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Clean the charging contacts on both the earbuds and the case to ensure proper charging.
- Do not immerse the charging case in water. While the earbuds are IP7 waterproof, it is best to wipe them clean rather than submerge them.

Storage

- When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- Store the device in a cool, dry place, away from extreme temperatures and direct sunlight.

Water Resistance (IP7 Rating)

The Drsaec Wireless Earbuds are rated IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. This makes them resistant to sweat and rain, ideal for workouts and outdoor activities. However, the charging case is not waterproof. Ensure earbuds are dry before placing them back into the charging case to prevent damage.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing with device.	<p>Ensure Bluetooth is enabled on your device.</p> <p>Make sure the earbuds are fully charged.</p> <p>Place earbuds back in the case, close the lid, wait a few seconds, then open again to re-enter pairing mode.</p> <p>Forget "Drsaec U-VID" from your device's Bluetooth list and try pairing again.</p> <p>Ensure no other devices are currently connected to the earbuds.</p>
No sound from one or both earbuds.	<p>Check the volume level on your device and on the earbuds.</p> <p>Ensure earbuds are properly connected to your device.</p> <p>Re-pair the earbuds with your device.</p> <p>Clean the charging contacts on the earbuds and inside the case.</p>
Earbuds not charging.	<p>Ensure the charging cable is securely connected to both the case and the power source.</p> <p>Verify the power source is working.</p> <p>Clean the charging contacts on both the earbuds and the case.</p> <p>Try a different USB-C cable or power adapter.</p>

Problem	Possible Solution
Poor sound quality or intermittent connection.	<p>Ensure the earbuds are within the Bluetooth range of your device (typically 10 meters/33 feet).</p> <p>Reduce interference by moving away from other wireless devices or strong electromagnetic fields.</p> <p>Check for any physical obstructions between the earbuds and your device.</p> <p>Ensure the earbuds are clean and free of debris.</p>

SPECIFICATIONS

Feature	Detail
Model Name	U-VID
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.3
Noise Control	Active Noise Cancellation (ENC Mics)
Water Resistance Level	IP7 Waterproof
Control Type	Touch Control
Ear Placement	In Ear
Form Factor	In Ear
Compatible Devices	Cellphones, Tablets (iOS/Android)
Frequency Range	20 Hz - 20,000 Hz
Material	Plastic
Item Weight	0.353 ounces
Package Dimensions	1.57 x 1.18 x 0.79 inches
Batteries	1 Lithium Polymer battery required (included)

WARRANTY INFORMATION

Drsaec products are manufactured to high quality standards. For specific warranty details, please refer to the warranty card included with your product or visit the official Drsaec website. Keep your purchase receipt as proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your Drsaec Wireless Earbuds that are not covered in this manual, please contact Drsaec customer support. Contact information can typically be found on the product packaging, the official Drsaec website, or through your point of purchase.