

[manuals.plus](#) /› [ICE-WATCH](#) /

› ICE-WATCH Ice Smart 2.0 Smartwatch User Manual

## ICE-WATCH Ice Smart 2.0 (023962)

# ICE-WATCH Ice Smart 2.0 Smartwatch User Manual

Model: Ice Smart 2.0 (023962)

## 1. INTRODUCTION

Welcome to the user manual for your ICE-WATCH Ice Smart 2.0 Smartwatch. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your device. Please read this manual thoroughly to ensure optimal performance and longevity of your smartwatch.

## 2. PRODUCT OVERVIEW

The ICE-WATCH Ice Smart 2.0 is a connected smartwatch designed to integrate seamlessly into your daily life. It offers a range of features for communication, health monitoring, and activity tracking. The watch is compatible with both iOS (9.0+) and Android (5.0+) devices.



Figure 2.1: Front view of the ICE-WATCH Ice Smart 2.0 Smartwatch displaying various metrics.



Figure 2.2: Angled front view of the smartwatch, highlighting the strap and watch face.



Figure 2.3: Side view of the smartwatch, showing the crown button and strap attachment.

## Key Features:

- Bluetooth Calling and Notifications
- Customizable Watch Faces and Always-On Display
- Pedometer, Stopwatch, Alarm, Games, Weather, Music Control, Camera Control
- Health Monitoring: Sleep, Heart Rate, Blood Oxygen, Blood Pressure, Water Drinking Reminder, Sedentary Reminder
- IP68 Water Resistance
- Up to 5 Days Battery Life

## 3. SETUP

## 3.1 Initial Charging

Before first use, fully charge your smartwatch. Connect the supplied magnetic USB charging cable to the charging points on the back of the watch and to a USB power source. A full charge typically takes approximately 2 hours.

## 3.2 App Installation and Pairing

1. Download the 'ICE Smart' app from your device's app store (Google Play Store for Android or Apple App Store for iOS).
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the 'ICE Smart' app and follow the on-screen instructions to create an account or log in.
4. In the app, navigate to the device pairing section and select your ICE Smart 2.0 from the list of available devices.
5. Confirm the pairing request on both your smartphone and the smartwatch.

# 4. OPERATING INSTRUCTIONS

---

## 4.1 Basic Navigation

- **Touchscreen:** Swipe left, right, up, or down to navigate through menus and features. Tap to select an option.
- **Side Button/Crown:** Press to return to the home screen or wake the device. Rotate (if applicable) to scroll through lists.

## 4.2 Core Functions

- **Bluetooth Calling:** Once paired, you can make and receive calls directly from your watch. Ensure the Bluetooth connection is stable.
- **Notifications:** View incoming calls, messages, and app alerts on your watch. Manage notification settings via the 'ICE Smart' app.
- **Watch Face Customization:** Select from various pre-installed watch faces or download new ones through the app to personalize your display.
- **Always-On Screen:** Enable this feature in settings for continuous time display, which may impact battery life.
- **Pedometer:** Tracks your daily steps, distance, and estimated calories burned.
- **Music Control:** Control music playback on your connected smartphone (play, pause, skip tracks).
- **Camera Control:** Use your watch as a remote shutter for your smartphone's camera.
- **Other Features:** Access stopwatch, alarm, weather updates, and built-in games through the watch's menu.

# 5. HEALTH MONITORING

---

The ICE Smart 2.0 smartwatch includes several sensors to help you monitor your well-being. Access these features through the watch's menu or the 'ICE Smart' app.

- **Heart Rate Monitoring:** Provides real-time heart rate data.
- **Blood Oxygen Level (SpO2):** Measures the oxygen saturation in your blood.
- **Blood Pressure Measurement:** Estimates your blood pressure.
- **Sleep Monitoring:** Tracks your sleep patterns, including deep and light sleep stages.

- **Water Drinking Reminder:** Set reminders to ensure adequate hydration throughout the day.
- **Sedentary Reminder:** Alerts you when you have been inactive for too long, encouraging movement.

*Note: The health monitoring features are for general wellness and fitness purposes only and are not intended for medical diagnosis, treatment, or prevention of disease. Consult a medical professional for any health concerns.*

## 6. WATER RESISTANCE

---

The ICE Smart 2.0 smartwatch has an IP68 rating, meaning it is water resistant up to 1.5 meters for 30 minutes. This makes it suitable for daily use, such as washing hands or being caught in the rain.

**Important:** While water resistant, this device is **not** designed for water sports, swimming, diving, or prolonged submersion in water. Exposure to hot water, steam, or high-pressure water jets should be avoided as it may compromise the water resistance.

## 7. BATTERY LIFE AND CHARGING

---

Your ICE Smart 2.0 is equipped with a robust 300mAh, 3.8V Lithium battery, providing up to 5 days of usage on a single charge, depending on usage patterns and enabled features (e.g., Always-On Display, frequent health monitoring).

### Charging Procedure:

1. Align the magnetic charging pins of the supplied USB cable with the charging contacts on the back of your smartwatch.
2. Ensure a secure connection. The watch display will indicate charging status.
3. Connect the USB end of the cable to a standard USB power adapter (not included) or a computer's USB port.
4. Charge until the battery indicator shows full.

## 8. MAINTENANCE

---

Proper care ensures the longevity and optimal performance of your smartwatch.

- **Cleaning:** Regularly wipe the watch face and strap with a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or solvents.
- **Strap Care:** If your watch has a silicone strap, clean it with mild soap and water, then rinse thoroughly and dry completely before wearing. For metal straps, use a soft brush to remove debris.
- **Avoid Extreme Temperatures:** Do not expose the watch to extreme hot or cold temperatures, as this can damage the battery and internal components.
- **Storage:** When not in use for extended periods, store the watch in a cool, dry place.

## 9. TROUBLESHOOTING

---

If you encounter issues with your ICE Smart 2.0 smartwatch, refer to the following common solutions:

- **Watch not turning on:** Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
- **Cannot pair with phone:**
  - Ensure Bluetooth is enabled on your phone and the watch.
  - Make sure the watch is within Bluetooth range of your phone.

- Restart both your phone and the watch.
- Clear the Bluetooth cache on your phone (Android) or forget the device and re-pair (iOS/Android).
- Ensure the 'ICE Smart' app is updated to the latest version.

- **Notifications not appearing:**

- Check notification settings within the 'ICE Smart' app.
- Ensure your phone's notification permissions are granted to the 'ICE Smart' app.
- Verify that the watch is connected via Bluetooth.

- **Inaccurate health data:**

- Ensure the watch is worn snugly on your wrist, not too loose or too tight.
- Clean the sensors on the back of the watch.
- Remain still during measurements for best accuracy.

- **Short battery life:**

- Disable features like Always-On Display if not essential.
- Reduce screen brightness.
- Limit frequent health monitoring if not needed continuously.
- Ensure the watch is fully charged each time.

If problems persist, consult the support section of the 'ICE Smart' app or contact ICE-WATCH customer support.

## 10. SPECIFICATIONS

Feature	Specification
Model Number	023962
Display	Amoled 1.2" (39mm), 390x390 pixels resolution
CPU	RTL8763EWE-VP
Memory	Flash 128Mb, PSRAM 2Mb
Battery	300mAh, 3.8V Lithium (1 included)
Battery Life	Up to 5 days
Compatibility	iOS 9.0+, Android 5.0+
Water Resistance	IP68 (1.5 meters for 30 minutes)
Band Length	180mm
Dimensions (Package)	15.9 x 9.5 x 3.2 cm
Weight	39 g

## 11. WARRANTY AND SUPPORT

### 11.1 Warranty Information

Your ICE-WATCH Ice Smart 2.0 Smartwatch comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents,

unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

## 11.2 Customer Support

For further assistance, technical support, or warranty inquiries, please refer to the 'ICE Smart' application's support section or visit the official ICE-WATCH website for contact information.

## Related Documents - Ice Smart 2.0 (023962)



**WHAT WATCH SIZE DO I NEED?**  
Pour la taille de votre montre  
Make sure that the size measures from 27% to 33% of your wrist circumference.  
For example, if your wrist circumference is 180mm, the watch size would be 48mm.  
C'est la taille de montre qui convient le mieux à votre poignet.  
Assurez-vous que la taille de montre mesure de 27% à 33% de la circonference de votre poignet.  
Pour exemple, si la circonference de votre poignet est de 180mm, la taille de montre sera de 48mm.  
**FRANÇAIS**      **QUELLE TAILLE ME CORRESPOND ?**  
Assurez-vous que la taille de montre mesure de 27% à 33% de la circonference de votre poignet.  
Si votre circonference de poignet est de 180mm, la taille de montre sera de 48mm.  
**DEUTSCH**      **WELCHE UHRGRÖSSE BRAUCHEN SIE?**  
Stellen Sie sicher, dass die Größe von 27% bis 33% Ihres Handumfangsmaßes ist.  
Für Beispiel, wenn Ihr Handumfang 180mm ist, ist die Uhrgröße 48mm.  
S'assurer que la taille de montre mesure de 27% à 33% de la circonference de votre poignet.  
Par exemple, si la circonference de votre poignet est de 180mm, la taille de montre sera de 48mm.

## [Ice-Watch Size Guide: Find Your Perfect Fit](#)

Discover the official Ice-Watch size guide to help you choose the right watch model and size for your wrist. Includes detailed dimensions for all popular collections.