

UPBRIGHT USB-C 5V AC/DC Adapter

UpBright USB-C 5V AC/DC Adapter Instruction Manual

Model: USB-C 5V AC/DC Adapter

Brand: UPBRIGHT

INTRODUCTION

This manual provides essential information for the safe and effective use of your UpBright USB-C 5V AC/DC Adapter. This adapter is designed to provide reliable power to compatible devices, specifically the Oklar W1101L C02 Blood Pressure Monitors. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- Ensure the adapter's voltage and current ratings match your device's requirements.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not disassemble or attempt to repair the adapter. Refer to qualified personnel for service.
- Keep out of reach of children.
- Unplug the adapter from the power outlet when not in use for extended periods.

PRODUCT OVERVIEW

Features

- World Wide Input Voltage: 100-240VAC 50/60Hz.
- OVP (Over Voltage output Protection), OCP (Over Current output Protection), SCP (Short Circuit output Protection).
- Compatible with Oklar W1101L C02 Blood Pressure Monitors Home Use Rechargeable Cuff Wrist Digital BP Machine LED Backlit Display.
- USB Type C 5VDC Power Supply.

Components

The UpBright USB-C 5V AC/DC Adapter consists of a wall plug unit integrated with a USB Type C cable.



Image: The UpBright USB-C 5V AC/DC Adapter, featuring a black rectangular wall plug with two prongs and an integrated black USB-C cable coiled neatly beside it. The adapter's specifications are visible on its side.

SETUP

1. Locate the USB Type C charging port on your Oklar W1101L C02 Blood Pressure Monitor.
2. Insert the USB Type C connector of the UpBright adapter cable into the monitor's charging port. Ensure a secure connection.
3. Plug the wall plug end of the adapter into a standard 100-240VAC 50/60Hz electrical outlet.

4. The monitor should indicate that it is receiving power or charging.



Image: A close-up view of the UpBright USB-C 5V AC/DC Adapter, highlighting the USB Type C connector. This image demonstrates the specific connector type for compatibility.

OPERATING INSTRUCTIONS

Once connected, the UpBright USB-C 5V AC/DC Adapter will supply power to your Oklar W1101L C02 Blood Pressure Monitor. If your monitor has a rechargeable battery, the adapter will charge it. You can typically use your blood pressure monitor while it is connected to the power adapter, depending on the monitor's design.

- Always ensure the adapter is securely plugged into both the wall outlet and your blood pressure monitor.
- Refer to your Oklar W1101L C02 Blood Pressure Monitor's specific manual for details on its power indicator and charging status.

PROTECTION FEATURES

The UpBright USB-C 5V AC/DC Adapter is equipped with multiple protection features to ensure the safety of your device and the adapter itself:

- **OVP (Over Voltage output Protection):** Prevents damage to your device from excessive voltage.
- **OCP (Over Current output Protection):** Protects against damage from excessive current flow.
- **SCP (Short Circuit output Protection):** Safeguards against short circuits, preventing potential hazards.



Image: An illustrative view of the UpBright USB-C 5V AC/DC Adapter, showing its internal components and highlighting various protection features such as Short-Circuit Protection, Over-Temp Protection, Over-Voltage Protection, and Overcurrent Protection.

SPECIFICATIONS

Feature	Detail
Product Dimensions	4 x 3 x 2 inches
Item Weight	2.08 ounces
Input Voltage	100-240VAC
Output Voltage	5VDC
Connector Type	USB Type C
Color	Black

TROUBLESHOOTING

- **No Power:** Ensure the adapter is firmly plugged into both the wall outlet and the device. Check if the wall outlet is functional.
- **Slow Charging:** Verify that the device's charging port is clean and free of debris. Ensure the adapter is not damaged.
- **Device Not Recognized:** Confirm that your device is compatible with a USB Type C 5VDC power supply.

WARRANTY AND SUPPORT

Your UpBright USB-C 5V AC/DC Adapter comes with:

- A 30-day refund policy.
- A 24-month exchange warranty.

For further assistance or warranty claims, please contact UpBright customer support through your purchase platform.