



Manuals.plus /

› K-MAINS /

› K-MAINS AC Adapter Charger User Manual for Slabway LM-FYCST501G Massager

## K-MAINS K-MAINS-K-422

# K-MAINS AC Adapter Charger User Manual

Model: K-MAINS-K-422

## INTRODUCTION

---

This manual provides essential information for the safe and effective use of your K-MAINS AC Adapter Charger, model K-MAINS-K-422. This adapter is designed to provide power to compatible devices, including the Slabway LM-FYCST501G Air Compression Heated Leg Foot Massager. Please read these instructions thoroughly before use and retain them for future reference.

## SAFETY INFORMATION

---

Your K-MAINS AC Adapter Charger is designed with multiple safety features to ensure reliable operation. Adhere to the following guidelines:

- **Compatibility:** Always verify that the adapter's voltage and current specifications match your device's requirements before connecting. This adapter is specifically compatible with devices like the Slabway LM-FYCST501G Air Compression Heated Leg Foot Massager.
- **Protection Features:** The adapter includes Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard both the adapter and your connected device.
- **Environment:** Use the adapter in a dry environment. Avoid exposure to water, moisture, or extreme temperatures.
- **Handling:** Do not attempt to open, modify, or repair the adapter. Refer all servicing to qualified personnel.
- **Cord Care:** Ensure the power cord is not pinched, walked on, or otherwise damaged. Replace damaged cords immediately.
- **Disconnection:** Always grasp the plug, not the cord, when disconnecting from the power outlet or device.

# Unlti-Protection



Over Voltage  
Protection



Over Load  
Protection



Over Current  
Protection



Over Charge  
Protection



Short Circit  
Protection



Temperature  
Protection

Image: The K-MAINS AC Adapter highlighting its multi-protection features including over voltage, over load, over current, over charge, short circuit, and temperature protection.

## PRODUCT FEATURES

- **Compact and Portable Design:** The adapter is lightweight and designed for easy transport, making it suitable for travel or use in various locations.
- **Durable Construction:** Manufactured with high-quality materials for long-lasting performance and reliability.

- **Universal Input Voltage:** Supports 100 Volts (AC) input, suitable for standard wall outlets.

# PORTABLE DESIGN



*Image: The K-MAINS AC Adapter showcasing its portable design with the main unit and coiled power cord.*

## SETUP AND CONNECTION

1. **Verify Compatibility:** Before connecting, ensure your device requires the output specifications of this K-MAINS adapter (e.g., for Slabway LM-FYGST501G). Check your device's manual or power input label.
2. **Connect to Device:** Insert the adapter's output connector (round type) firmly into the power input port of your compatible device.
3. **Connect to Power Outlet:** Plug the AC adapter into a standard 100V AC wall outlet.

4. **Power On:** Once connected, your device should receive power. Follow your device's instructions to power it on.

This adapter is suitable for various compatible devices, including but not limited to:

- Slabway LM-FYCST501G Air Compression Heated Leg Foot Massager
- CCTV cameras
- Mobile DVD players
- Routers
- TV boxes
- Small desk lamps
- Game machines
- Stereo systems
- Network switches



*Image: The K-MAINS AC Adapter connected to a wall outlet, illustrating its compatibility with various electronic devices.*

## OPERATION

Once properly connected, the K-MAINS AC Adapter Charger operates automatically to provide power to your device. No user intervention is required for its basic function. Ensure the adapter is placed in a well-ventilated area to prevent overheating during prolonged use.

## MAINTENANCE

---

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cord to prevent damage.
- **Inspection:** Periodically inspect the adapter and its cord for any signs of damage, such as cuts, fraying, or bent pins. Discontinue use if damage is found.

## TROUBLESHOOTING

---

If you encounter issues with your K-MAINS AC Adapter Charger, consider the following:

- **Device Not Powering On:**
  - Ensure the adapter is securely plugged into both the wall outlet and the device.
  - Verify the wall outlet is functional by testing it with another appliance.
  - Confirm that the adapter's specifications (voltage, current) match your device's requirements.
  - Check the adapter cord and connector for any visible damage.
- **Adapter Overheating:**
  - Ensure the adapter is in a well-ventilated area and not covered.
  - Confirm that the connected device is not drawing excessive power beyond the adapter's capacity.
  - If overheating persists, discontinue use and contact support.

## SPECIFICATIONS

---

Feature	Detail
Model Number	K-MAINS-K-422
Brand	K-MAINS
Input Voltage	100 Volts (AC)
Power Source	Corded Electric
Connector Type	Round
Compatible Devices	Slabway LM-FYCST501G Air Compression Heated Leg Foot Massager, Cameras, Speakers, Tablets, Routers, etc.
Special Feature	Travel-friendly design
Color	Black
Item Weight	3 ounces (85 grams)
Manufacturer	DONGGUAN RONG HANG ELECTRONIC TECHNOLOGY CO LTD

## WARRANTY AND SUPPORT

---

For information regarding warranty coverage, technical support, or replacement parts, please refer to the contact information provided with your purchase or visit the official K-MAINS website. Please note that any missing or damaged parts should be reported to the seller for a satisfactory solution.