

[Manuals.plus](#) /

› [HoMedics](#) /

› HoMedics Deluxe Ultrasonic Humidifier User Manual

HoMedics UHE-WMTF342

HoMedics Deluxe Ultrasonic Humidifier User Manual

Model: UHE-WMTF342

INTRODUCTION

Thank you for purchasing the HoMedics Deluxe Ultrasonic Humidifier. This advanced humidifier is designed to improve air quality in large rooms by providing both warm and cool mist options, incorporating UV-C technology for cleaner mist, and offering aromatherapy capabilities. Please read this manual thoroughly to ensure proper use, maintenance, and optimal performance of your device.



Image: The HoMedics Deluxe Ultrasonic Humidifier, black in color, shown with its product packaging and remote control. The humidifier features a digital display and a sleek, modern design.

PACKAGE CONTENTS

Please verify that all components are present in your package:

- (1) HoMedics Deluxe Ultrasonic Humidifier
- (1) Remote Control

- (2) "AAA" Batteries (for remote control)
- (1) Demineralization Cartridge
- (3) Essential Oil Tray Pads
- (1) 2-Year Limited Warranty Information

SETUP GUIDE

Follow these steps to set up your humidifier for first use:

1. **Placement:** Place the humidifier on a firm, flat, waterproof surface at least 12 inches (30 cm) away from walls and appliances. Ensure the mist outlet is not directed at furniture or electronics.
2. **Power Connection:** Plug the power cord into a 120V AC electrical outlet.
3. **Fill Water Tank:** The humidifier features a top-fill design. Remove the top cover. Fill the 1.5-gallon tank with clean, cool tap water. Do not use hot water. Do not fill past the MAX fill line. Replace the top cover securely.
4. **Install Demineralization Cartridge:** Locate the demineralization cartridge slot at the bottom of the water tank. Insert the provided demineralization cartridge. This helps reduce mineral buildup and white dust.
5. **Insert Batteries into Remote:** Open the battery compartment on the remote control and insert the two "AAA" batteries, observing polarity (+/-) markings.



LONG RUNTIME
up to 70 hours



1.5 GALLON

**TOP-FILL TANK FOR
LARGE ROOMS
EASY TO CLEAN AND FILL**

Image: A hand pouring water into the top-fill opening of the HoMedics Deluxe Ultrasonic Humidifier. The image highlights the convenient top-fill design.

OPERATING INSTRUCTIONS

Controls and Display

Your humidifier can be operated using the LED touch panel on the unit or the included remote control. The digital display shows current humidity levels and settings.

feel the difference



VISIBLE WARM
& COOL MIST

CLEAN TANK
TECHNOLOGY

HELPS PROTECT THE TANK
FROM MOLD & MILDEW

360° ROTATING

DUAL MIST NOZZLES WITH
7 MIST SETTINGS

NIGHT LIGHT

WITH ON/OFF



PROGRAMMABLE
HUMIDISTAT

WITH SMART-ADJUST HUMIDITY
SENSOR + COLOR INDICATOR



UV-C TECHNOLOGY

REDUCES BACTERIA, MOLD &
FUNGUS IN THE MIST*

AUTO-OFF TIMER
UP TO 12 HOURS

AUTO SHUTOFF
WHEN OUT OF WATER

*UV-C TECHNOLOGY REDUCES E. COLI BACTERIA, STAPHYLOCOCCUS EPIDERMIDIS BACTERIA, A. NIGER MOLD, AND P. CITRINUM FUNGUS IN THE MIST. SHOWN BY INDEPENDENT LABORATORY TESTING.

Image: The HoMedics Deluxe Ultrasonic Humidifier with visual callouts pointing to its key features, including the digital display, UV-C technology, programmable humidistat, and dual 360-degree rotating mist nozzles.

- **Power Button:** Press to turn the unit ON or OFF.
- **Mist Settings:** Cycle through 7 mist output levels to adjust the intensity of the mist.
- **Warm/Cool Mist:** Select between warm mist (for added comfort in colder environments) or cool mist (for general humidification).
- **Programmable Humidistat:** Set your desired humidity level. The smart-adjust humidity sensor will automatically turn the unit on/off to maintain this level. The color indicator on the display provides a quick visual of the current humidity status.
- **UV-C Technology:** This feature operates internally to reduce bacteria, mold, and fungus in the mist. It is always active when the unit is running and is not visible to the eye.
- **Timer:** Set an auto-off timer for up to 12 hours.
- **Night Light:** Turn the soft night light ON or OFF.
- **Auto Shut-off:** The unit will automatically turn off when the water tank is empty.

Aromatherapy Feature

Enhance your environment with essential oils using the built-in aromatherapy tray:

1. Locate the essential oil tray at the base of the humidifier.
2. Pull out the tray.
3. Add 5-7 drops of your favorite essential oil onto one of the included essential oil pads.
4. Slide the tray back into the humidifier. The aroma will diffuse into the air along with the mist.
5. To change scents, replace the essential oil pad. Additional pads can be purchased separately.



relaxing aromatherapy

ADD YOUR FAVORITE SCENT TO THE AIR WITH THE
BUILT-IN ESSENTIAL OIL TRAY

(ESSENTIAL OILS NOT INCLUDED)



Image: A close-up view of the essential oil tray on the HoMedics Deluxe Ultrasonic Humidifier, with the text "OIL TRAY - PUSH HERE" visible, indicating how to access it for aromatherapy.

MAINTENANCE AND CLEANING

Regular cleaning is essential for optimal performance and to prevent mineral buildup and mold. Always unplug the unit before cleaning.

Daily Maintenance

- Empty any remaining water from the tank and base.
- Wipe the tank and base dry with a clean, dry cloth.

Weekly Cleaning (or more often with hard water)

1. **Descaling the Tank:**
 - Pour 2 cups of white vinegar into the water tank.
 - Replace the top cover and gently swirl the vinegar around the tank.
 - Let it soak for 30 minutes.
 - Empty the vinegar and rinse the tank thoroughly with clean water.
2. **Descaling the Base:**
 - Pour 2 cups of white vinegar into the base reservoir.
 - Let it soak for 30 minutes.
 - Using a soft brush or cloth, clean the internal components, including the ultrasonic transducer.
 - Rinse the base thoroughly with clean water. Do not submerge the base in water.
3. **Clean Tank Technology:** The built-in Clean Tank Technology helps protect the tank from mold and mildew. However, regular manual cleaning as described above is still recommended.
4. **Demineralization Cartridge:** Replace the demineralization cartridge every 30-40 fillings, or when you notice increased white dust around the humidifier.

TROUBLESHOOTING

Refer to this table for common issues and their solutions:

Problem	Possible Cause	Solution
No mist or low mist output.	No water in tank. Unit not plugged in. Mineral buildup on transducer. Mist output setting too low.	Refill water tank. Ensure power cord is securely plugged in. Clean the ultrasonic transducer as per maintenance instructions. Increase mist output setting.
White dust around humidifier.	Hard water used. Demineralization cartridge needs replacement.	Use distilled or demineralized water. Replace the demineralization cartridge.
Unusual odor.	Stagnant water or mineral buildup.	Clean the unit thoroughly as per maintenance instructions. Ensure fresh water is used daily.

Problem	Possible Cause	Solution
Unit leaks water.	Tank not seated properly. Overfilled tank. Unit on an uneven surface.	Ensure the tank is correctly seated on the base. Do not fill water past the MAX fill line. Place the unit on a flat, level surface.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Name	Deluxe Ultrasonic Humidifier
Model Number	UHE-WMTF342
Brand	HoMedics
Operation Mode	Ultrasonic (Warm & Cool Mist)
Water Tank Capacity	1.5 Gallons
Runtime	Up to 70 hours (depending on mist setting)
Coverage Area	Up to 502 sq. ft.
Special Features	UV-C Technology, Digital Programmable Humidistat, Smart-Adjust Humidity Sensor, Aromatherapy Tray, Auto Shut-off, Night Light, Remote Control
Product Dimensions	7.42"D x 10.43"W x 15.7"H
Item Weight	6.64 pounds
Power Source	Corded Electric
Batteries Required	2 AAA (for remote, included)

WARRANTY AND SUPPORT

2-Year Limited Warranty: Your HoMedics Deluxe Ultrasonic Humidifier is covered by a 2-year limited warranty from the date of purchase. This warranty covers defects in material and workmanship under normal use. It does not cover damage caused by misuse, abuse, accident, attachment of unauthorized accessories, alteration to the product, or any other conditions whatsoever that are beyond the control of HoMedics.

For warranty service or technical support, please contact HoMedics Customer Service. Do not attempt to repair the unit yourself.

Contact Information:

Please refer to the contact information provided in your product packaging or visit the official HoMedics website for the most up-to-date support details.

© 2025 HoMedics. All rights reserved. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question