

Linsoul BLON BL03 II

Linsoul BLON BL03 II In-Ear Monitor User Manual

Model: BLON BL03 II | Brand: Linsoul

INTRODUCTION

The Linsoul BLON BL03 II In-Ear Monitors (IEMs) are designed to deliver high-fidelity audio with an upgraded 10mm dual-chamber dynamic driver. Featuring a durable zinc alloy acoustic cavity and an ergonomic design for comfortable wear, these wired earbuds offer a balanced and natural sound profile across all frequencies. The detachable 0.78mm 2-pin cable provides flexibility for customization and enhanced durability. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your BLON BL03 II IEMs.

WHAT'S IN THE BOX

Upon opening your Linsoul BLON BL03 II package, you should find the following items:

- Linsoul BLON BL03 II In-Ear Monitors (Left and Right)
- Detachable 0.78mm 2-pin Cable (Type-C with Microphone)
- Assorted Silicone Ear Tips (various sizes for optimal fit)
- User Manual
- Small Carrying Pouch



Image: The complete package contents, showing the IEMs, cable, ear tips, and pouch.

SETUP INSTRUCTIONS

1. **Choose the Right Ear Tips:** Select the ear tips that provide the most comfortable and secure fit, as well as the best sound isolation. Experiment with different sizes to find your ideal fit. A proper seal is crucial for optimal audio performance and passive noise reduction.



Image: The BLON BL03 II IEMs with ear tips attached.

2. **Connect the Detachable Cable:** The BLON BL03 II uses a 0.78mm 2-pin connector. Carefully align the pins on the cable with the receptacles on each IEM unit. Push firmly until the cable is securely connected. Ensure the left (L) and right (R) indicators on the cable match the respective IEM units.



Image: Detachable 2-pin cable connectors.

3. **Wear the IEMs:** The BLON BL03 II are designed to be worn with the cable looped over your ear. This ergonomic design ensures a secure fit and reduces microphonics (cable noise). Gently insert the

earbud into your ear canal, adjusting the cable over your ear until it feels comfortable and stable.



Image: Proper wearing technique for the IEMs, with the cable looped over the ear.

4. **Connect to Your Device:** Plug the Type-C connector of the cable into your audio source (e.g., smartphone, tablet, computer).

OPERATING INSTRUCTIONS

Once properly set up, your Linsoul BLON BL03 II IEMs are ready for use.

- **Audio Playback:** Begin playing audio from your connected device. Adjust the volume using your device's controls.
- **Using the Microphone (Type-C with Mic version):** The in-line microphone allows for hands-free calls and voice commands. Press the button on the microphone unit to answer/end calls or play/pause music.



Image: The BLON BL03 II IEMs connected to a portable audio player.

MAINTENANCE

Proper care will extend the lifespan and maintain the performance of your IEMs.

- **Cleaning Ear Tips:** Regularly remove the ear tips and clean them with mild soap and water. Ensure they are completely dry before reattaching them to the IEMs.
- **Cleaning IEM Units:** Use a soft, dry cloth to wipe the zinc alloy housing. Avoid using harsh chemicals or abrasive materials. For the nozzle, gently remove any earwax or debris using a small brush or cleaning tool.
- **Cable Care:** Avoid sharp bends or excessive pulling on the cable. When not in use, coil the cable loosely and store it in the provided carrying pouch to prevent tangling and damage.
- **Storage:** Store your IEMs in the carrying pouch when not in use to protect them from dust, moisture, and physical damage.



Image: The BLON BL03 II IEMs in hand, demonstrating their compact form factor.

TROUBLESHOOTING

If you encounter any issues with your BLON BL03 II IEMs, refer to the following common solutions:

Problem	Possible Cause	Solution
No sound or intermittent sound	Loose cable connection, incorrect ear tip fit, device volume too low, faulty audio source.	Ensure the 2-pin connectors are fully inserted. Check ear tip fit for a secure seal. Increase device volume. Test with a different audio source.
Poor sound quality (e.g., lack of bass, muffled sound)	Improper ear tip seal, earwax buildup in nozzle, damaged cable.	Adjust ear tips for a tighter seal. Clean earbud nozzles. Try a different cable if available.
Microphone not working	Device settings, faulty microphone.	Check your device's audio input settings to ensure the external microphone is selected. Test with another device.

Problem	Possible Cause	Solution
IEMs feel uncomfortable or fall out easily	Incorrect ear tip size, improper wearing technique.	Experiment with different ear tip sizes. Ensure the cable is looped over your ear for stability.

SPECIFICATIONS

Detailed technical specifications for the Linsoul BLON BL03 II In-Ear Monitors:

- **Driver:** 10mm Dual-Chamber Dynamic Driver (Enhanced Carbon Diaphragm)
- **Impedance:** 32 Ohms
- **Sensitivity:** 116 dB
- **Frequency Range:** 20Hz – 20kHz
- **Connector Type:** 0.78mm 2-pin
- **Cable:** Detachable High-Purity Oxygen-Free Silver-Plated Copper Cable (Type-C with Microphone)
- **Housing Material:** Zinc Alloy
- **Noise Control:** Passive Noise Cancellation
- **Additional Features:** Ergonomic Design, Mirror-Polished Finish

WARRANTY AND SUPPORT

The Linsoul BLON BL03 II In-Ear Monitors come with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty claims, technical support, or any product-related inquiries, please contact Linsoul customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty validation.