

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ZWP](#) /

› [ZWP RF339 Replacement Remote Control Instruction Manual for Adjustable Bed Bases](#)

ZWP RF339

ZWP RF339 Replacement Remote Control Instruction Manual

For OKIN, Tempur, Saatva, Lineal 81649, RF339, JLDK.26.07.11 Adjustable Bed Bases

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your ZWP RF339 replacement remote control. Please read this manual thoroughly to ensure proper functionality and to maximize the lifespan of your remote control. This remote is compatible with adjustable bed bases including models 81649 RF339 JLDK.26.07.11.

SETUP

Battery Installation

The ZWP RF339 remote control requires two AAA batteries (not included). Ensure batteries are inserted with the correct polarity as indicated inside the battery compartment.



Image Description: A close-up view of the back of the RF339 remote control, illustrating the open battery compartment. Two AAA batteries are shown being inserted, with clear markings for positive (+) and negative (-) terminals to guide correct placement.

Pairing Instructions

Follow these steps to pair your ZWP RF339 replacement remote control with your adjustable bed base:

1. **Step 1:** Ensure your bed base remote has fresh batteries installed.
2. **Step 2:** Locate the Battery Backup Box on your adjustable bed base. Press the POWER DOWN button on the Battery Backup Box twice. A light on the Battery Backup Box will illuminate.
3. **Step 3:** On the back of the RF339 remote control, press and hold the PAIR button. The PAIR button will illuminate blue and start flashing. Continue holding until the PAIR button stops flashing and the illuminated light on the Battery Backup Box goes out.
4. **Step 4:** Release the PAIR button. Test all remote functions to confirm successful pairing.



HOW TO PAIRING

1

First, start the massage bed, then find the control box of the massage bed. Locate the Battery Backup Box and press the button TWICE. A light on the Battery Back Up Box will illuminate (Sometimes on the power cord)

2

Point the remote control at the control box (open the remote control battery cover and press the Pair/Paire button).

3

Press and hold the Pair/Paire button for 30 seconds to complete the pairing.

Pairing Button

Image Description: This image provides a visual guide for the pairing process. It shows the back of the RF339 remote control with the battery cover removed, highlighting the 'Pairing Button' within the battery compartment. Adjacent to it, a diagram outlines the three steps for pairing, including locating the control box and pressing the pairing button.

OPERATING INSTRUCTIONS

Remote Control Layout

The ZWP RF339 remote control features an intuitive button layout for easy control of your adjustable bed base. Below is an overview of the remote and its primary functions.



Image Description: A clear, angled view of the ZWP RF339 remote control, showcasing its silver finish and all labeled buttons. The buttons are arranged logically for massage, head/foot adjustments, Zero G, light, and wave functions.

Button Functions

- **MESSAGE (10 MIN, 20 MIN, 30 MIN):** Press these buttons to activate the massage function for the

specified duration.

- **TIMER/ALL OFF:** Press to cycle through massage timer settings or to turn off all active massage functions.
- **HEAD (+ / -):** Use the '+' button to raise the head section of the bed and the '-' button to lower it.
- **FOOT (+ / -):** Use the '+' button to raise the foot section of the bed and the '-' button to lower it.
- **ZERO G:** Activates the 'Zero Gravity' preset position, which elevates the head and foot to a position designed to relieve pressure.
- **LIGHT (Sun Icon):** Toggles the under-bed lighting or other integrated light features.
- **WAVE FUNCTIONS (Wave Icons):** Activates various wave massage patterns.

MAINTENANCE

To ensure the longevity and optimal performance of your ZWP RF339 remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these can damage the surface and internal components.
- **Battery Replacement:** Replace batteries promptly when the remote's performance diminishes or if the indicator light fails to illuminate. Always use new AAA batteries and dispose of old batteries responsibly.
- **Storage:** Store the remote control in a dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your ZWP RF339 remote control, refer to the following common problems and solutions:

- **Remote Not Responding:**
 - Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.
 - Ensure there are no obstructions between the remote and the bed base's receiver.
 - Attempt the pairing process again as described in the 'Pairing Instructions' section.
- **Pairing Failure:**
 - Confirm that the bed base is powered on and the Battery Backup Box light illuminates during the pairing sequence.
 - Ensure you are holding the PAIR button on the remote for the required duration until the light stops flashing.
 - Verify that the remote control is compatible with your specific adjustable bed base model (e.g., 81649 RF339 JLDK.26.07.11).
- **Intermittent Operation:**
 - Weak batteries can cause intermittent operation. Replace them.
 - Ensure the remote is within effective range of the bed base.

SPECIFICATIONS

Brand	ZWP
Model Number	RF339
Compatible Models	81649 RF339 JLDK.26.07.11 Adjustable Bed Base (OKIN, Tempur, Saatva, Lineal)
Color	White
Special Feature	Ergonomic Design
Max Number of Supported Devices	1
Item Weight	1.92 ounces
Package Dimensions	10 x 3 x 1 inches

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your ZWP RF339 replacement remote control, please do not hesitate to contact the manufacturer or seller. Providing your product model number (RF339) and any relevant serial numbers (e.g., 6800013715C20B120392, if applicable to your specific unit) will assist in faster resolution. Your satisfaction is important, and assistance will be provided to resolve any issues.