

MAST TATTOO P60

MAST TATTOO P60 Cordless Tattoo Gun Machine Kit

User Manual

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your MAST TATTOO P60 Cordless Tattoo Gun Machine Kit. Please read this manual thoroughly before operating the device to ensure proper function and to prevent damage or injury. The P60 is designed for professional tattoo artists, offering versatility for various tattooing and permanent makeup applications.

2. SAFETY INFORMATION

- Always ensure the device is clean and sterilized before each use.
- Use only genuine MAST TATTOO needle cartridges and accessories.
- Do not operate the machine if it appears damaged or malfunctioning.
- Keep the device away from water and other liquids.
- Store the device in a dry, safe place, out of reach of children.
- For external use only.

3. PACKAGE CONTENTS

Your MAST TATTOO P60 kit includes the following items:

- MAST TATTOO P60 Cordless Pen
- Extra 900mAh Battery (total 2 batteries)
- 20 Pcs 3RL Tattoo Needles
- 0.5oz Tattoo Ink
- RCA Adapter
- Essential Accessories (e.g., practice skin, grip tape, ink cups)

**EASY CHARGE
ENDLESS PERFORMANCE**



Image: The P60 pen with a detached battery module, highlighting the Type-C charging port for easy and convenient charging.

Video: This video demonstrates the process of installing and removing the battery from the P60 tattoo machine, showing how to connect the Type-C charging cable.

5.2 Attaching the Needle Cartridge

To attach a needle cartridge, gently push the cartridge into the front opening of the pen until it clicks securely into place. Ensure the cartridge is fully seated to prevent any movement during operation. To remove, twist and pull the cartridge out.

SIMPLE TO USE

PRECISION ADAPTATION



Image: A close-up view of a needle cartridge being inserted into the MAST TATTOO P60 pen, demonstrating the secure fit.

Video: This video provides an unboxing experience of the Mast P60, including a demonstration of how to attach a needle cartridge to the machine.

6. OPERATION

6.1 Adjusting Stroke Length

The P60 features an adjustable stroke mechanism. Rotate the grip section of the pen to select your desired stroke length from 2.2mm, 2.5mm, 2.7mm, 2.9mm, or 3.2mm. Each stroke length is suitable for different tattooing techniques and skin types.



Image: A close-up of the P60 pen showing the adjustable grip with marked stroke lengths (2.2mm, 2.5mm, 2.7mm, 2.9mm, 3.2mm).

6.2 Adjusting Needle Length (Depth)

After attaching the needle cartridge, you can adjust the needle's protrusion (depth) by rotating the grip. This allows for precise control over how deep the needle penetrates the skin, crucial for different tattoo styles and client comfort.



Image: A hand adjusting the grip of the P60 pen to control the needle's depth, with visible markings for precise adjustment.

Video: This video demonstrates how to adjust both the needle length and stroke length on the P60 tattoo machine for optimal performance.

6.3 Power On/Off and Voltage Adjustment

To power on the device, press and hold the power button. The integrated display will illuminate, showing the current voltage. Use the '+' and '-' buttons to adjust the voltage to your preferred setting. Double-click the power button to check the work duration. Press and hold the power button again to turn off the device.



**FASHIONABLE
GREAT FEEL**

Curved screen design for simplicity and ease of observation, with elegantly smooth anti-slip lines on the handle, practical and attractive.

MAST p60

LOVE AT FIRST TOUCH

Image: A close-up of the P60 pen's control panel, showing the power button, voltage adjustment buttons ('+' and '-'), and the digital display.

7. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your MAST TATTOO P60.

- **Cleaning:** After each use, wipe down the machine body with a suitable disinfectant. Do not immerse the machine in liquid.
- **Sterilization:** Ensure all components that come into contact with skin or ink are properly sterilized according to professional standards.

- **Storage:** Store the machine in its original packaging or a protective case in a cool, dry place.
- **Battery Care:** Charge batteries regularly, even if not in use, to maintain their lifespan. Avoid overcharging or completely draining the batteries.

8. TROUBLESHOOTING

If you encounter issues with your P60, refer to the following common troubleshooting steps:

- **Machine not turning on:** Ensure the battery is fully charged and correctly installed. If using the RCA adapter, check the power supply connection.
- **Needle not moving:** Verify that the needle cartridge is securely attached and not damaged. Check the stroke adjustment.
- **Inconsistent power:** Ensure the battery is fully charged. If using the RCA adapter, check for loose connections or a faulty power supply.
- **Unusual noise or vibration:** Disassemble and reassemble the machine to ensure all parts are correctly seated. If the issue persists, contact customer support.

9. SPECIFICATIONS

Technical specifications for the MAST TATTOO P60:

Parameter	Value
Weight	121g
Length	150mm
Working Time	>3h (per battery)
Stroke Lengths	2.2mm, 2.5mm, 2.7mm, 2.9mm, 3.2mm
Speed	11000 ±10% rpm
Connect Cord	Type-C
Working Voltage	4V - 10V
Battery Capacity	900mAh
Grip Diameter	22mm

STRONG COLLABORATION WITH MAST BRAND

Lightweight Design
Shorter and Lighter

P60 excels in performance when
using MAST's high-quality
integrated needles

OUTSTANDING
PERFORMANCE

Image: A diagram illustrating the key parameters and dimensions of the MAST TATTOO P60 machine.

10. WARRANTY AND SUPPORT

MAST TATTOO products are manufactured to high-quality standards. For warranty information, product support, or service inquiries, please refer to the warranty card included in your package or visit the official MAST TATTOO website. Keep your purchase receipt as proof of purchase for any warranty claims.