

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Xelarvex](#) /

> [Xelarvex Magnetic Voice Activated Recorder User Manual](#)

Xelarvex Xelarvex Voice Recorder

Xelarvex Magnetic Voice Activated Recorder Manual

Model: Xelarvex Voice Recorder (B0F14XPHBB)

INTRODUCTION

Welcome to the user manual for your Xelarvex Magnetic Voice Activated Recorder. This compact and powerful device is designed for high-quality audio recording in various environments, from lectures and meetings to interviews. With advanced AI-Intelligent Noise Reduction and a long-lasting battery, you can capture clear audio with ease. Its magnetic design offers versatile placement options, and broad compatibility ensures seamless file management across your devices.



Figure 1: Xelarvex Magnetic Voice Activated Recorder Device

PACKAGE CONTENTS

Please ensure all items are present in your package:

- Xelarvex Magnetic Voice Activated Recorder Device
- USB-A to USB-C Charging Cable

- USB-C Headphones
- USB-C to Lightning Adapter
- USB-C to USB-A Adapter
- Storage Pouch



Figure 2: Overview of the recorder and its included accessories, highlighting 64GB memory, 9800 hours voice storage, magnetic attachment, voice activation, 72-hour recording time, and iPhone/Android compatibility.

SETUP

1. Charging the Device

Before first use, fully charge your Xelarvex recorder. Connect the provided USB-A to USB-C charging cable to the device and a power source (e.g., computer USB port, wall adapter). A full charge takes approximately 2 hours.



Figure 3: The recorder connected for charging, emphasizing its 72-hour continuous recording capability and auto-save function.

2. Setting the Time

For accurate timestamping of your recordings, it is recommended to connect the device to a computer (Windows/Mac) or a compatible smartphone (iPhone/Android) using the provided adapters. Access the device's settings file to synchronize the internal clock with your device's time.

OPERATING INSTRUCTIONS

1. Starting a Recording

To begin recording, simply slide the power switch on the side of the device to the **ON** position. The blue indicator light will blink briefly and then turn off, indicating that the device is now actively recording.

2. Stopping and Saving a Recording

To stop recording and save your audio file, slide the power switch to the **OFF** position. The red indicator light will blink briefly, confirming that your recording has been saved to the device's internal memory.

3. Voice Activated Recording (VAR)

The Xelarvex recorder features an intelligent voice activation mode. When enabled (via settings accessed through a connected device), the recorder will automatically start recording when sound is detected above 45dB and pause when the sound level drops below 45dB, conserving battery and storage space.



Figure 4: The voice activation feature in action, illustrating how the device intelligently manages recording based on ambient sound.

4. Accessing and Managing Recordings

You can access your recorded files in several ways:

- **Via USB-C Headphones:** Plug the provided USB-C headphones into the device's USB-C port. You can then listen to your recordings directly. Use the +/- buttons on the headphone cable to navigate between tracks and adjust volume.
- **Via Computer (Windows/Mac):** Connect the recorder to your computer using the USB-A to USB-C cable. The device will appear as a removable drive. Navigate to the 'RECORDED' folder to find your audio files (typically .WAV format).
- **Via Smartphone (iPhone/Android):** Use the appropriate USB-C to Lightning or USB-C to USB-A adapter to connect the recorder to your smartphone. Access the files through your phone's file management application.



Figure 5: The recorder connected to various devices, demonstrating its broad compatibility for seamless file access.

5. Deleting Recordings

To delete recordings directly from the device using the headphones, connect the USB-C headphones. While listening to a recording, press and hold both the '+' and '-' volume buttons simultaneously for approximately 10 seconds until you hear a confirmation tone or indication that the files are deleted.

MAINTENANCE

- Keep the device dry and away from moisture.
- Avoid exposing the device to extreme temperatures.
- Clean the device with a soft, dry cloth. Do not use harsh chemicals.
- Charge the device regularly to maintain battery health, even if not in frequent use.

TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Connect it to a power source and try again.
- **No recording or poor audio quality:** Check that the power switch is firmly in the 'ON' position. Ensure the microphone is not obstructed. While the device has AI-Intelligent Noise Reduction, very loud or continuous background noise may still affect clarity. Try recording in a quieter environment.
- **Cannot access files on computer/phone:** Verify that the correct OTG adapter is used and securely connected. Ensure your computer or phone's file management system is open and recognizing external drives. Try restarting the connected device.
- **Device unresponsive:** Locate the 'RESET' pinhole on the device (often near the USB-C port or switch). Use a small, pointed object (like a paperclip) to gently press the reset button.

SPECIFICATIONS

Feature	Detail
Storage Capacity	64GB (approx. 9800 hours of voice storage)
Continuous Recording Time	Up to 72 hours
Charging Time	Approx. 2 hours (quick charge)
Noise Reduction	AI-Intelligent DSP Active Noise Reduction
Voice Activation Threshold	>45dB (start recording), <45dB (pause recording)
Material	Metal construction
Dimensions	1.8 x 1.8 x 0.4 inches
Item Weight	4.2 ounces
Compatibility	iPhone, Android, Windows, Mac

WARRANTY AND SUPPORT

Your Xelarvex Magnetic Voice Activated Recorder comes with a **1-year warranty**. For any product inquiries, technical support, or warranty claims, please contact Xelarvex customer service through the retailer's platform or visit our official website for contact information.

We are committed to providing excellent support and ensuring your satisfaction with our products.