

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VEODONT](#) /

> [VEODONT Universal Side Brushes Instruction Manual for Mamibot PetVac 280 Robot Vacuum Cleaner \(Model 2280\)](#)

VEODONT 2280

VEODONT Universal Side Brushes Instruction Manual

Compatible with Mamibot PetVac 280 / Petvac280 Robot Vacuum Cleaner (Model 2280)

1. INTRODUCTION

This manual provides instructions for the proper installation, maintenance, and troubleshooting of your VEODONT universal side brushes. These brushes are designed as replacement parts for Mamibot PetVac 280 and Petvac280 robot vacuum cleaners, ensuring continued optimal cleaning performance.

2. SAFETY INFORMATION

- Always turn off and unplug your robot vacuum cleaner before attempting any installation, removal, or maintenance procedures.
- Ensure the robot vacuum is on a stable, flat surface to prevent accidental movement.
- Keep small children and pets away from the robot vacuum during maintenance.
- Handle brushes carefully to avoid bending or damaging the bristles.

3. PACKAGE CONTENTS

Your package should contain the following items:

- 6 x VEODONT Universal Side Brushes (3 with square mounting, 3 with circular mounting)



This image shows a complete set of six VEODONT universal side brushes. Three brushes are equipped with a square central mounting point, and three are equipped with a circular central mounting point. All brushes feature three black bristles and a yellow base, ready for installation on compatible robot vacuum cleaners.

4. SETUP AND INSTALLATION

Follow these steps to replace the side brushes on your Mamibot PetVac 280 / Petvac280 robot vacuum cleaner:

1. **Power Off:** Ensure your robot vacuum cleaner is powered off and disconnected from its charging base.
2. **Access Brushes:** Carefully turn the robot vacuum cleaner upside down to expose the underside where the side brushes are located.
3. **Remove Old Brushes:** Depending on your specific Mamibot PetVac 280 model, the side brushes may be held in place by a screw or a simple snap-on mechanism. Use a small screwdriver (if necessary) to remove the central screw holding the old brush. Gently pull the old brush upwards to detach it.
4. **Select Correct Brush:** Observe the mounting point on your robot vacuum. It will either be square or circular. Select the corresponding VEODONT side brush (either with a square or circular central hole) from your package.
5. **Install New Brush:** Align the central hole of the new VEODONT side brush with the mounting post on the robot vacuum. Press down firmly until it clicks into place or re-insert and tighten the screw if applicable. Ensure the brush is securely attached and can rotate freely.

6. **Repeat:** If your robot vacuum uses two side brushes, repeat the process for the second brush.
7. **Verify:** Once installed, gently spin the brushes by hand to confirm they are properly seated and move without obstruction.



This image displays two VEODONT universal side brushes. One brush features a square-shaped central mounting point, while the other has a circular mounting point. Both brushes have three black bristles extending from a yellow base, designed to sweep debris into the vacuum's path. This illustrates the two types of brushes provided for compatibility.

5. OPERATING

Once the new side brushes are installed, turn your robot vacuum cleaner back on. The side brushes will automatically rotate during cleaning cycles, sweeping debris from edges and corners into the main suction path of the vacuum. No special operation is required for the brushes themselves beyond their proper installation.

6. MAINTENANCE

Regular maintenance of your side brushes ensures efficient cleaning and extends their lifespan.

- **Cleaning:** Periodically inspect the side brushes for tangled hair, string, or other debris. Turn off the vacuum, remove the brushes as described in the installation section, and carefully remove any obstructions. You can

use a small pair of scissors or a cleaning tool to cut away tangled hair.

- **Inspection:** Check the bristles for wear, bending, or damage. If bristles are significantly worn or permanently bent, the brush's effectiveness will be reduced.
- **Replacement:** It is recommended to replace side brushes every 3-6 months, or sooner if visible wear or damage occurs, to maintain optimal cleaning performance. The frequency of replacement depends on usage and the type of debris encountered.

7. TROUBLESHOOTING

- **Brushes Not Spinning:**

- Ensure the brushes are installed correctly and securely.
- Check for any hair or debris tangled around the brush's base or motor shaft.
- Verify that the robot vacuum's brush motor is functioning properly (this may require professional inspection if the issue persists after clearing obstructions).

- **Brushes Making Unusual Noise:**

- Remove and clean the brushes thoroughly, checking for any trapped debris.
- Ensure the brushes are not bent or damaged, which could cause imbalance during rotation.

- **Brushes Falling Off:**

- Confirm the correct brush type (square or circular mounting) was used for the specific mounting post.
- If screw-mounted, ensure the screw is tightened sufficiently.
- If snap-on, ensure the brush is fully seated and clicked into place.

8. SPECIFICATIONS

Brand	VEODONT
Model Number	2280
Compatibility	Mamibot PetVac 280, Petvac280 Robot Vacuum Cleaners
Color	Black bristles, Yellow base
Package Contents	6 Side Brushes
Item Weight	1.76 ounces (50 Grams)
Package Dimensions	1.18 x 0.79 x 0.39 inches

9. WARRANTY INFORMATION

For specific warranty details regarding your VEODONT side brushes, please refer to the product packaging or contact the manufacturer directly. Warranty terms may vary based on region and retailer.

10. SUPPORT

If you encounter any issues or have questions not covered in this manual, please contact VEODONT customer support through their official website or the retailer from whom the product was purchased. Please have your product model number (2280) and purchase information ready when contacting support.

