

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [YenLove](#) /

> [YenLove Automatic Touchless Mouthwash Dispenser S15 User Manual](#)

YenLove S15

YenLove Automatic Touchless Mouthwash Dispenser S15 User Manual

Model: S15

1. INTRODUCTION

Thank you for choosing the YenLove Automatic Touchless Mouthwash Dispenser. This manual provides essential information for the safe and efficient use of your new device. Please read it thoroughly before operation and retain it for future reference.

Package Contents:

- Mouthwash Dispenser Unit x1
- Reusable Cups x4 (2 black, 2 white)
- Cup Holders x2
- Mounting Screws x1 set
- Self-Adhesive Pads x3
- USB-C Charging Cable x1
- User Manual x1



Image 1.1: YenLove Automatic Mouthwash Dispenser and its components, including the main unit, four magnetic cups, and charging cable.

2. SAFETY INFORMATION

- Do not immerse the main unit in water. The device is water-resistant but not fully waterproof. Avoid direct water spray.
- Keep out of reach of children without adult supervision.
- Use only the provided USB-C cable for charging. Do not use while charging.
- Ensure the dispenser is securely mounted before filling with mouthwash.
- Do not use abrasive cleaners or solvents on the device.
- This device is intended for dispensing mouthwash only. Do not use with other liquids.

3. PRODUCT OVERVIEW

The YenLove Automatic Touchless Mouthwash Dispenser offers a hygienic and convenient way to dispense mouthwash. It features a touch-free sensor, adjustable dispensing volumes, an LED display, and a large capacity reservoir.



Care about the oral health of your loved ones

Image 3.1: Detailed diagram illustrating the components of the dispenser, including the Power/Mode Selector, Display Screen, Water Outlet, Main Unit, Water Catch Tray, Water Hose, Water Tank, Type-C Charging Port, Hook, Wall-Mounted Adhesive Board, and Mouthwash Cup Holder.

Key Features:

- **Touch-Free Dispensing:** Infrared sensor detects cup placement for automatic dispensing.
- **Adjustable Volume:** Four modes (10ml, 20ml, 30ml, Custom) to suit individual needs.
- **LED Display:** Shows dispensing volume and battery status.
- **Large Capacity:** 600ml (20.29 oz) transparent mouthwash tank.
- **Rechargeable Battery:** 2000mAh battery provides up to 180 days of standby time.
- **Magnetic Cups:** Four hygienic cups included, designed for easy storage and use.
- **Easy Installation:** Wall-mountable with screws or adhesive options.

4. SETUP

4.1 Initial Charging

1. Before first use, fully charge the dispenser. Connect the provided USB-C cable to the charging port on the side of the main unit.
2. Connect the other end of the USB-C cable to a DC 5V1A USB power adapter (not included).
3. The LED display will indicate charging status. A full charge takes approximately 3 hours. The device cannot be used while charging.



Image 4.1: The dispenser's charging port and LED display indicating battery level and charging time.

4.2 Installation

Choose between wall-mounted installation (for humid environments) or adhesive installation (for smooth surfaces).

Option A: Wall-Mounted (Screws)

1. Select a suitable location on your bathroom wall.
2. Mark the positions for drilling using the mounting bracket as a guide.
3. Drill holes and insert the wall anchors.
4. Secure the mounting bracket to the wall with the provided screws.
5. Slide the dispenser unit onto the mounting bracket until it clicks into place.

Option B: Adhesive Installation (No-Drill)

1. Clean and dry the desired wall surface thoroughly. Ensure it is smooth and non-porous.
2. Peel off the protective film from the self-adhesive pad.
3. Attach the adhesive pad to the back of the mounting bracket.
4. Press the mounting bracket firmly onto the wall for 30 seconds.
5. **Wait 24 hours** before hanging the dispenser unit to ensure maximum adhesion.
6. Slide the dispenser unit onto the mounting bracket.

4.3 Filling the Mouthwash Tank

1. Remove the mouthwash tank from the main unit by twisting it counter-clockwise.
2. Pour your preferred mouthwash into the tank, ensuring not to exceed the MAX fill line. The tank has a 600ml capacity.
3. Reattach the tank to the main unit by twisting clockwise until secure. Ensure the water hose is properly inserted into the tank.



Image 4.2: The dispenser's transparent tank allows for easy monitoring of mouthwash levels and refilling.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- To power on, press and hold the Power/Mode Selector button (located on top of the unit) for 3 seconds. The LED display will light up.
- To power off, press and hold the Power/Mode Selector button for 3 seconds. The LED display will

turn off.

5.2 Selecting Dispensing Modes

The dispenser has four dispensing modes: 10ml, 20ml, 30ml, and Custom (00ml).

1. With the dispenser powered on, short press the Power/Mode Selector button to cycle through the available volume settings: 10ml, 20ml, 30ml, and 00ml.
2. The selected volume will be displayed on the LED screen.
3. **Custom Mode (00ml):** In this mode, the dispenser will dispense mouthwash continuously as long as the cup is placed under the nozzle. Remove the cup to stop dispensing.



Image 5.1: The LED display shows the selected dispensing volume, allowing users to choose between 10ml, 20ml, 30ml, or a custom amount.

5.3 Dispensing Mouthwash

1. Ensure the dispenser is powered on and your desired volume mode is selected.
2. Place one of the provided magnetic cups directly under the dispensing nozzle. The sensor will detect the cup.
3. The dispenser will automatically dispense the pre-set amount of mouthwash into the cup. In Custom Mode (00ml), remove the cup to stop dispensing.
4. After use, you can hang the magnetic cups upside down on the included cup holders to keep them dust-free and dry.

6. MAINTENANCE

6.1 Cleaning

- **External Cleaning:** Wipe the exterior of the dispenser with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
- **Internal Cleaning (Automatic):** The custom mode (00ml) can be used for automatic cleaning. Fill the tank with clean water, select 00ml mode, and place a cup to dispense water through the system. Repeat as necessary.
- **Tank Cleaning:** Periodically remove the mouthwash tank and rinse it thoroughly with water. Allow it to air dry completely before refilling.
- **Cup Cleaning:** Wash the magnetic cups with soap and water regularly.

6.2 Refilling

When the mouthwash level in the transparent tank is low, refill it following the instructions in Section 4.3.

6.3 Charging

When the battery indicator on the LED display shows low power, recharge the dispenser using the provided USB-C cable as described in Section 4.1. The 2000mAh battery offers a long standby time of up to 180 days on a single charge.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Dispenser does not turn on.	Battery is depleted.	Charge the dispenser fully (refer to Section 4.1).
No mouthwash dispenses.	<ul style="list-style-type: none">• Mouthwash tank is empty.• Water hose is not properly inserted.• Sensor is obstructed.• Dispenser is off.	<ul style="list-style-type: none">• Refill the mouthwash tank.• Ensure the water hose is securely placed in the tank.• Clear any obstructions from the sensor area.• Turn on the dispenser.
Dispensing volume is incorrect.	Incorrect mode selected.	Press the Power/Mode Selector button to cycle to the desired volume (refer to Section 5.2).
Dispenser falls off the wall.	Adhesive not fully cured or surface not clean.	If using adhesive, ensure the surface is clean and dry, and wait 24 hours before hanging. For humid environments, screw mounting is recommended.
LED display is not working.	Device is off or battery is very low.	Turn on the device or charge the battery.

8. SPECIFICATIONS

Feature	Detail
Model	S15
Brand	YenLove
Material	Plastic
Color	Black
Product Dimensions	10.2"L x 3.5"W x 3.5"H (25.9cm L x 8.9cm W x 8.9cm H)

Feature	Detail
Item Weight	1.08 pounds (0.49 kg)
Mouthwash Tank Capacity	600ml (20.29 oz)
Battery	2000mAh Lithium Ion (rechargeable)
Charging Port	USB-C (DC 5V1A)
Charging Time	Approx. 3 hours
Standby Time	Up to 180 days
Dispensing Modes	10ml, 20ml, 30ml, Custom (00ml)

9. WARRANTY AND SUPPORT

YenLove is committed to providing high-quality products. For warranty information, technical support, or any questions regarding your Automatic Touchless Mouthwash Dispenser, please refer to the contact information provided with your purchase or visit the official YenLove website. Please retain your proof of purchase for warranty claims.