

## HY-C8 AI Smart Translator Wireless Bluetooth Glasses Headset (HY-G11 AI Sunglasses)

# HY-C8 AI Smart Translator Wireless Bluetooth Glasses Headset User Manual

Model: HY-G11 AI Sunglasses

## INTRODUCTION

---

This manual provides comprehensive instructions for the HY-C8 AI Smart Translator Wireless Bluetooth Glasses Headset. Please read this manual carefully before using the product to ensure proper operation and to maximize its features. This device combines smart translation capabilities with a comfortable glasses design, offering real-time language interpretation, audio communication, and AI-powered assistance.



Image: The HY-C8 AI Smart Translator Wireless Bluetooth Glasses Headset, shown with its packaging, charging cable, and instruction manual. This image displays the black variant of the glasses.

## PACKAGE CONTENTS

---

Verify that all items are present in the package:

- 1 x HY-C8 AI Smart Translator Wireless Bluetooth Glasses Headset
- 1 x Magnetic Charging Cable
- 1 x Instruction Manual
- 1 x Lens Cloth



Image: A detailed view of the package contents, including the HY-C8 glasses, magnetic charging cable, instruction manual, and lens cloth. This image features the black version of the glasses.

## SPECIFICATIONS

Feature	Detail
Material	ABS+PC
Battery Capacity	55mAh*2
Product Weight	135g
Connectivity	Bluetooth
Wireless Distance	10m and above
Operation Method	Touch communication function
Translation Languages	75 national languages

Feature	Detail
Additional Functions	Bluetooth music, AI smart translation, meeting records, AI graphic office, AI chat, AI voice dialogue, AI music, AI office assistant, AI recording conference assistant

**Smart AI Bluetooth Glasses**

Real-time translation | Audio and video calls | Meeting Minutes | simultaneous interpretation | 166 AI agents  
 172 languages | Visual Chat | Field Recording Shorthand Summary | Translators near you | AI friend in your ear

**deepseek** x **Doubao AI large model**  
 Exploring Unknown Territory | Ringing the Door of the Unknown

The graphic features a pair of black smart glasses with clear lenses, resting on a blue water surface that creates ripples. The background is a light blue gradient with a faint grid pattern. Text and icons are arranged in a clean, modern layout.

Image: A graphic displaying key product parameters for the HY-C8 Bluetooth Glasses, including Bluetooth version (5.4), effective distance (10m), speaker size (10mm), interface type (DC magnetic), charging time (1h), and battery capacity (55mAh).

## SETUP

### 1. Charging the Device

Before first use, fully charge the HY-C8 glasses. Connect the magnetic charging cable to the charging port on the glasses and the other end to a USB power adapter (not included) or a computer USB port.

- A full charge typically takes approximately 1 hour.
- The indicator light on the glasses will show charging status (e.g., red for charging, blue/green for fully charged).

## 2. Pairing with Your Mobile Device

The HY-C8 glasses connect to your smartphone via Bluetooth for full functionality, including translation and AI features.

1. Ensure the glasses are powered on.
2. Enable Bluetooth on your mobile device.
3. Open the dedicated HY-C8 companion application (download from your device's app store).
4. Within the app, navigate to the device pairing section.
5. Select "HY-C8" from the list of available Bluetooth devices.
6. Confirm the pairing request on both the glasses (if prompted) and your mobile device.

Once paired, the glasses are ready for use with the application.

## OPERATING INSTRUCTIONS

---

### 1. Basic Controls

The HY-C8 glasses feature touch-sensitive controls for various functions. Specific touch gestures will be detailed within the companion app.

- **Power On/Off:** Press and hold the designated button/area for a few seconds.
- **Volume Adjustment:** Swipe or tap specific areas on the temple arms.
- **Call Answering/Ending:** Single tap on the designated area.
- **Music Play/Pause:** Single tap on the designated area.

### 2. AI Smart Translation

The core feature of the HY-C8 is its real-time translation capability. This function requires the companion app to be active and connected.

1. Open the HY-C8 app on your paired mobile device.
2. Select the "Translation" mode within the app.
3. Choose the source and target languages for translation.
4. Speak clearly into the glasses' microphone. The translated audio will be played back through the glasses' speakers.
5. For conference or multi-speaker translation, utilize the app's advanced settings for speaker distinction and transcription.

The device supports 75 national languages for barrier-free communication.

# HY1008

## Bluetooth glasses

AI intelligent translation

AI Voice Video Call

Make a call

Polaroid polarized lenses

Fashion design

Can't get rid of it

Control camera

DC magnetic charging

Various AI intelligent functions

Built-in GPTdeepseek

Doubao AI large model

镜片颜色  
Lens Color  
—  
灰色  
Gray

镜框颜色  
Mirror Frame  
—  
黑色  
Black



Image: An illustration highlighting the key features of the Smart AI Bluetooth Glasses, such as real-time translation in 172 languages, audio and video calls, meeting minutes, simultaneous interpretation, and AI agents.

### 3. AI Functions and Office Assistant

Leverage the integrated AI for various tasks:

- **AI Chat/Voice Dialogue:** Interact with the AI for information, queries, or general conversation.
- **AI Music:** Control music playback and access AI-curated playlists.
- **AI Office Assistant:** Utilize features like meeting records, graphic office assistance, and recording transcription with up to 98% accuracy.

These functions are primarily managed through the companion application, with audio output and input handled by the glasses.

## MAINTENANCE

## 1. Cleaning

- Use the provided lens cloth to gently clean the lenses.
- For the frame and temple arms, wipe with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, alcohol, or solvents, as these can damage the finish or electronic components.

## 2. Storage

- Store the glasses in a cool, dry place, away from direct sunlight and extreme temperatures.
- When not in use, store them in their protective case to prevent scratches and damage.

## 3. Battery Care

- Avoid fully discharging the battery frequently.
- Charge the device regularly, even if not in constant use, to maintain battery health.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the device fully using the magnetic charging cable.
Cannot pair with mobile device.	Bluetooth is off on mobile device; glasses are not in pairing mode; interference.	Ensure Bluetooth is enabled. Restart glasses and mobile device. Move closer to the device. Check app for pairing instructions.
Translation is inaccurate or not working.	Poor internet connection; incorrect language selection; background noise.	Ensure stable internet connection. Verify source and target languages. Speak clearly and reduce background noise. Update the app.
Audio quality is poor.	Low battery; distance from paired device; interference.	Charge the glasses. Stay within 10m of the paired device. Avoid environments with strong electromagnetic interference.

## WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including warranty duration and coverage details.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact the manufacturer or your point of purchase. Contact information may be found on the product packaging or the manufacturer's official website.

Manufacturer: CNSX-LOVE LIFE

Place of Business: Foshan Zhidunying Electronic Equipment Co., Ltd. Address: Foshan, Guangdong, China

