



Manuals.plus /

- › Cloudeck /
- › Cloudeck Mouse Mover Undetectable Mouse Jiggler Instruction Manual

Cloudeck MJUF-8A

Cloudeck Mouse Mover Undetectable Mouse Jiggler

INSTRUCTION MANUAL

Product Overview

The Cloudeck Mouse Mover is an undetectable mouse jiggler designed to keep your computer active and prevent it from entering sleep mode. This device simulates physical mouse movement, ensuring your online status remains active for applications like Microsoft Outlook, Microsoft Teams, and Skype. It operates silently and is 100% undetectable by IT departments as it does not require software installation or direct connection to your computer's USB data port.



This image displays the Cloudeck Mouse Mover, a circular device designed to simulate mouse movement. It features a textured top surface where the mouse is placed, and a smooth base. The device is shown from an angle, highlighting its compact and discreet design.

Setup

- Power Connection:** Connect the Mouse Mover using the provided 5V/2A power adapter and cable. The device can be powered either by an external power adapter or by a USB port on your computer. Powering via a computer's USB port will not be detected by IT departments.
- Mouse Placement:** Place your optical mouse on the spinning wheel of the Mouse Mover. Ensure the optical sensor of your mouse is directly over the center of the spinning wheel for optimal operation.
- Initial Activation:** Once powered and the mouse is correctly positioned, the device is ready for use.

Operating Instructions

- ON/OFF Switch:** The Mouse Mover features an integrated ON/OFF switch. Simply press the switch to turn the device on or off. There is no need to repeatedly plug and unplug the device.
- Speed Modes:** The device offers two speed modes for mouse movement, along with a memory function that retains your last selected speed setting. Refer to the device's indicators for current speed mode (specific method for changing modes not detailed in product information).
- Undetectable Operation:** The Mouse Mover simulates physical mouse movement and does not require any software installation or direct data connection to your computer. This design ensures it remains undetectable by hardware scans and company IT systems.

- **Compatibility:** This device is compatible with most operating systems, including Windows 7/8/10, Linux, and Mac. It works with any optical mouse.

Maintenance

To ensure the longevity and optimal performance of your Cloudeck Mouse Mover, follow these simple maintenance guidelines:

- **Cleaning:** Gently wipe the device with a soft, dry cloth to remove dust or debris. Avoid using abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the device with care to prevent physical damage. Avoid dropping or subjecting it to strong impacts.

Troubleshooting

If you encounter issues with your Cloudeck Mouse Mover, consider the following:

- **Device Not Moving Mouse:**
 - Ensure the device is properly powered. Check the power adapter and cable connection.
 - Verify that the ON/OFF switch is in the 'ON' position.
 - Confirm that your optical mouse's sensor is correctly positioned directly over the spinning wheel.
 - Test with a different optical mouse to rule out mouse-specific issues.
- **Unusual Noise:**
 - While designed to be ultra-silent, ensure no foreign objects are obstructing the spinning mechanism.
 - If persistent, contact customer support.

Specifications

Feature	Detail
Model	MJUF-8A
Product Dimensions	4.9 x 4.9 x 0.04 inches
Item Weight	7 ounces
Brand	Cloudeck
Color	Blue
Connectivity Technology	USB (for power only)
Special Feature	Ultra-Silent, Undetectable by IT
Movement Detection Technology	Optical (compatible with)

Warranty and Support

Cloudeck is committed to product quality and customer satisfaction. We have dedicated 3 years to research and development to bring you a reliable product.

For any questions, concerns, or support needs regarding your Mouse Mover, please contact our customer service team. We aim to provide a satisfying solution within 24 hours, 7 days a week.

Your suggestions and opinions are valuable to us as they help us continuously improve our products.