

BEST UFL

User Manual

ADJUSTABLE BASE REPLACEMENT REMOTE CONTROL

Model: BEST UFL

1. INTRODUCTION

This manual provides comprehensive instructions for the Generic Adjustable Base Replacement Remote Control, Model BEST UFL. This remote is designed for use with Leggett & Platt Performance/Mattress Firm 500 Series Bed Frames. Please read this manual carefully before using your new remote control to ensure proper operation and to maximize its lifespan.

2. PRODUCT OVERVIEW

The BEST UFL remote control is an OEM pre-owned replacement unit, thoroughly tested for functionality. It is designed to provide seamless control over your compatible adjustable bed frame. Its ergonomic and lightweight design ensures comfortable handling.



Figure 2.1: Front view of the BEST UFL remote control, displaying its various function buttons.

2.1 Compatibility

This remote control is compatible with Leggett & Platt Performance/Mattress Firm 500 Series Bed Frames. It is crucial to ensure that the buttons and their labels on this remote exactly match your original remote control for proper functionality. If the buttons do not match, this remote may not be compatible with your specific bed frame model.

3. SETUP

3.1 Battery Installation

The remote control requires 3 AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert 3 AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.



Figure 3.1: Battery compartment of the remote control, showing space for three AAA batteries.

3.2 Initial Use

Once batteries are installed, the remote control should be ready for immediate use with compatible Leggett & Platt Mattress Firm 500 Series bed frames. No additional pairing steps are typically required if the remote's buttons match your original unit.

4. OPERATING INSTRUCTIONS

Familiarize yourself with the buttons on your remote control:

- **POSITION + / -:** Adjusts the overall bed position (head and foot simultaneously or proportionally).
- **HEAD:** Adjusts the head section of the bed. Press '+' to raise, '-' to lower.
- **FOOT:** Adjusts the foot section of the bed. Press '+' to raise, '-' to lower.
- **CUST 1 / CUST 2:** Recalls pre-programmed custom positions.
- **SET:** Used to program or save custom positions (refer to your bed frame's manual for specific programming steps).
- **FLAT:** Returns the bed to a completely flat position.
- **MESSAGE + / -:** Controls the massage function. Press '+' to increase intensity/mode, '-' to decrease.

To operate, point the remote control towards the bed frame's receiver and press the desired function button. Ensure there are no obstructions between the remote and the bed frame.

5. MAINTENANCE

5.1 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or immerse the remote in liquid.

5.2 Battery Replacement

Replace batteries when the remote's performance diminishes or if it stops responding. Always replace all three AAA batteries at the same time with new ones. Dispose of old batteries according to local regulations.

5.3 Storage

Store the remote control in a dry place, away from extreme temperatures and direct sunlight. If storing for an extended period, it is advisable to remove the batteries to prevent leakage.

6. TROUBLESHOOTING

- **Remote not responding:**

- Check if the batteries are installed correctly and are not depleted. Replace with fresh AAA batteries if necessary.
- Ensure there are no obstructions between the remote control and the bed frame's receiver.
- Verify that the remote's buttons and labels exactly match your original remote. Incompatibility is a common cause of non-responsiveness.

- **Bed frame functions intermittently:**

- This could indicate low battery power. Replace the batteries.
- Ensure you are within range of the bed frame's receiver.

- **Remote has light scratches:**

- As a pre-owned unit, minor cosmetic imperfections like light scratches are normal and do not affect functionality.

If you continue to experience issues after following these troubleshooting steps, please refer to the support section.

7. SPECIFICATIONS

Model Number	BEST UFL
Product Dimensions	7 x 2 x 0.5 inches
Item Weight	4 ounces
Power Source	3 AAA batteries (required)
Compatible Devices	Leggett & Platt Performance/Mattress Firm 500 Series Bed Frames
Special Features	Ergonomic, Lightweight

8. WARRANTY AND SUPPORT

As this is a pre-owned replacement unit, specific manufacturer warranty details may vary. For any

questions, technical assistance, or support regarding this replacement remote control, please contact the seller directly through your purchase platform. They will be able to provide further guidance and assistance.