




---

[Home](#) » [companion](#) » **Companion FINDER T Global Locator Integrates With Apple Find My Network User Manual** 

## Contents [ [hide](#) ]

- [1 Companion FINDER T Global Locator Integrates With Apple Find My Network](#)
- [2 Overview Introduction](#)
- [3 Button Function](#)
- [4 How to Pair](#)
- [5 Battery](#)
- [6 Battery Replacement](#)
- [7 Additional Tips](#)
- [8 Important Matters](#)
- [9 Important Handling Guidelines](#)
- [10 Legal Notice](#)
- [11 FCC WARNING](#)
- [12 Documents / Resources](#)
  - [12.1 References](#)

*Companion*

**Companion FINDER T Global Locator Integrates With Apple Find My Network**





## Overview Introduction

The FINDER integrates with Apple Find My network to provide a secure and user-friendly solution for tracking items, making it easy to locate keys, wallets, and more, with security and privacy at the forefront.

FINDER is designed for the convenience of users, simplifying daily life, allowing you to say goodbye to lost belongings and enjoy a peace of mind lifestyle.

## Button Function

### Power On

Tap the button once and hear 1 beep (1 tick).

### Power Off

Press and hold the button (about 5s) to hear 3 prompt sounds (3 ticks) and release.

### Factory Reset

Click 3 times in a row + long press the 4th time to hear a long beep tone.

## How to Pair

**Note:**iOS or iPadOS version 14.5 or above.





(Figure1 )



(Figure2 )



( Figure3 )

1. Place the FINDER next to your Apple device, like an iPhone.
2. Turn on bluetooth on your iPhone and connect to the Internet.
3. Press the button of the FINDER once to turn on the device.
4. Open the 'Find My' app.
5. In the 'Find My' app, Tap '+', then 'Add Other Item'. See figure 1.
6. Once your FINDER is located, tap 'connect' See figure 2.
7. Enter a name and choose an emoji for your FINDER and tap 'Continue'. See Figure 3.
8. Find My will ask for confirmation to add your FINDER to your Apple ID. Tap
9. Tap 'finish' and your FINDER will be set up and ready to be used.

## Battery

The FINDER contains a CR2032 coin cell battery. During the product's lifespan, it may be necessary to replace the battery. And you should pay attention to the positive and negative electrodes of the battery.

## Battery Replacement

1. Rotate counterclockwise to separate the upper and lower housings.
2. Replace the battery with a new one, with the positive terminal facing upwards.
3. Turn clockwise to tighten the case.

## Additional Tips

1. When the device is paired with the Find My app, the phone needs to be linked to the Apple server.

Pairing failures may occur due to network issues.

We recommend the following:



- **a.** Change the cellular network, such as switching between WIFI and mobile networks;
  - **b.** Factory reset the PBX FINDER;
  - **c.** Re-pairing.
2. To remove FINDER from your Apple device, open the Find My app, select "items", find the device, then scroll down and tap "Remove this device".
  3. Battery life, related to personal usage habits, frequent use of the call function will accelerate battery drain.

## **Important Matters**

The FINDER contains delicate electronics, including a battery, to avoid damage, loss of function, or potential harm.

Please refrain from dropping, hitting, puncturing, crushing, disassembling, exposing it to extreme heat or liquids, or placing it in areas with a high concentration of industrial chemicals.

**WARNING:** Do not swallow the battery; There is a chemical burn hazard.

### **Choking Hazard Warning**

The FINDER, its battery compartment door, the battery itself, and the case may pose a choking hazard or cause injury to small children. Please keep these items out of reach of young children.

### **Medical Device Interference**

The FINDER contains components and radios that emit electromagnetic fields, as well as magnets. These elements may potentially interfere with pacemakers, defibrillators, or other medical devices. To ensure safety, maintain a safe distance between your medical device and the FINDER.

We strongly advise consulting your physician and the manufacturer of your medical device for information that is specific to your situation. If you suspect that the FINDER is interfering with your pacemaker defibrillator or any other medical device, discontinue its



use immediately.

## **Important Handling Guidelines**

It's normal for the FINDER to show discoloration with regular use. To clean it, use a soft, dry, lint-free cloth.

Avoid applying pressure with sharp objects on the rubber seal or the battery terminal contacts inside the device.

Do not allow moisture to enter any openings or use aerosol sprays, solvents or abrasive materials to clean the device.

## **Legal Notice**

Use of the Works with Apple badge means that a product has been designed to work < specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My NeM/ork product specifications and requirements. Apple is not responsible for the operation of this device or the use of this product or its compliance with safety and regulatory standards. Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS, and watch OS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

## **FCC WARNING**

This device complies with part 15 of the FCC Rules.

**Operation is subject to the following two conditions:** (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to



provide reasonable protection against harmful interference in a residential installation. This equipment generates, use,s and can radiate radio frequency energy and, if not installed and used in accordance with the Instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation


If this equipment does cause harmful interference to radio or television eception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet the general RF exposure requirements.

The device can be used in portable exposure conditions without restriction.

## Documents / Resources

	<a href="#">Companion FINDER T Global Locator Integrates With Apple Find My Network [pdf]</a> User Manual FINDER T Global Locator Integrates With Apple Find My Network, FINDE R T, Global Locator Integrates With Apple Find My Network, Apple Find M y Network, Find My Network
---	--

## References

- [User Manual](#)



# Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.