



## FitCloudPro Bracelet User Manual

[Home](#) » [FitcloudPro](#) » FitCloudPro Bracelet User Manual

### Contents [ [hide](#) ]

- 1 FitCloudPro Bracelet User Manual
- 2 Please make a full charge before use it. APP: FitCloudPro
- 3 1.3 Enter the APP to bind the searched device.
- 4 3.Functions on App
- 5 4 . Warm notes
- 6 Disclaimer
- 7 Documents / Resources
- 8 Related Posts

## FitCloudPro Bracelet User Manual



**Please make a full charge before use it. APP: FitCloudPro**

### 1.Download & Pairing

1.1 Long press the side button to turn on.

1.2 Scan the following QR code to install FitCloudPro APP,download "FitCloudPro" from App Store, Google Player then install it.



Compatible System: Android4.4 and above iOS 8.2 and above

### 1.3 Enter the APP to bind the searched device.

**Step1** : Enable Bluetooth on the mobile phone;

**Step2** : Open "FitCloudPro" APP , Tap" Add a device" to bind •

- Please keep bluetooth address consistent with your smart bracelet when you connecting.
- Slide down screen from main interface enter into"About"to check bluetooth address.

## 2.Smart bracelet Functions

### 2.1.Time Interface

2.1.1 Power on : Long press side button to turn on.

2.2.2 Power off : On the time interface , long press side button to power off.

2.2.Switch dial:Rotate the button to switch the dial you



2.3.Temperature Monitor

2.4.Sport data(Mileage,Calorie,steps)

2.5.Multi-sports: Running,WalkingClimbing,Riding,Climbing,Ta ble tennis,Badminton,Basketball,Skipping

2.6.Heart rate monitor

2.7.Sleep monitor ( Sleep monitor period:

21:30PM to 12:00AM)

2.8.Blood pressure

2.9.Blood Oxygen

2.10.Music

2.11.Weather

2.12.Stopwatch

2.13.Notifications push (Turn on app" Notifications" social app likeFacebook, Twitte r,Skype etc,

2.14 Find Phone

2.15.Setting language, menu style, bright

screen display, vibration intensity.system

### 3.Functions on App

3.1.Show the testing data(sleep monitor data , Heart rate , Blood pressure , Blood oxgen(click "Health measurement" )

3.2.Device

3.2.1Message Notification Push ( Turn on app "Notifications" social app like Facebook, Twitter, Skype etc,) Call reminder: When the incoming call appears on the bracelet interface,you can long press"reject" incon to ring off.

3.2.2.Alarm clock

3.2.3.Sedentary reminder : reminder per hour

3.2.4.Drink water reminder: reminder every 2 hours

3.2.5.Dail settings : uploading watch face you like

3.2.6.Shake wrist to wake up screen

3.2.7.Enhance Measurement

3.2.8.Find Band

3.2.9.Band location :choose right hand or left hand.

3.2.10.Hour Style : choose 24 hour sor 12 hour system.

3.2.11.Shake photograph

3.2.12.Device Version

3.2.13.Reset

3.2.14. Unbind

**( Notes : Please kindly note above functions are working based on activated and saved the related setup )**

3.3Mine

3.3.1Click" ID " to set your datailed data.like height, weight

3.3.2 GoogleFit: all the sport data will be syncon GoogleFit after connecting app

3.3.3.Exercise goal

## 4 . Warm notes

### 4.1 Connect Bluetooth :

4.1.1 Please power on your phone bluetooth and turn on smart bracelet bluetooth before connecting;

4.1.2 Please ensure your smart bracelet didn' t connect with other phone before connecting ;

4.1.3 Please keep close to your smart bracelet when you are connecting.

4.2 Please turn on mobile phone notifications and allow permissions to run in the background if your Mobile has installed "Mobile manager" or

other similar Apps, otherwise you will not receive the messages.

4.3 Battery Recharge:Power adaptor: 5V 0.5~1A If the bracelet won' t be used for long period, please ensure a full charging every month and turn it off after get full charged


4.4 To ensure the accuracy of blood pressure data, after entering blood pressure monitor mode, please hold the smart band at the same height as your heart, relax yourself and calm down. Do not talk when the monitor is working. (This function is to monitor the blood pressure data change before & after exercise. The data are only for reference, can' t use for special medical purpose)

## Disclaimer

Warning: This product is not a medical device. The smart band and its applications should not be used in diagnosis, treatment or as a preventive treatment for diseases and sickness. Please consult medical professionals before changing exercise habit or sleep habit to avoid serious injuries. The manufacturer reserves the right to modify and improve any functions description in this user guide and continuous update of the new content without further notice. This user guide is for reference only, the smart band for selling is subject to the final product.

FitCloudPro

## Documents / Resources

	<a href="#">FitCloudPro Bracelet</a> [pdf] User Manual Bracelet
---	--