

HealTech HL Pair System Eliminator User Manual

Home » HealTech » HealTech HL Pair System Eliminator User Manual



Contents

- 1 HealTech HL Pair System
- **Eliminator**
- 2 Specifications
- **3 Product Usage Instructions**
- 4 Foreword
- 5 Installation
- **6 Warranty**
- 7 FAQ
- 8 Documents / Resources
 - 8.1 References



HealTech HL Pair System Eliminator



Specifications

• Supply voltage: +5V to +16V

• Size: 30 x 20 x 15mm (1.18 x 0.78 x 0.51)

• Max. supply current at 12V: 130 mA

Weight: 24g (0.84oz)Waterproof: IP68

Plug 'n Go design

• Operating temp: -40°C to +80°C (-40°F to +176°F)

Product Usage Instructions

Installation:

- 1. Ensure you have the correct part for your motorcycle by checking the part number and compatibility on our website.
- 2. Disconnect the headlight unit from your bike and remove it.
- 3. Plug the HLE module into the 8-pin headlight connector on the main wiring harness.
- 4. Peel off the green plastic from the back of the unit, mount it, and secure the wiring with the supplied cable tie.
- 5. Turn the ignition on to ensure the FI light and/or warning message for the missing headlight unit is off.
- 6. You have successfully installed the product. Enjoy your track/race-converted bike!

Warranty:

The unit is sealed and epoxy-encapsulated for extreme protection from shocks, vibrations, and water. It has been extensively tested prior to shipment. The product is covered by a 2-year replacement warranty from the date of purchase.

Foreword

Congratulations on your purchase of a HealTech Electronics Headlight Eliminator module (HLE). This unit will fit select Aprilia and KTM motorcycles. The Plug 'n Go connector makes installation quick and easy, eliminating the need to alter the bike's original wiring.

Attention: Motorcycles without lighting devices (i.e. headlights) aren't allowed on public roads! Please keep your track/race bike where it belongs – on the racetrack! Do not use on public roads.

Installation

- Before installing this product, please make sure you got the right part for your bike. See the part number on the packaging and use the Product Advisor on our website to check compatibility.
- These instructions are applicable to a wide range of motorcycles and describe the main install steps needed for a successful installation. You can find motorcycle-specific Supplementary Manuals on our website.

Please visit: www.healtech-electronics.com/HLE

Disclaimer: Do not attempt to install the product if you don't have basic mechanical skills. HealTech Electronics Ltd. and its distributors shall not be liable for any loss or damage caused by improper installation. If in doubt,

please consult with your dealer.

Follow these steps:

- 1. Disconnect the headlight unit and remove it.
- 2. Plug the HLE module into the 8-pin headlight connector on the main wiring harness.
- 3. Peel off the green plastic from the back of the unit and mount it. Secure the wiring with the supplied cable tie.
- 4. Turn the ignition on. The FI light and/or warning message on the dashboard for the missing headlight unit should be off.
- 5. That's it! You're all set! Enjoy your track/race-converted bike!

Warranty

- The unit is completely sealed and epoxy encapsulated, which gives extreme protection for the internal parts from shocks, vibrations and water.
- To ensure trouble-free operation from the start, all units have been extensively tested prior to shipment.
- Our dealers are offering a 30-day money-back guarantee on HealTech products, thus you will get your money back if the product does not fulfill your expectations (all parts must be returned in original condition for full refund).
- Furthermore, the product is covered by our 2-year replacement warranty from the date of purchase.

www.healtech-electronics.com/HLE

FAQ

Q: Can I use this product on public roads?

A: No, motorcycles without lighting devices (headlights) are not allowed on public roads. Please keep your bike for track/race use only.

Q: What should I do if I have doubts about installing the product?

A: If you are unsure about installing the product, consult with your dealer or a professional to avoid improper installation and any associated risks.

Documents / Resources



HealTech HL Pair System Eliminator [pdf] User Manual

HL Pair System Eliminator, HL, Pair System Eliminator, System Eliminator, Eliminator

References

User Manual

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.