

# HYGIPLAS Countdown Timer Instruction Manual

[Home](#) » [HYGIPLAS](#) » HYGIPLAS Countdown Timer Instruction Manual

# HYGIPLAS

Countdown Timer

Instruction manual



Model: DP028

Contents [hide](#)

- [1 Features](#)
- [2 Installation](#)
- [3 Operation](#)
- [4 Compliance](#)
- [5 DECLARATION OF CONFORMITY](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

## Features

- Big Digit Display
- Loud Buzzer Sound
- Pocket Clip
- Foldaway Stand
- Magnetic attachment

Maximum Count down/ up range	Hour/Minute mode: 19 hours 59 minutes Minute/Second mode: 99 minutes 59 seconds
Digit increment	Hour/Minute mode: 1 minute Minute/Second mode: 1 second
Accuracy	±2 seconds every 99 minutes 59 seconds
Display size	47(W) x 20(H) mm
Battery	1.5 V, size MA or equivalent, 1 piece (included)
Product size	63(W) x 63(H) x 15(D) mm (Clip portion excluded)

## Installation

1. Slide down battery cover.
2. Install battery with correct polarity positioning.
3. Peel off display protective sheet.
4. The unit will display "00 00" and is ready for use.

**Note:** For the [HR/MIN] switch on the back, you can set it to [HR] to enter Hour/Minute mode or [MIN] to enter Minute/the Second mode.

## Operation

1. Press [HR-MIN] and [MIN-SEC] to set the desired count downtime.
2. Press [START/STOP] to start the timer. The buzzer will sound when the display counts down to "00 00".
3. Press [START/STOP] to stop the timer and the preset value will be displayed.
4. Press [HR-MIN] and [MIN-SEC] simultaneously will clear display value to "00 00".
5. Press [START/STOP] to start to count up.
6. When the display counts up to the maximum range, it will re-count from 0.

Remove the batteries if you will not be using the appliance for an extended period of time.

## Compliance

Dispose of depleted batteries in accordance with local regulations, within the EC there are nominated disposal points for batteries.

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.



HYGIPLAS parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities. HYGIPLAS products have been approved to carry the following symbol:



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of HYGIPLAS. Every effort is made to ensure all details are correct at the time of going to press, however, HYGIPLAS reserve the right to change specifications without notice.

## DECLARATION OF CONFORMITY

Equipment Type Countdown Timer (Min/Sec)	Model DP028 <b>Electro-Magnetic Compatibility (EMC) Directive 2014/30/EU – recast of 2004/108/EC</b>
Application of Territory Legislation & Council Directives(s)	IEC EN 61000-6-1:2019 EN 61000-6-3: 2007 +A1:2011 <b>Restriction of Hazardous Substances Directive (RoHS) 2015/863 amending Annex II to Directive 2011/65/EU</b>
Producer Name	<b>Hygiplas</b>

I, the undersigned, hereby declare that the equipment specified above conforms to the above Territory Legislation, Directive(s), and Standard(s).

Date	2nd November 2020		
Signature			
Full Name	Ashley Hooper	Eoghan Donnellan	Josie Holt
Position	Technical & Quality Manager	Commercial Manager/ Importer	Commercial Manager/ Responsible Supplier
Producer Address	Fourth Way, Avonmouth, Bristol, BS11 8TB United Kingdom	42 North Point Business Park New Mallow Road Cork Ireland	15 Bagdally Road, Campbelltown NSW 2560



UK	+44 (0)845 146 2887
Elite	
NL	040 — 2628080
FR	01 60 34 28 80
BE-NL	0800-29129
BE-FR	0800-29229
DE	0800 — 1860806
IT	N/A
ES	901-100 133
PT	<a href="mailto:vendas@nisbets.pt">vendas@nisbets.pt</a>
AU	1300 225 960

## Documents / Resources



[HYGIPLAS HYGIPLAS Countdown Timer](#) [pdf] Instruction Manual  
HYGIPLAS, Countdown, Timer

## [Manuals+](#)

- [home](#)
- [privacy](#)