

[Skip to content](#)

**Manuals+**

User Manuals Simplified.

# I-BOM Smart Diaper Sensor User Manual

[Home](#) » [I-BOM](#) » I-BOM Smart Diaper Sensor User Manual

Contents [hide](#)

[1 I-BOM Smart Diaper Sensor](#)

[2 Specification](#)

[3 Product contents](#)

[4 Functions](#)

[5 How to use](#)

[6 Certification](#)

[7 FCC Warning Statement](#)

[8 Documents / Resources](#)

[8.1 References](#)

[9 Related Posts](#)

# Ibom

## I-BOM Smart Diaper Sensor



### Specification

Product Name	Smart Diaper Sensor
Model Name	i-BOM (SiB-12)
Power	DC 3V (Coin Battery, CR2032), 220mAh
Communication	BLE 5.0
Product size	25mm x 207mm x 8.5mm
Product weight	13g
Operating	Temp. : +10°C ~ +40°C, Humidity : under 85%RH
Storage	Temp. : -10°C ~ +60°C, Humidity : under 90%RH

### Product contents

- Sensor Module: 1ea
- Sensor band : 1ea

### Functions

- Urine Alert
- Ambient temperature display

- Personal care mode: 1~3 babies /
- Defecation diary
- Baby character customizing

## How to use

- Install 'i-BOM' app to smart phone from google play store.(<https://play.google.com/store/apps/details?id=com.soft.ean>)



- Push the button near the nose of the character
- Run 'i-BOM' app and register the sensor.



- Attach the diaper sensor to the diaper
- When a defecation alarm comes, check the diaper, replace with a new diaper, and then attach the diaper sensor to the new diaper.

## Certification

- FCC ID : 2A27S-I-BOM
- KC ID : R-R-s9d-i-BOM

## FCC Warning Statement

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

## Caution

- Do not use the product for any purpose other than its intended purpose. It may cause damage or injury.
- Do not disassemble or repair the product arbitrarily. It may cause malfunction or fire.
- Do not store the product in a high-temperature place or near the fire. It may deform the appearance or cause malfunction.
- Be careful not to get chemicals on the product. The product may be damaged and there is a risk of transmission to the human body.
- Do not allow any conductive material such as metal or liquid to come into contact with the contact point between the module and the band. It may cause product damage.
- Be careful of falling, immersion, and impact. The internal components may be damaged.
- Be careful not to allow infants or pets to suck or bite the product.
- It is recommended to use this device for infants from 0 to 24 months of age, and caution is required for shock and disassembly when used by infants over 24 months of age.
- When replacing the band, there is a risk that the separated parts may be swallowed by infants, so be sure to separate the body and the band out of the reach of children.

## Documents / Resources

I-BOM I-BOM Smart Diaper Sensor [pdf] User Manual  
I-BOM, IBOM, 2A27S-I-BOM, 2A27SIBOM, I-BOM Smart Diaper Sensor, I-BOM, Smart Diaper Sensor

- [!\[\]\(8be7dbed0cdcd9134bb63b78488f98f4\_img.jpg\) i..i'ë'..\(i-BOM\) - Apps on Google Play](#)

- [home](#)
- [privacy](#)