



ideal-tek LE-UVWE5D Magnifying LED Lamp User Manual

[Home](#) » [ideal-tek](#) » ideal-tek LE-UVWE5D Magnifying LED Lamp User Manual 

ideal-tek LE-UVWE5D Magnifying LED Lamp User Manual



Contents

- [1 PRODUCT INFORMATION](#)
- [2 ASSEMBLY](#)
- [3 HOW TO USE](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

PRODUCT INFORMATION



Magnification	2.25X (5-Diopter)
Lens Dimension	19 x 15,7 mm (7.5" x 6.2")
Color	Black
Lighting	48 White LEDs (6500K) 30 UV LEDs (400nm)
Lumen	Max: 1100Lm
ESD safe	Yes

ASSEMBLY

- LE-UVWE5D package includes the following items:
- LE-UVWE5D unit
- Heavy Duty Mounting Clamp
- Power Supply
- LE-UVWE5D manual

Mounting LE-UVWE5D Magnifying Lamp

1. Attach the mounting clamp to the side of your work bench and hand tighten
2. Then insert LE-UVWE5D lamp into the hole of the mounting table clamp

HOW TO USE

Using Your LE-UVWE5D Magnifying Lamp



1. Connect LE-UVWE5D to a power outlet
2. Turn the power ON/OFF by pressing the Power Switch
3. Select White LEDs or UV LEDs
4. Adjust the brightness with the LED Brightness Control (works with White LEDs only)

Adjusting Arm Position



1. Loosen the Adjustable Tension Knob
2. Set the desired position and lamp head angle, and re-tighten

Documents / Resources

	<p>ideal-tek LE-UVWE5D Magnifying LED Lamp [pdf] User Manual LE-UVWE5D, Magnifying LED Lamp, LE-UVWE5D Magnifying LED Lamp</p>
---	--

References

- [Ideal-tek - Swiss High precision tools since 1964](#)