



ideal-tek LE-WWE5D LED Illuminated Magnifier Instruction Manual

[Home](#) » [ideal-tek](#) » ideal-tek LE-WWE5D LED Illuminated Magnifier Instruction Manual 



LE-WWE5D



Contents

- [1 PRODUCT INFORMATION](#)
- [2 ASSEMBLY](#)
- [3 HOW TO USE](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

PRODUCT INFORMATION

Magnification	2.25X (5-Diopter)
Lens Dimension Color	7.5" x 6.2"
Color	Black
Lighting	30 LEDs (3500K) 30 LEDs (6500K)
ESD safe	Yes

ASSEMBLY

LE-WWE5D package includes the following items:

- LE-WWE5D unit
- Heavy Duty Mounting Clamp
- Power Supply
- LE-WWE5D manual

Mounting LE-WWE5D Magnifying Lamp

1. Attach the mounting clamp to the side of your workbench and hand tighten
2. Then insert the LE-WWE5D lamp into the hole of the mounting table clamp

HOW TO USE

Using Your LE-WWE5D Magnifying Lamp



1. Connect LE-WWE5D to a power outlet
2. Turn the power ON/OFF by pressing the Power Switch
3. Adjust the brightness of the white LEDs with the White LED Controls
4. Adjust the brightness of the amber LEDs with the Amber LED Controls




Adjusting Arm Position

1. Loosen the Adjustable Tension Knob
2. Set the desired position and lamp head angle, and re-tighten

ideal-tek.com

Documents / Resources

	<p>ideal-tek LE-WWE5D LED Illuminated Magnifier [pdf] Instruction Manual LE-WWE5D LED Illuminated Magnifier, LE-WWE5D, LED Illuminated Magnifier</p>
---	--