

**IDEAL®**  
**35-206 Precision**  
**Levels**



## IDEAL 35-206 Precision Levels Instructions

[Home](#) » [IDEAL](#) » IDEAL 35-206 Precision Levels Instructions 

### Contents

- [1 IDEAL 35-206 Precision Levels](#)
- [2 Product Specifications](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 Changing a Spirit Vial in an IDEAL® PRECISION LEVEL](#)
- [6 Installation Instructions](#)
- [7 WARRANTY](#)
- [8 CONTACT](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)



**IDEAL 35-206 Precision Levels**





## Product Specifications

- **Models:** 35-206, 35-207, 35-208
- **Features:** Tough molded acrylic vials with shock-absorbing rubber O-rings
- **Vial Replacement:** Easy field replacement design
- **Origin:** Made in Taiwan

## Product Usage Instructions

### Vial Replacement

- Remove the set screw using a hex wrench.
- Take out the O-ring and the damaged vial carefully.
- Insert the new vial into the level.
- Reinstall the O-ring and set the screw securely.

If you have any questions or need assistance, you can reach out to IDEAL INDUSTRIES, INC. at [800-435-0705](tel:800-435-0705) or visit their website at [www.idealind.com](http://www.idealind.com).

## FAQ

- **Q:** What should I do if my spirit-level vial is damaged?
- **A:** Follow the provided instructions to replace the vial with a new one easily in the field.
- **Q:** Where can I find warranty information for the product?
- **A:** Visit [www.idealind.com](http://www.idealind.com) or contact Customer Assistance at [800-435-0705](tel:800-435-0705) for warranty details.

## Changing a Spirit Vial in an IDEAL® PRECISION LEVEL

- The most frequent failure of spirit levels is damage to the vials.
- IDEAL Precision Levels feature tough, molded acrylic vials with shock-absorbing rubber O-rings, which virtually eliminate shock damage to the vials.



- Additionally, unlike most competitors' vials, which are typically glued into their levels, IDEAL vials are designed for easy field replacement.

## Installation Instructions

1. Remove the set screw with a hex wrench



2. Remove O-ring and damaged vial



3. Insert new vial





#### 4. Reinstall O-ring and set screw



## WARRANTY

- See [www.idealind.com](http://www.idealind.com), or call Customer Assistance at [800-435-0705](tel:800-435-0705) for warranty details.

## CONTACT

### IDEAL INDUSTRIES, INC.

- 1800 S. Prairie Drive
- Sycamore, IL 60178, U.S.A.
- [800-435-0705](tel:800-435-0705)
- [www.idealind.com](http://www.idealind.com)
- ND XXXX-1 Made in Taiwan

## Documents / Resources

	<p><a href="#">IDEAL 35-206 Precision Levels</a> [pdf] Instructions 35-206, 35-207, 35-208, 35-206 Precision Levels, 35-206, Precision Levels, Levels</p>
--	---

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.