



Home » Insta360 » Insta360 Flow 2 Pro Al Tracker Instruction Manual 🥦

## Contents [ hide ]

- 1 Insta360 Flow 2 Pro Al Tracker
- 2 Specifications
- 3 Part Names
- 4 How to Use
- 5 Spotlight Instructions
- 6 Indicator Status
- 7 Disclaimer
- 8 After-Sales Service
- 9 Documents / Resources
  - 9.1 References




Insta360 Flow 2 Pro Al Tracker



## **Specifications**

- **Dimensions** 57.4 x 46 x 15.8mm (2.3 x 1.8 x 0.6in)
- **Weight** 14g (±0.5g) / 0.49oz (±0.02oz)
- Power Consumption 1.6W
- Power Input 5V 320mA
- Colour Temperature Options: Cool (5000K), Warm (2900K), Mixed (35001<)
- Illumination 1 O BO Lux (0.6m distance from subject)
- Operating Temperature: 14°F to 104°F (-10·c to 40°C)


### **Part Names**




## How to Use

#### 1. Installation and Removal


1. Connect your gimbal to your phone via Bluetooth. Align the notch on the gimbal's tilt axis with the USB port and insert the Al Tracker.



2. Position the AI Tracker facing forward for front camera use and backwards for rear camera use.



3. To remove the A1 Tracker, press the clips on both sides and detach it by gently pulling it away from the gimbal.



Notes: Before using the Al Tracker for the first time, upgrade the Insta360
 App to the latest version. If an update is available, follow the on-screen

instructions to install it.

- Ensure the Al Tracker is properly aligned and the clips are securely attached before using it.
- While in use, keep your gimbal connected to your phone via Bluetooth
- The Al Tracker is powered by the gimbal. If the gimbal is powered off or out of battery, the Al Tracker will not work.

## 2. Tracking Instructions

- 1. Press the Al Tracker Button to turn it on or off.
- 2. Use the Al Tracker to track people or animals (cats and dogs) through hand gestures or the Trigger Button on your gimbal.



## Palm gesture:

Start/stop tracking.



# **Trigger Button:**

- Single Press: Start/stop tracking or wake the Al Tracker.
- Double Press: Stop tracking and recenter the gimbal.
- Triple Press: Stop tracking and switch the phone between forwardfacing and backwards-facing.



## Peace gesture:

Start/stop recording video. Start/stop taking photos.



## Joystick:

 Adjust the central point of tracking by moving the Joystick up, down, left, or right.


#### Notes:

• If the Trigger Button is not pressed or tracking is not activated within 5 minutes\* after connecting the AI Tracker to the gimbal, it will enter standby mode.

- To wake the Al Tracker, press the Trigger Button on the gimbal or any button on the Al Tracker. If awakened via the Trigger Button, the Al Tracker will start tracking immediately.
- After pressing the gimbal's Trigger Button, the Al Tracker will automatically select and track a subject in the centre of the frame. In scenes with multiple people, gesture control is recommended for selecting a subject.
- In scenes with multiple pets, move closer to the target pet and use the Trigger Button for best results.
- For gesture control, adults should face the Gesture Recognition Lens and perform gestures at a distance of 1.6 to 16ft (0.5 to 5 meters). For children, the recommended distance is 1.6 to 6.5ft (0.5 to 2 meters).
- The Al Tracker supports tracking in the native camera app and third-party apps. The
  tracking function of the Al Tracker cannot work when you track on the shooting page
  inside the Insta360 App, though the spotlight function will still work.
- If no action is taken within 5 minutes, the Al Tracker will enter standby mode. You can adjust this in the settings.
- To adjust the standby timeout, make sure the gimbal and Al Tracker are powered on and connected to the Insta36D App. Open the App and go to
   Settings > Device
   Settings > Al Tracker Management > Standby Timeout

## **Spotlight Instructions**

- Long-press the Colour Temperature Button or Brightness Button to turn the spotlight on or off
- 2. Press the Colour Temperature Button to cycle through cool, warm, and mixed colour temperatures. Press the Brightness Button to adjust the brightness to high, medium, or low.



#### **Notes**

- The Al Tracker is not waterproof. Do not immerse it in water or expose it to moisture.
- Do not hit, crush, or throw the Al Tracker.
- Avoid using the AI Tracker during high-intensity activities to prevent it from falling.
- Avoid direct skin contact with the USB-C Connector after prolonged use.
- Clean the Al Tracker with a soft, dry cloth. Avoid using cleaning liquids.

### **Indicator Status**

Al Tracker Status	Indicator Status
Clips not fully inserted/ clips loose	Flashes red
Power on/ Stop tracking	Solid red
Tracking	Solid green
Tracking failed	Flashes green
Start/stop recording video. Start taking photos	Spotlight flashes three times
Entering standby mode	Flashes yellow
Start tracking after exiting standby mod e	Flashes yellow, then red before turning soli d green
Firmware updating	Flashes red and green alternately

### **Disclaimer**

- Please read this Disclaimer carefully. Using this product means that you acknowledge and accept the terms of this disclaimer.
- By using this product, you hereby acknowledge and agree that you are solely responsible for your conduct when using this product and any consequences thereof.
- You agree to use this product only for proper and lawful purposes.
- You understand and agree that Arashi Vision Inc. (hereinafter referred to as 'Insta360')

accepts no liability for all misuse, consequences, damages, injuries, penalties, or any other legal responsibility directly or indirectly incurred by your using this product and associated accessories. Before every use, make sure that your accessories are functioning properly.

- If there's any damage or irregularity, stop using them immediately.
- Within the scope of state laws and regulations, Insta360 reserves the right to final explanation and revision for the commitment.

#### **After-Sales Service**

- The warranty period of the attached product is 1 year from the original retail purchase.
- Warranty service may vary according to the applicable laws of your state or jurisdiction.
- For detailed warranty policies, please visit <a href="https://insta360.com/support">https://insta360.com/support</a>
- Arashi Vision (U.S.) LLC
- TEL: +18006920360
- WEB: www.insta360.com
- EMAIL: service@insta360.com
- ADDRESS: 2323 Main St, Unit 1, 92614, United States
- EC REP Insta360 GmbH
- TEL: +49 30221520255
- WEB: www.insta360.com
- EMAIL: service@insta360.com
- ADDRESS: Gartenfelder Straße 29-37, Gebäude 31 /31.12
- 1.OG, 13599 Berlin Germany

## **Documents / Resources**



Insta360 Flow 2 Pro Al Tracker [pdf] Instruction Manual
CINSABQA-FLOW2LITE10, 842126113024, Flow 2 Pro Al Tracker, Flow
2 Pro, Al Tracker, Tracker

#### References

#### User Manual

- ▶ 842126113024, AI Tracker, CINSABQA-FLOW2LITE10, Flow 2 Pro, Flow 2 Pro AI Tracker, Insta360,
- Insta360 Tracker

## Leave a comment

Your email address will not be published. Required fields are marked\* Comment \* Name Email Website ☐ Save my name, email, and website in this browser for the next time I comment. **Post Comment** Search:

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

e.g. whirlpool wrf535swhz

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.

Search