



## logitech HM803B Wireless Hygiene Mouse with Scroll Wheel Sensor Instructions

[Home](#) » [Logitech](#) » logitech HM803B Wireless Hygiene Mouse with Scroll Wheel Sensor Instructions 

# logitech

### Contents

- [1 logitech HM803B Wireless Hygiene Mouse with Scroll Wheel Sensor](#)
- [2 Quick Start](#)
- [3 FAQ](#)
- [4 Delivery Content](#)
- [5 FCC Statment](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

### logitech HM803B Wireless Hygiene Mouse with Scroll Wheel Sensor



## Quick Start

1. Take out the USB receiver dongle
2. Insert the supplied batteries as marked inside the battery compartment
3. Close the battery cover and tighten the screws
4. Connect the dongle to a free USB port at your PC and start your computer
5. Start using the mouse after automatic driver installation has completed

### **As a distributor of batteries, we have the following obligations under §18 BattG:**

1. Batteries can be returned free of charge after use in the commercial firm.
2. End users are legally obliged to return used batteries.
3. Manufacturers of batteries are required to mark batteries with the following symbol before placing them on the market for the first time:

The manufacturer of batteries shall label batteries containing more than 0.0005% by mass of mercury, more than 0.002% by mass of cadmium or more than 0.004% by mass of lead, before placing them on the market for the first time with the chemical symbols of metals (Hg, Cd, Pb) in which the limit is exceeded. The characters are to be applied below the symbol.

**Safety Note: The enclosed batteries must not be charged!**

## FAQ

### **How to pair a dongle with the device?**

Please follow the instructions below

1. Remove the batteries from the mouse and plug out the dongle from the computer
2. Plug in the dongle to the computer
3. In the first 15 seconds after the dongle is plugged, place the mouse as close as possible to the dongle (less than 1cm). Press and hold right button and middle button (inside the battery compartment) and install the batteries to the mouse
4. Keep holding the right button and middle button for 2 seconds and then release them
5. Test the mouse for function. If the pairing process was not successful, repeat the instructions from step (1)

## Delivery Content

- 2,4 GHz wireless mouse
- 2,4 GHz USB-receiver
- 2x AAA batteries
- Screwdriver
- Instructions

## FCC Statment

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Changes or modifications not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

## Documents / Resources

	<a href="#">logitech HM803B Wireless Hygiene Mouse with Scroll Wheel Sensor</a> [pdf] Instructions HM803B, XEN-HM803B, XENHM803B, HM803B Wireless Hygiene Mouse with Scroll Wheel Sensor, Wireless Hygiene Mouse with Scroll Wheel Sensor
---	---