

CR1100 & CR1500

- Not Compatible with Other Models -

VERSION 03 – RELEASE DATE JAN 2022



codecorp.com

Configuring CR1100 & CR1500 Barcode Readers

To configure a CR1100 or CR1500 to be assigned to a patient room or workstation-on-wheels, scan only one of the following barcodes:



CC004395_02

Epic Patient Look up

&



CC005888_01

Epic Alt Keypad Emulator

CR1500 Feedback Settings

Scan the preferred feedback settings (not for a CR1100):



M20329_01

Beep On
Vibrate On



M20331_01

Beep On
Vibrate Off



M20330_01

Beep Off
Vibrate On

CR100 and CR1500 Reader Settings



M20111_01

Reset to factory defaults

Firmware Version Information

Scan the following barcodes to identify firmware versions:



M20361_01

Reader information